


SDK-ATEM Switchers Software Developers Kit.

Blackmagicdesign 



Mac OS X™

Windows™

December 2015

Table of Contents

| | | |
|----------|--|-----------|
| 1 | Introduction | 27 |
| 1.1 | Welcome | 27 |
| 1.2 | Overview | 27 |
| 1.3 | API Design | 28 |
| 1.3.1 | Overview | 28 |
| 1.3.2 | Object Model | 28 |
| 1.3.3 | Object Interfaces | 28 |
| 1.3.4 | Reference Counting | 29 |
| 1.3.5 | Interface Stability | 29 |
| 1.3.5.1 | New Interfaces | 29 |
| 1.3.5.2 | Updated Interfaces | 30 |
| 1.3.5.3 | Deprecated Interfaces | 30 |
| 1.3.5.4 | Removed interfaces | 30 |
| 1.4 | Interface Reference | 31 |
| 1.4.1 | IUnknown Interface | 31 |
| 1.4.1.1 | IUnknown::QueryInterface method | 32 |
| 1.4.1.2 | IUnknown::AddRef method | 33 |
| 1.4.1.3 | IUnknown::Release method | 33 |
| 1.5 | Using the Switcher API in a project | 34 |
| 1.5.1 | Basic Types | 35 |
| 1.5.2 | Accessing Switcher devices | 36 |
| 1.5.2.1 | Windows | 36 |
| 1.5.2.2 | Mac OS X | 37 |
| 2 | Basic Switcher Control | 38 |
| 2.1 | General Information | 38 |
| 2.1.1 | Switcher Configuration and Transitions | 38 |
| 2.1.2 | Switcher Interface Diagram | 39 |
| 2.2 | Switcher Data Types | 40 |
| 2.2.1 | Basic Switcher Data Types | 40 |
| 2.2.2 | Switcher Event Type | 40 |
| 2.2.3 | Switcher Power Status | 40 |
| 2.2.4 | Switcher Video Mode | 41 |

Table of Contents

| | | |
|----------|---|----|
| 2.2.5 | Switcher Down Conversion Methods | 42 |
| 2.2.6 | Switcher Input Event Types | 42 |
| 2.2.7 | Switcher External Port Types | 43 |
| 2.2.8 | Switcher Port Types | 43 |
| 2.2.9 | Switcher Input Availability | 44 |
| 2.2.10 | Switcher Mix Effect Block Properties | 44 |
| 2.2.11 | Switcher Connection Errors | 45 |
| 2.2.12 | Switcher MultiView Layouts | 45 |
| 2.2.13 | Switcher Serial Port Functions | 45 |
| 2.2.14 | Switcher Color Events | 46 |
| 2.2.15 | Switcher Aux Events | 46 |
| 2.2.16 | Switcher MultiView Events | 46 |
| 2.2.17 | Switcher Serial Port Event Types | 46 |
| 2.3 | Interface Reference | 47 |
| 2.3.1 | IBMDSwitcherDiscovery Interface | 47 |
| 2.3.1.1 | IBMDSwitcherDiscovery::ConnectTo method | 48 |
| 2.3.2 | IBMDSwitcher Interface | 49 |
| 2.3.2.1 | IBMDSwitcher:: GetProductName method | 50 |
| 2.3.2.2 | IBMDSwitcher:: GetVideoMode method | 50 |
| 2.3.2.3 | IBMDSwitcher:: SetVideoMode method | 51 |
| 2.3.2.4 | IBMDSwitcher:: DoesSupportVideoMode method | 52 |
| 2.3.2.5 | IBMDSwitcher:: GetMethodForDownConvertedSD method | 53 |
| 2.3.2.6 | IBMDSwitcher:: SetMethodForDownConvertedSD method | 54 |
| 2.3.2.7 | IBMDSwitcher:: GetDownConvertedHDVideoMode method | 55 |
| 2.3.2.8 | IBMDSwitcher:: SetDownConvertedHDVideoMode method | 56 |
| 2.3.2.9 | IBMDSwitcher:: DoesSupportDownConvertedHDVideoMode method | 57 |
| 2.3.2.10 | IBMDSwitcher:: GetMultiViewVideoMode method | 58 |
| 2.3.2.11 | IBMDSwitcher:: SetMultiViewVideoMode method | 59 |
| 2.3.2.12 | IBMDSwitcher:: DoesSupportMultiViewVideoMode method | 60 |
| 2.3.2.13 | IBMDSwitcher:: GetPowerStatus method | 61 |
| 2.3.2.14 | IBMDSwitcher:: CreateIterator method | 62 |
| 2.3.2.15 | IBMDSwitcher:: AddCallback method | 63 |
| 2.3.2.16 | IBMDSwitcher:: RemoveCallback method | 64 |
| 2.3.3 | IBMDSwitcherCallback Interface | 65 |
| 2.3.3.1 | IBMDSwitcherCallback:: Notify method | 66 |
| 2.3.4 | IBMDSwitcherInputIterator Interface | 67 |

Table of Contents

| | | |
|----------|--|-----|
| 2.3.4.1 | IBMDSwitcherInputIterator::Next method | 68 |
| 2.3.4.2 | IBMDSwitcherInputIterator::GetById method | 69 |
| 2.3.5 | IBMDSwitcherInput Interface | 70 |
| 2.3.5.1 | IBMDSwitcherInput::AddCallback method | 72 |
| 2.3.5.2 | IBMDSwitcherInput::RemoveCallback method | 73 |
| 2.3.5.3 | IBMDSwitcherInput::GetInputId method | 73 |
| 2.3.5.4 | IBMDSwitcherInput::GetPortType method | 74 |
| 2.3.5.5 | IBMDSwitcherInput::GetInputAvailability method | 75 |
| 2.3.5.6 | IBMDSwitcherInput::SetShortName method | 76 |
| 2.3.5.7 | IBMDSwitcherInput::GetShortName method | 77 |
| 2.3.5.8 | IBMDSwitcherInput::SetLongName method | 78 |
| 2.3.5.9 | IBMDSwitcherInput::GetLongName method | 79 |
| 2.3.5.10 | IBMDSwitcherInput::ResetNames method | 80 |
| 2.3.5.11 | IBMDSwitcherInput::IsProgramTallied method | 81 |
| 2.3.5.12 | IBMDSwitcherInput::IsPreviewTallied method | 82 |
| 2.3.5.13 | IBMDSwitcherInput::GetAvailableExternalPortTypes method | 83 |
| 2.3.5.14 | IBMDSwitcherInput::SetCurrentExternalPortType method | 84 |
| 2.3.6 | IBMDSwitcherInputCallback Interface | 85 |
| 2.3.6.1 | IBMDSwitcherInputCallback::Notify method | 86 |
| 2.3.7 | IBMDSwitcherMixEffectBlockIterator Interface | 87 |
| 2.3.7.1 | IBMDSwitcherMixEffectBlockIterator::Next method | 88 |
| 2.3.8 | IBMDSwitcherMixEffectBlock Interface | 89 |
| 2.3.8.1 | IBMDSwitcherMixEffectBlock::CreateIterator method | 90 |
| 2.3.8.2 | IBMDSwitcherMixEffectBlock::AddCallback method | 91 |
| 2.3.8.3 | IBMDSwitcherMixEffectBlock::RemoveCallback method | 92 |
| 2.3.8.4 | IBMDSwitcherMixEffectBlock::GetFlag method | 93 |
| 2.3.8.5 | IBMDSwitcherMixEffectBlock::GetInt method | 94 |
| 2.3.8.6 | IBMDSwitcherMixEffectBlock::GetFloat method | 95 |
| 2.3.8.7 | IBMDSwitcherMixEffectBlock::GetString method | 96 |
| 2.3.8.8 | IBMDSwitcherMixEffectBlock::SetFlag method | 97 |
| 2.3.8.9 | IBMDSwitcherMixEffectBlock::SetInt method | 98 |
| 2.3.8.10 | IBMDSwitcherMixEffectBlock::SetFloat method | 99 |
| 2.3.8.11 | IBMDSwitcherMixEffectBlock::SetString method | 100 |
| 2.3.8.12 | IBMDSwitcherMixEffectBlock::PerformAutoTransition method | 101 |
| 2.3.8.13 | IBMDSwitcherMixEffectBlock::PerformCut method | 102 |
| 2.3.8.14 | IBMDSwitcherMixEffectBlock::PerformFadeToBlack method | 102 |

Table of Contents

| | | |
|----------|--|-----|
| 2.3.9 | IBMDSwitcherMixEffectBlockCallback Interface | 103 |
| 2.3.9.1 | IBMDSwitcherMixEffectBlockCallback::PropertyChanged method | 104 |
| 2.3.10 | IBMDSwitcherInputColor Interface | 105 |
| 2.3.10.1 | IBMDSwitcherInputColor::GetHue method | 106 |
| 2.3.10.2 | IBMDSwitcherInputColor::SetHue method | 107 |
| 2.3.10.3 | IBMDSwitcherInputColor::GetSaturation method | 107 |
| 2.3.10.4 | IBMDSwitcherInputColor::SetSaturation method | 108 |
| 2.3.10.5 | IBMDSwitcherInputColor::GetLuma method | 108 |
| 2.3.10.6 | IBMDSwitcherInputColor::SetLuma method | 109 |
| 2.3.10.7 | IBMDSwitcherInputColor::AddCallback method | 110 |
| 2.3.10.8 | IBMDSwitcherInputColor::RemoveCallback method | 111 |
| 2.3.11 | IBMDSwitcherInputColorCallback Interface | 112 |
| 2.3.11.1 | IBMDSwitcherInputColorCallback::Notify method | 113 |
| 2.3.12 | IBMDSwitcherInputAux Interface | 114 |
| 2.3.12.1 | IBMDSwitcherInputAux::GetInputSource method | 115 |
| 2.3.12.2 | IBMDSwitcherInputAux::SetInputSource method | 116 |
| 2.3.12.3 | IBMDSwitcherInputAux::GetInputAvailabilityMask method | 117 |
| 2.3.12.4 | IBMDSwitcherInputAux::AddCallback method | 118 |
| 2.3.12.5 | IBMDSwitcherInputAux::RemoveCallback method | 119 |
| 2.3.13 | IBMDSwitcherInputAuxCallback Interface | 120 |
| 2.3.13.1 | IBMDSwitcherInputAuxCallback::Notify method | 121 |
| 2.3.14 | IBMDSwitcherMultiViewIterator Interface | 122 |
| 2.3.14.1 | IBMDSwitcherMultiViewIterator::Next method | 123 |
| 2.3.15 | IBMDSwitcherMultiView Interface | 124 |
| 2.3.15.1 | IBMDSwitcherMultiView::GetLayout method | 125 |
| 2.3.15.2 | IBMDSwitcherMultiView::SetLayout method | 126 |
| 2.3.15.3 | IBMDSwitcherMultiView::GetWindowInput method | 127 |
| 2.3.15.4 | IBMDSwitcherMultiView::SetWindowInput method | 128 |
| 2.3.15.5 | IBMDSwitcherMultiView::GetWindowCount method | 129 |
| 2.3.15.6 | IBMDSwitcherMultiView::GetInputAvailabilityMask method | 130 |
| 2.3.15.7 | IBMDSwitcherMultiView::CanRouteInputs method | 131 |
| 2.3.15.8 | IBMDSwitcherMultiView::AddCallback method | 132 |
| 2.3.15.9 | IBMDSwitcherMultiView::RemoveCallback method | 133 |
| 2.3.16 | IBMDSwitcherMultiViewCallback Interface | 134 |
| 2.3.16.1 | IBMDSwitcherMultiViewCallback::Notify method | 135 |
| 2.3.17 | IBMDSwitcherSerialPortIterator Interface | 136 |

Table of Contents

| | | |
|----------|--|-----|
| 2.3.17.1 | IBMDSwitcherSerialPortIterator::Next method | 137 |
| 2.3.18 | IBMDSwitcherSerialPort Interface | 138 |
| 2.3.18.1 | IBMDSwitcherSerialPort::SetFunction method | 139 |
| 2.3.18.2 | IBMDSwitcherSerialPort::GetFunction method | 140 |
| 2.3.18.3 | IBMDSwitcherSerialPort::DoesSupportFunction method | 141 |
| 2.3.18.4 | IBMDSwitcherSerialPort::AddCallback method | 142 |
| 2.3.18.5 | IBMDSwitcherSerialPort::RemoveCallback method | 143 |
| 2.3.19 | IBMDSwitcherSerialPortCallback Interface | 144 |
| 2.3.19.1 | IBMDSwitcherSerialPortCallback::Notify method | 145 |

3 Advanced Transitions 146

| | | |
|---------|--|-----|
| 3.1 | Data Types | 146 |
| 3.1.1 | Mix Parameters Event Type | 146 |
| 3.1.2 | Dip Parameters Event Type | 146 |
| 3.1.3 | Wipe Parameters Event Type | 146 |
| 3.1.4 | DVE Parameters Event Type | 147 |
| 3.1.5 | Stinger Parameters Event Type | 148 |
| 3.1.6 | Transition Parameters Event Type | 148 |
| 3.1.7 | Transition Style | 149 |
| 3.1.8 | Transition Selection | 149 |
| 3.1.9 | DVE Transition Style | 150 |
| 3.1.10 | Stinger Transition Source | 151 |
| 3.2 | Interface Reference | 152 |
| 3.2.1 | IBMDSwitcherTransitionMixParameters Interface | 152 |
| 3.2.1.1 | IBMDSwitcherTransitionMixParameters::GetRate method | 153 |
| 3.2.1.2 | IBMDSwitcherTransitionMixParameters::SetRate method | 154 |
| 3.2.1.3 | IBMDSwitcherTransitionMixParameters::AddCallback method | 155 |
| 3.2.1.4 | IBMDSwitcherTransitionMixParameters::RemoveCallback method | 156 |
| 3.2.2 | IBMDSwitcherTransitionMixParametersCallback Interface | 157 |
| 3.2.2.1 | IBMDSwitcherTransitionMixParametersCallback::Notify method | 158 |
| 3.2.3 | IBMDSwitcherTransitionDipParameters Interface | 159 |
| 3.2.3.1 | IBMDSwitcherTransitionDipParameters::GetRate method | 160 |
| 3.2.3.2 | IBMDSwitcherTransitionDipParameters::SetRate method | 161 |
| 3.2.3.3 | IBMDSwitcherTransitionDipParameters::GetInputDip method | 162 |
| 3.2.3.4 | IBMDSwitcherTransitionDipParameters::SetInputDip method | 163 |

Table of Contents

| | | |
|----------|--|-----|
| 3.2.3.5 | IBMDSwitcherTransitionDipParameters::AddCallback method | 164 |
| 3.2.3.6 | IBMDSwitcherTransitionDipParameters::RemoveCallback method | 165 |
| 3.2.4 | IBMDSwitcherTransitionDipParametersCallback Interface | 166 |
| 3.2.4.1 | IBMDSwitcherTransitionDipParametersCallback::Notify method | 167 |
| 3.2.5 | IBMDSwitcherTransitionWipeParametersCallback Interface | 168 |
| 3.2.5.1 | IBMDSwitcherTransitionWipeParametersCallback::Notify method | 169 |
| 3.2.6 | IBMDSwitcherTransitionWipeParameters Interface | 170 |
| 3.2.6.1 | IBMDSwitcherTransitionWipeParameters::GetRate method | 172 |
| 3.2.6.2 | IBMDSwitcherTransitionWipeParameters::SetRate method | 173 |
| 3.2.6.3 | IBMDSwitcherTransitionWipeParameters::GetPattern method | 174 |
| 3.2.6.4 | IBMDSwitcherTransitionWipeParameters::SetPattern method | 175 |
| 3.2.6.5 | IBMDSwitcherTransitionWipeParameters::GetBorderSize method | 176 |
| 3.2.6.6 | IBMDSwitcherTransitionWipeParameters::SetBorderSize method | 176 |
| 3.2.6.7 | IBMDSwitcherTransitionWipeParameters::GetInputBorder method | 177 |
| 3.2.6.8 | IBMDSwitcherTransitionWipeParameters::SetInputBorder method | 178 |
| 3.2.6.9 | IBMDSwitcherTransitionWipeParameters::GetSymmetry method | 179 |
| 3.2.6.10 | IBMDSwitcherTransitionWipeParameters::SetSymmetry method | 179 |
| 3.2.6.11 | IBMDSwitcherTransitionWipeParameters::GetSoftness method | 180 |
| 3.2.6.12 | IBMDSwitcherTransitionWipeParameters::SetSoftness method | 180 |
| 3.2.6.13 | IBMDSwitcherTransitionWipeParameters::GetHorizontalOffset method | 181 |
| 3.2.6.14 | IBMDSwitcherTransitionWipeParameters::SetHorizontalOffset method | 181 |
| 3.2.6.15 | IBMDSwitcherTransitionWipeParameters::GetVerticalOffset method | 182 |
| 3.2.6.16 | IBMDSwitcherTransitionWipeParameters::SetVerticalOffset method | 182 |
| 3.2.6.17 | IBMDSwitcherTransitionWipeParameters::GetReverse method | 183 |
| 3.2.6.18 | IBMDSwitcherTransitionWipeParameters::SetReverse method | 183 |
| 3.2.6.19 | IBMDSwitcherTransitionWipeParameters::GetFlipFlop method | 184 |
| 3.2.6.20 | IBMDSwitcherTransitionWipeParameters::SetFlipFlop method | 184 |
| 3.2.6.21 | IBMDSwitcherTransitionWipeParameters::AddCallback method | 185 |
| 3.2.6.22 | IBMDSwitcherTransitionWipeParameters::RemoveCallback method | 186 |
| 3.2.7 | IBMDSwitcherTransitionDVEParameters Interface | 187 |
| 3.2.7.1 | IBMDSwitcherTransitionDVEParameters::GetRate method | 189 |
| 3.2.7.2 | IBMDSwitcherTransitionDVEParameters::SetRate method | 190 |
| 3.2.7.3 | IBMDSwitcherTransitionDVEParameters::GetLogoRate method | 191 |
| 3.2.7.4 | IBMDSwitcherTransitionDVEParameters::SetLogoRate method | 192 |
| 3.2.7.5 | IBMDSwitcherTransitionDVEParameters::GetReverse method | 193 |
| 3.2.7.6 | IBMDSwitcherTransitionDVEParameters::SetReverse method | 193 |

Table of Contents

| | | |
|----------|--|-----|
| 3.2.7.7 | IBMDSwitcherTransitionDVEParameters::GetFlipFlop method | 194 |
| 3.2.7.8 | IBMDSwitcherTransitionDVEParameters::SetFlipFlop method | 194 |
| 3.2.7.9 | IBMDSwitcherTransitionDVEParameters::GetStyle method | 195 |
| 3.2.7.10 | IBMDSwitcherTransitionDVEParameters::SetStyle method | 196 |
| 3.2.7.11 | IBMDSwitcherTransitionDVEParameters::GetInputFill method | 197 |
| 3.2.7.12 | IBMDSwitcherTransitionDVEParameters::SetInputFill method | 198 |
| 3.2.7.13 | IBMDSwitcherTransitionDVEParameters::GetInputCut method | 199 |
| 3.2.7.14 | IBMDSwitcherTransitionDVEParameters::SetInputCut method | 200 |
| 3.2.7.15 | IBMDSwitcherTransitionDVEParameters::GetFillInputAvailabilityMask method | 201 |
| 3.2.7.16 | IBMDSwitcherTransitionDVEParameters::GetCutInputAvailabilityMask method | 202 |
| 3.2.7.17 | IBMDSwitcherTransitionDVEParameters::GetEnableKey method | 203 |
| 3.2.7.18 | IBMDSwitcherTransitionDVEParameters::SetEnableKey method | 203 |
| 3.2.7.19 | IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method | 204 |
| 3.2.7.20 | IBMDSwitcherTransitionDVEParameters::SetPreMultiplied method | 204 |
| 3.2.7.21 | IBMDSwitcherTransitionDVEParameters::GetClip method | 205 |
| 3.2.7.22 | IBMDSwitcherTransitionDVEParameters::SetClip method | 205 |
| 3.2.7.23 | IBMDSwitcherTransitionDVEParameters::GetGain method | 206 |
| 3.2.7.24 | IBMDSwitcherTransitionDVEParameters::SetGain method | 206 |
| 3.2.7.25 | IBMDSwitcherTransitionDVEParameters::GetInverse method | 207 |
| 3.2.7.26 | IBMDSwitcherTransitionDVEParameters::SetInverse method | 207 |
| 3.2.7.27 | IBMDSwitcherTransitionDVEParameters::AddCallback method | 208 |
| 3.2.7.28 | IBMDSwitcherTransitionDVEParameters::RemoveCallback method | 209 |
| 3.2.8 | IBMDSwitcherTransitionDVEParametersCallback Interface | 210 |
| 3.2.8.1 | IBMDSwitcherTransitionDVEParametersCallback::Notify method | 211 |
| 3.2.9 | IBMDSwitcherTransitionStingerParameters Interface | 212 |
| 3.2.9.1 | IBMDSwitcherTransitionStingerParameters::GetSource method | 214 |
| 3.2.9.2 | IBMDSwitcherTransitionStingerParameters::SetSource method | 215 |
| 3.2.9.3 | IBMDSwitcherTransitionStingerParameters::GetPreMultiplied method | 216 |
| 3.2.9.4 | IBMDSwitcherTransitionStingerParameters::SetPreMultiplied method | 216 |
| 3.2.9.5 | IBMDSwitcherTransitionStingerParameters::GetClip method | 217 |
| 3.2.9.6 | IBMDSwitcherTransitionStingerParameters::SetClip method | 217 |
| 3.2.9.7 | IBMDSwitcherTransitionStingerParameters::GetGain method | 218 |
| 3.2.9.8 | IBMDSwitcherTransitionStingerParameters::SetGain method | 218 |
| 3.2.9.9 | IBMDSwitcherTransitionStingerParameters::GetInverse method | 219 |
| 3.2.9.10 | IBMDSwitcherTransitionStingerParameters::SetInverse method | 219 |
| 3.2.9.11 | IBMDSwitcherTransitionStingerParameters::GetPreroll method | 220 |

Table of Contents

| | | |
|----------|---|-----|
| 3.2.9.12 | IBMDSwitcherTransitionStingerParameters::SetPreroll method | 220 |
| 3.2.9.13 | IBMDSwitcherTransitionStingerParameters::GetClipDuration method | 221 |
| 3.2.9.14 | IBMDSwitcherTransitionStingerParameters::SetClipDuration method | 221 |
| 3.2.9.15 | IBMDSwitcherTransitionStingerParameters::GetTriggerPoint method | 222 |
| 3.2.9.16 | IBMDSwitcherTransitionStingerParameters::SetTriggerPoint method | 222 |
| 3.2.9.17 | IBMDSwitcherTransitionStingerParameters::GetMixRate method | 223 |
| 3.2.9.18 | IBMDSwitcherTransitionStingerParameters::SetMixRate method | 223 |
| 3.2.9.19 | IBMDSwitcherTransitionStingerParameters::AddCallback method | 224 |
| 3.2.9.20 | IBMDSwitcherTransitionStingerParameters::RemoveCallback method | 225 |
| 3.2.10 | IBMDSwitcherTransitionStingerParametersCallback Interface | 226 |
| 3.2.10.1 | IBMDSwitcherTransitionStingerParametersCallback::Notify method | 227 |
| 3.2.11 | IBMDSwitcherTransitionParameters Interface | 228 |
| 3.2.11.1 | IBMDSwitcherTransitionParameters::GetTransitionStyle method | 229 |
| 3.2.11.2 | IBMDSwitcherTransitionParameters::GetNextTransitionStyle method | 229 |
| 3.2.11.3 | IBMDSwitcherTransitionParameters::SetNextTransitionStyle method | 230 |
| 3.2.11.4 | IBMDSwitcherTransitionParameters::GetTransitionSelection method | 231 |
| 3.2.11.5 | IBMDSwitcherTransitionParameters::SetNextTransitionSelection method | 232 |
| 3.2.11.6 | IBMDSwitcherTransitionParameters::GetNextTransitionSelection method | 233 |
| 3.2.11.7 | IBMDSwitcherTransitionParameters::AddCallback method | 234 |
| 3.2.11.8 | IBMDSwitcherTransitionParameters::RemoveCallback method | 235 |
| 3.2.12 | IBMDSwitcherTransitionParametersCallback Interface | 236 |
| 3.2.12.1 | IBMDSwitcherTransitionParametersCallback::Notify method | 237 |

4 Switcher Media 238

| | | |
|---------|--|-----|
| 4.1 | General Information | 238 |
| 4.1.1 | Uploading a Still or Clip | 238 |
| 4.1.2 | Downloading a Still or Clip | 239 |
| 4.2 | Media Data Types | 240 |
| 4.2.1 | Switcher Pixel Format | 240 |
| 4.2.2 | Media Player Source Type | 240 |
| 4.2.3 | Media Pool Event Type | 240 |
| 4.3 | Interface Reference | 241 |
| 4.3.1 | IBMDSwitcherMediaPlayerCallback Interface | 241 |
| 4.3.1.1 | IBMDSwitcherMediaPlayerCallback::SourceChanged method | 242 |
| 4.3.1.2 | IBMDSwitcherMediaPlayerCallback::PlayingChanged method | 242 |

Table of Contents

| | | |
|----------|--|-----|
| 4.3.1.3 | IBMDSwitcherMediaPlayerCallback::LoopChanged method | 243 |
| 4.3.1.4 | IBMDSwitcherMediaPlayerCallback::AtBeginningChanged method | 243 |
| 4.3.1.5 | IBMDSwitcherMediaPlayerCallback::ClipFrameChanged method | 244 |
| 4.3.2 | IBMDSwitcherMediaPlayerIterator Interface | 245 |
| 4.3.2.1 | IBMDSwitcherMediaPlayerIterator::Next method | 246 |
| 4.3.3 | IBMDSwitcherMediaPlayer Interface | 247 |
| 4.3.3.1 | IBMDSwitcherMediaPlayer::GetSource method | 248 |
| 4.3.3.2 | IBMDSwitcherMediaPlayer::SetSource method | 249 |
| 4.3.3.3 | IBMDSwitcherMediaPlayer::GetPlaying method | 250 |
| 4.3.3.4 | IBMDSwitcherMediaPlayer::SetPlaying method | 250 |
| 4.3.3.5 | IBMDSwitcherMediaPlayer::GetLoop method | 251 |
| 4.3.3.6 | IBMDSwitcherMediaPlayer::SetLoop method | 251 |
| 4.3.3.7 | IBMDSwitcherMediaPlayer::GetAtBeginning method | 252 |
| 4.3.3.8 | IBMDSwitcherMediaPlayer::SetAtBeginning method | 253 |
| 4.3.3.9 | IBMDSwitcherMediaPlayer::GetClipFrame method | 253 |
| 4.3.3.10 | IBMDSwitcherMediaPlayer::SetClipFrame method | 254 |
| 4.3.3.11 | IBMDSwitcherMediaPlayer::AddCallback method | 255 |
| 4.3.3.12 | IBMDSwitcherMediaPlayer::RemoveCallback method | 256 |
| 4.3.4 | IBMDSwitcherFrame Interface | 257 |
| 4.3.4.1 | IBMDSwitcherFrame::GetWidth method | 258 |
| 4.3.4.2 | IBMDSwitcherFrame::GetHeight method | 258 |
| 4.3.4.3 | IBMDSwitcherFrame::GetRowBytes method | 259 |
| 4.3.4.4 | IBMDSwitcherFrame::GetPixelFormat method | 259 |
| 4.3.4.5 | IBMDSwitcherFrame::GetBytes method | 260 |
| 4.3.5 | IBMDSwitcherAudio Interface | 261 |
| 4.3.5.1 | IBMDSwitcherFrame::GetSize method | 262 |
| 4.3.5.2 | IBMDSwitcherAudio::GetBytes method | 262 |
| 4.3.6 | IBMDSwitcherLockCallback Interface | 263 |
| 4.3.6.1 | IBMDSwitcherLockCallback::Obtained method | 264 |
| 4.3.7 | IBMDSwitcherStillsCallback Interface | 265 |
| 4.3.7.1 | IBMDSwitcherStillsCallback::Notify method | 266 |
| 4.3.8 | IBMDSwitcherStills Interface | 267 |
| 4.3.8.1 | IBMDSwitcherStills::GetCount method | 268 |
| 4.3.8.2 | IBMDSwitcherStills::IsValid method | 268 |
| 4.3.8.3 | IBMDSwitcherStills::GetName method | 269 |
| 4.3.8.4 | IBMDSwitcherStills::SetName method | 270 |

Table of Contents

| | | |
|-----------|---|-----|
| 4.3.8.5 | IBMDSwitcherStills::GetHash method | 271 |
| 4.3.8.6 | IBMDSwitcherStills::SetInvalid method | 272 |
| 4.3.8.7 | IBMDSwitcherStills::Lock method | 273 |
| 4.3.8.8 | IBMDSwitcherStills::Unlock method | 274 |
| 4.3.8.9 | IBMDSwitcherStills::Upload method | 275 |
| 4.3.8.10 | IBMDSwitcherStills::Download method | 276 |
| 4.3.8.11 | IBMDSwitcherStills::CancelTransfer method | 277 |
| 4.3.8.12 | IBMDSwitcherStills::GetProgress method | 277 |
| 4.3.8.13 | IBMDSwitcherStills::AddCallback method | 278 |
| 4.3.8.14 | IBMDSwitcherStills::RemoveCallback method | 279 |
| 4.3.9 | IBMDSwitcherClipCallback Interface | 280 |
| 4.3.9.1 | IBMDSwitcherClipCallback::Notify method | 281 |
| 4.3.10 | IBMDSwitcherClip Interface | 283 |
| 4.3.10.1 | IBMDSwitcherClip::GetIndex method | 285 |
| 4.3.10.2 | IBMDSwitcherClip::IsValid method | 285 |
| 4.3.10.3 | IBMDSwitcherClip::GetName method | 286 |
| 4.3.10.4 | IBMDSwitcherClip::SetName method | 287 |
| 4.3.10.5 | IBMDSwitcherClip::SetValid method | 288 |
| 4.3.10.6 | IBMDSwitcherClip::SetInvalid method | 289 |
| 4.3.10.7 | IBMDSwitcherClip::GetFrameCount method | 290 |
| 4.3.10.8 | IBMDSwitcherClip::GetMaxFrameCount method | 291 |
| 4.3.10.9 | IBMDSwitcherClip::IsFrameValid method | 292 |
| 4.3.10.10 | IBMDSwitcherClip::GetFrameHash method | 293 |
| 4.3.10.11 | IBMDSwitcherClip::IsAudioValid method | 294 |
| 4.3.10.12 | IBMDSwitcherClip::GetAudioName method | 295 |
| 4.3.10.13 | IBMDSwitcherClip::SetAudioName method | 296 |
| 4.3.10.14 | IBMDSwitcherClip::GetAudioHash method | 297 |
| 4.3.10.15 | IBMDSwitcherClip::SetAudioInvalid method | 297 |
| 4.3.10.16 | IBMDSwitcherClip::Lock method | 298 |
| 4.3.10.17 | IBMDSwitcherClip::Unlock method | 299 |
| 4.3.10.18 | IBMDSwitcherClip::UploadFrame method | 300 |
| 4.3.10.19 | IBMDSwitcherClip::DownloadFrame method | 301 |
| 4.3.10.20 | IBMDSwitcherClip::UploadAudio method | 302 |
| 4.3.10.21 | IBMDSwitcherClip::DownloadAudio method | 303 |
| 4.3.10.22 | IBMDSwitcherClip::CancelTransfer method | 304 |
| 4.3.10.23 | IBMDSwitcherClip::GetProgress method | 304 |

Table of Contents

| | | |
|-----------|---|-----|
| 4.3.10.24 | IBMDSwitcherClip::AddCallback method | 305 |
| 4.3.10.25 | IBMDSwitcherClip::RemoveCallback method | 306 |
| 4.3.11 | IBMDSwitcherMediaPoolCallback Interface | 307 |
| 4.3.11.1 | IBMDSwitcherMediaPoolCallback::ClipFrameMaxCountsChanged method | 308 |
| 4.3.11.2 | IBMDSwitcherMediaPoolCallback::FrameTotalForClipsChanged method | 308 |
| 4.3.12 | IBMDSwitcherMediaPool Interface | 309 |
| 4.3.12.1 | IBMDSwitcherMediaPool::GetStills method | 310 |
| 4.3.12.2 | IBMDSwitcherMediaPool::GetClip method | 311 |
| 4.3.12.3 | IBMDSwitcherMediaPool::GetClipCount method | 312 |
| 4.3.12.4 | IBMDSwitcherMediaPool::CreateFrame method | 313 |
| 4.3.12.5 | IBMDSwitcherMediaPool::CreateAudio method | 314 |
| 4.3.12.6 | IBMDSwitcherMediaPool::GetFrameTotalForClips method | 315 |
| 4.3.12.7 | IBMDSwitcherMediaPool::GetClipMaxFrameCounts method | 316 |
| 4.3.12.8 | IBMDSwitcherMediaPool::Clear method | 317 |
| 4.3.12.9 | IBMDSwitcherMediaPool::SetClipMaxFrameCounts method | 318 |
| 4.3.12.10 | IBMDSwitcherMediaPool::AddCallback method | 319 |
| 4.3.12.11 | IBMDSwitcherMediaPool::RemoveCallback method | 320 |

5 Keys

321

| | | |
|---------|---|-----|
| 5.1 | Key Data Types | 321 |
| 5.1.1 | Key Type | 321 |
| 5.1.2 | Fly Key Frames | 321 |
| 5.1.3 | Border Bevel Options | 322 |
| 5.1.4 | Key Event Type | 322 |
| 5.1.5 | Luminance Key Parameters Event Type | 323 |
| 5.1.6 | Chroma Key Parameters Event Type | 323 |
| 5.1.7 | Pattern Key Parameters Event Type | 323 |
| 5.1.8 | DVE Key Parameters Event Type | 324 |
| 5.1.9 | Fly Key Parameters Event Type | 325 |
| 5.1.10 | Downstream Key Event Type | 326 |
| 5.2 | Interface Reference | 327 |
| 5.2.1 | IBMDSwitcherKeyIterator Interface | 327 |
| 5.2.1.1 | IBMDSwitcherMediaPool::AddCallback method | 328 |
| 5.2.2 | IBMDSwitcherKey Interface | 329 |
| 5.2.2.1 | IBMDSwitcherKey::GetType method | 331 |

Table of Contents

| | | |
|----------|--|-----|
| 5.2.2.2 | IBMDSwitcherKey::SetType method | 332 |
| 5.2.2.3 | IBMDSwitcherKey::GetInputCut method | 333 |
| 5.2.2.4 | IBMDSwitcherKey::SetInputCut method | 334 |
| 5.2.2.5 | IBMDSwitcherKey::GetInputFill method | 335 |
| 5.2.2.6 | IBMDSwitcherKey::SetInputFill method | 336 |
| 5.2.2.7 | IBMDSwitcherKey::GetFillInputAvailabilityMask method | 337 |
| 5.2.2.8 | IBMDSwitcherKey::GetCutInputAvailabilityMask method | 338 |
| 5.2.2.9 | IBMDSwitcherKey::GetOnAir method | 339 |
| 5.2.2.10 | IBMDSwitcherKey::SetOnAir method | 339 |
| 5.2.2.11 | IBMDSwitcherKey::CanBeDVEKey method | 340 |
| 5.2.2.12 | IBMDSwitcherKey::GetMasked method | 341 |
| 5.2.2.13 | IBMDSwitcherKey::SetMasked method | 341 |
| 5.2.2.14 | IBMDSwitcherKey::GetMaskTop method | 342 |
| 5.2.2.15 | IBMDSwitcherKey::SetMaskTop method | 342 |
| 5.2.2.16 | IBMDSwitcherKey::GetMaskBottom method | 343 |
| 5.2.2.17 | IBMDSwitcherKey::SetMaskBottom method | 343 |
| 5.2.2.18 | IBMDSwitcherKey::GetMaskLeft method | 344 |
| 5.2.2.19 | IBMDSwitcherKey::SetMaskLeft method | 344 |
| 5.2.2.20 | IBMDSwitcherKey::GetMaskRight method | 345 |
| 5.2.2.21 | IBMDSwitcherKey::SetMaskRight method | 345 |
| 5.2.2.22 | IBMDSwitcherKey::ResetMask method | 346 |
| 5.2.2.23 | IBMDSwitcherKey::GetTransitionSelectionMask method | 346 |
| 5.2.2.24 | IBMDSwitcherKey::AddCallback method | 347 |
| 5.2.2.25 | IBMDSwitcherKey::RemoveCallback method | 348 |
| 5.2.3 | IBMDSwitcherKeyCallback Interface | 349 |
| 5.2.3.1 | IBMDSwitcherKeyCallback::Notify method | 350 |
| 5.2.4 | IBMDSwitcherKeyLumaParameters Interface | 351 |
| 5.2.4.1 | IBMDSwitcherKeyLumaParameters::GetPreMultiplied method | 352 |
| 5.2.4.2 | IBMDSwitcherKeyLumaParameters::SetPreMultiplied method | 353 |
| 5.2.4.3 | IBMDSwitcherKeyLumaParameters::GetClip method | 354 |
| 5.2.4.4 | IBMDSwitcherKeyLumaParameters::SetClip method | 354 |
| 5.2.4.5 | IBMDSwitcherKeyLumaParameters::GetGain method | 355 |
| 5.2.4.6 | IBMDSwitcherKeyLumaParameters::SetGain method | 355 |
| 5.2.4.7 | IBMDSwitcherKeyLumaParameters::GetInverse method | 356 |
| 5.2.4.8 | IBMDSwitcherKeyLumaParameters::SetInverse method | 356 |
| 5.2.4.9 | IBMDSwitcherKeyLumaParameters::AddCallback method | 357 |

Table of Contents

| | | |
|----------|--|-----|
| 5.2.4.10 | IBMDSwitcherKeyLumaParameters::RemoveCallback method | 358 |
| 5.2.5 | IBMDSwitcherKeyLumaParametersCallback Interface | 359 |
| 5.2.5.1 | IBMDSwitcherKeyLumaParametersCallback::Notify method | 360 |
| 5.2.6 | IBMDSwitcherKeyChromaParameters Interface | 361 |
| 5.2.6.1 | IBMDSwitcherKeyChromaParameters::GetHue method | 362 |
| 5.2.6.2 | IBMDSwitcherKeyChromaParameters::SetHue method | 362 |
| 5.2.6.3 | IBMDSwitcherKeyChromaParameters::GetGain method | 363 |
| 5.2.6.4 | IBMDSwitcherKeyChromaParameters::SetGain method | 363 |
| 5.2.6.5 | IBMDSwitcherKeyChromaParameters::GetYSuppress method | 364 |
| 5.2.6.6 | IBMDSwitcherKeyChromaParameters::SetYSuppress method | 364 |
| 5.2.6.7 | IBMDSwitcherKeyChromaParameters::GetLift method | 365 |
| 5.2.6.8 | IBMDSwitcherKeyChromaParameters::SetLift method | 365 |
| 5.2.6.9 | IBMDSwitcherKeyChromaParameters::GetNarrow method | 366 |
| 5.2.6.10 | IBMDSwitcherKeyChromaParameters::SetNarrow method | 366 |
| 5.2.6.11 | IBMDSwitcherKeyChromaParameters::AddCallback method | 367 |
| 5.2.6.12 | IBMDSwitcherKeyChromaParameters::RemoveCallback method | 368 |
| 5.2.7 | IBMDSwitcherKeyChromaParametersCallback Interface | 369 |
| 5.2.7.1 | IBMDSwitcherKeyChromaParametersCallback::Notify method | 370 |
| 5.2.8 | IBMDSwitcherKeyPatternParameters Interface | 371 |
| 5.2.8.1 | IBMDSwitcherKeyPatternParameters::GetPattern method | 373 |
| 5.2.8.2 | IBMDSwitcherKeyPatternParameters::SetPattern method | 374 |
| 5.2.8.3 | IBMDSwitcherKeyPatternParameters::GetSize method | 375 |
| 5.2.8.4 | IBMDSwitcherKeyPatternParameters::SetSize method | 375 |
| 5.2.8.5 | IBMDSwitcherKeyPatternParameters::GetSymmetry method | 376 |
| 5.2.8.6 | IBMDSwitcherKeyPatternParameters::SetSymmetry method | 376 |
| 5.2.8.7 | IBMDSwitcherKeyPatternParameters::GetSoftness method | 377 |
| 5.2.8.8 | IBMDSwitcherKeyPatternParameters::SetSoftness method | 377 |
| 5.2.8.9 | IBMDSwitcherKeyPatternParameters::GetHorizontalOffset method | 378 |
| 5.2.8.10 | IBMDSwitcherKeyPatternParameters::SetHorizontalOffset method | 378 |
| 5.2.8.11 | IBMDSwitcherKeyPatternParameters::GetVerticalOffset method | 379 |
| 5.2.8.12 | IBMDSwitcherKeyPatternParameters::SetVerticalOffset method | 379 |
| 5.2.8.13 | IBMDSwitcherKeyPatternParameters::GetInverse method | 380 |
| 5.2.8.14 | IBMDSwitcherKeyPatternParameters::SetInverse method | 380 |
| 5.2.8.15 | IBMDSwitcherKeyPatternParameters::AddCallback method | 381 |
| 5.2.8.16 | IBMDSwitcherKeyPatternParameters::RemoveCallback method | 382 |
| 5.2.9 | IBMDSwitcherKeyPatternParametersCallback Interface | 383 |

Table of Contents

| | | |
|-----------|--|-----|
| 5.2.9.1 | IBMDSwitcherKeyPatternParametersCallback::Notify method | 384 |
| 5.2.10 | IBMDSwitcherKeyDVEParameters Interface | 385 |
| 5.2.10.1 | IBMDSwitcherKeyDVEParameters::GetShadow method | 388 |
| 5.2.10.2 | IBMDSwitcherKeyDVEParameters::SetShadow method | 388 |
| 5.2.10.3 | IBMDSwitcherKeyDVEParameters::GetLightSourceDirection method | 389 |
| 5.2.10.4 | IBMDSwitcherKeyDVEParameters::SetLightSourceDirection method | 389 |
| 5.2.10.5 | IBMDSwitcherKeyDVEParameters::GetLightSourceAltitude method | 390 |
| 5.2.10.6 | IBMDSwitcherKeyDVEParameters::SetLightSourceAltitude method | 390 |
| 5.2.10.7 | IBMDSwitcherKeyDVEParameters::GetBorderEnabled method | 391 |
| 5.2.10.8 | IBMDSwitcherKeyDVEParameters::SetBorderEnabled method | 391 |
| 5.2.10.9 | IBMDSwitcherKeyDVEParameters::GetBorderBevel method | 392 |
| 5.2.10.10 | IBMDSwitcherKeyDVEParameters::SetBorderBevel method | 393 |
| 5.2.10.11 | IBMDSwitcherKeyDVEParameters::GetBorderWidthIn method | 394 |
| 5.2.10.12 | IBMDSwitcherKeyDVEParameters::SetBorderWidthIn method | 394 |
| 5.2.10.13 | IBMDSwitcherKeyDVEParameters::GetBorderWidthOut method | 395 |
| 5.2.10.14 | IBMDSwitcherKeyDVEParameters::SetBorderWidthOut method | 395 |
| 5.2.10.15 | IBMDSwitcherKeyDVEParameters::GetBorderSoftnessIn method | 396 |
| 5.2.10.16 | IBMDSwitcherKeyDVEParameters::SetBorderSoftnessIn method | 396 |
| 5.2.10.17 | IBMDSwitcherKeyDVEParameters::GetBorderSoftnessOut method | 397 |
| 5.2.10.18 | IBMDSwitcherKeyDVEParameters::SetBorderSoftnessOut method | 397 |
| 5.2.10.19 | IBMDSwitcherKeyDVEParameters::GetBorderBevelSoftness method | 398 |
| 5.2.10.20 | IBMDSwitcherKeyDVEParameters::SetBorderBevelSoftness method | 398 |
| 5.2.10.21 | IBMDSwitcherKeyDVEParameters::GetBorderBevelPosition method | 399 |
| 5.2.10.22 | IBMDSwitcherKeyDVEParameters::SetBorderBevelPosition method | 399 |
| 5.2.10.23 | IBMDSwitcherKeyDVEParameters::GetBorderOpacity method | 400 |
| 5.2.10.24 | IBMDSwitcherKeyDVEParameters::SetBorderOpacity method | 400 |
| 5.2.10.25 | IBMDSwitcherKeyDVEParameters::GetBorderHue method | 401 |
| 5.2.10.26 | IBMDSwitcherKeyDVEParameters::SetBorderHue method | 401 |
| 5.2.10.27 | IBMDSwitcherKeyDVEParameters::GetBorderSaturation method | 402 |
| 5.2.10.28 | IBMDSwitcherKeyDVEParameters::SetBorderSaturation method | 402 |
| 5.2.10.29 | IBMDSwitcherKeyDVEParameters::GetBorderLuma method | 403 |
| 5.2.10.30 | IBMDSwitcherKeyDVEParameters::SetBorderLuma method | 403 |
| 5.2.10.31 | IBMDSwitcherKeyDVEParameters::GetMasked method | 404 |
| 5.2.10.32 | IBMDSwitcherKeyDVEParameters::SetMasked method | 404 |
| 5.2.10.33 | IBMDSwitcherKeyDVEParameters::GetMaskTop method | 405 |
| 5.2.10.34 | IBMDSwitcherKeyDVEParameters::SetMaskTop method | 405 |

Table of Contents

| | | |
|-----------|--|-----|
| 5.2.10.35 | IBMDSwitcherKeyDVEParameters::GetMaskBottom method | 406 |
| 5.2.10.36 | IBMDSwitcherKeyDVEParameters::SetMaskBottom method | 406 |
| 5.2.10.37 | IBMDSwitcherKeyDVEParameters::GetMaskLeft method | 407 |
| 5.2.10.38 | BMDSwitcherKeyDVEParameters::SetMaskLeft method | 407 |
| 5.2.10.39 | BMDSwitcherKeyDVEParameters::GetMaskRight method | 408 |
| 5.2.10.40 | BMDSwitcherKeyDVEParameters::SetMaskRight method | 408 |
| 5.2.10.41 | IBMDSwitcherKeyDVEParameters::ResetMask method | 409 |
| 5.2.10.42 | IBMDSwitcherKeyDVEParameters::AddCallback method | 410 |
| 5.2.10.43 | IBMDSwitcherKeyDVEParameters::RemoveCallback method | 411 |
| 5.2.11 | IBMDSwitcherKeyDVEParametersCallback Interface | 412 |
| 5.2.11.1 | IBMDSwitcherKeyDVEParametersCallback::Notify method | 413 |
| 5.2.12 | IBMDSwitcherKeyFlyParameters Interface | 414 |
| 5.2.12.1 | IBMDSwitcherKeyFlyParameters::GetFly method | 416 |
| 5.2.12.2 | IBMDSwitcherKeyFlyParameters::SetFly method | 416 |
| 5.2.12.3 | IBMDSwitcherKeyFlyParameters::GetCanFly method | 417 |
| 5.2.12.4 | IBMDSwitcherKeyFlyParameters::GetRate method | 418 |
| 5.2.12.5 | IBMDSwitcherKeyFlyParameters::SetRate method | 419 |
| 5.2.12.6 | IBMDSwitcherKeyFlyParameters::GetSizeX method | 420 |
| 5.2.12.7 | IBMDSwitcherKeyFlyParameters::SetSizeX method | 421 |
| 5.2.12.8 | IBMDSwitcherKeyFlyParameters::GetSizeY method | 422 |
| 5.2.12.9 | IBMDSwitcherKeyFlyParameters::SetSizeY method | 423 |
| 5.2.12.10 | IBMDSwitcherKeyFlyParameters::GetPositionX method | 424 |
| 5.2.12.11 | IBMDSwitcherKeyFlyParameters::SetPositionX method | 425 |
| 5.2.12.12 | IBMDSwitcherKeyFlyParameters::GetPositionY method | 426 |
| 5.2.12.13 | IBMDSwitcherKeyFlyParameters::SetPositionY method | 427 |
| 5.2.12.14 | IBMDSwitcherKeyFlyParameters::GetRotation method | 427 |
| 5.2.12.15 | IBMDSwitcherKeyFlyParameters::SetRotation method | 428 |
| 5.2.12.16 | IBMDSwitcherKeyFlyParameters::ResetRotation method | 428 |
| 5.2.12.17 | IBMDSwitcherKeyFlyParameters::ResetDVE method | 429 |
| 5.2.12.18 | IBMDSwitcherKeyFlyParameters::ResetDVEFull method | 429 |
| 5.2.12.19 | IBMDSwitcherKeyFlyParameters::IsKeyFrameStored method | 430 |
| 5.2.12.20 | IBMDSwitcherKeyFlyParameters::StoreAsKeyFrame method | 431 |
| 5.2.12.21 | IBMDSwitcherKeyFlyParameters::RunToKeyFrame method | 432 |
| 5.2.12.22 | IBMDSwitcherKeyFlyParameters::IsAtKeyFrames method | 433 |
| 5.2.12.23 | IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters method | 434 |
| 5.2.12.24 | IBMDSwitcherKeyFlyParameters::IsRunning method | 435 |

Table of Contents

| | | |
|-----------|--|-----|
| 5.2.12.25 | IBMDSwitcherKeyFlyParameters::AddCallback method | 436 |
| 5.2.12.26 | IBMDSwitcherKeyFlyParameters::RemoveCallback method | 437 |
| 5.2.13 | IBMDSwitcherKeyFlyParametersCallback Interface | 438 |
| 5.2.13.1 | IBMDSwitcherKeyFlyParametersCallback::Notify method | 439 |
| 5.2.14 | IBMDSwitcherKeyFlyKeyFrameParameters Interface | 440 |
| 5.2.14.1 | IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeX method | 443 |
| 5.2.14.2 | IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeX method | 443 |
| 5.2.14.3 | IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeY method | 444 |
| 5.2.14.4 | IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeY method | 444 |
| 5.2.14.5 | IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionX method | 445 |
| 5.2.14.6 | IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionX method | 445 |
| 5.2.14.7 | IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionY method | 446 |
| 5.2.14.8 | IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionY method | 446 |
| 5.2.14.9 | IBMDSwitcherKeyFlyKeyFrameParameters::GetRotation method | 447 |
| 5.2.14.10 | IBMDSwitcherKeyFlyKeyFrameParameters::SetRotation method | 447 |
| 5.2.14.11 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthOut method | 448 |
| 5.2.14.12 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthOut method | 448 |
| 5.2.14.13 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthIn method | 449 |
| 5.2.14.14 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthIn method | 449 |
| 5.2.14.15 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessOut method | 450 |
| 5.2.14.16 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessOut method | 450 |
| 5.2.14.17 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessIn method | 451 |
| 5.2.14.18 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessIn method | 451 |
| 5.2.14.19 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelSoftness method | 452 |
| 5.2.14.20 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelSoftness method | 452 |
| 5.2.14.21 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelPosition method | 453 |
| 5.2.14.22 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelPosition method | 453 |
| 5.2.14.23 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderOpacity method | 454 |
| 5.2.14.24 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderOpacity method | 454 |
| 5.2.14.25 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderHue method | 455 |
| 5.2.14.26 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderHue method | 455 |
| 5.2.14.27 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSaturation method | 456 |
| 5.2.14.28 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSaturation method | 456 |
| 5.2.14.29 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLuma method | 457 |
| 5.2.14.30 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLuma method | 457 |
| 5.2.14.31 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceDirection method | 458 |

Table of Contents

| | | |
|-----------|--|-----|
| 5.2.14.32 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceDirection method | 459 |
| 5.2.14.33 | IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceAltitude method | 460 |
| 5.2.14.34 | IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceAltitude method | 460 |
| 5.2.14.35 | IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskTop method | 461 |
| 5.2.14.36 | IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskTop method | 461 |
| 5.2.14.37 | IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskBottom method | 462 |
| 5.2.14.38 | IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskBottom method | 462 |
| 5.2.14.39 | IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskLeft method | 463 |
| 5.2.14.40 | IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskLeft method | 463 |
| 5.2.14.41 | IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskRight method | 464 |
| 5.2.14.42 | IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskRight method | 464 |
| 5.2.14.43 | IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback method | 465 |
| 5.2.14.44 | IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback method | 466 |
| 5.2.15 | IBMDSwitcherKeyFlyKeyFrameParametersCallback Interface | 467 |
| 5.2.15.1 | IBMDSwitcherKeyFlyKeyFrameParametersCallback::Notify method | 468 |
| 5.2.16 | IBMDSwitcherDownstreamKeyIterator Interface | 469 |
| 5.2.16.1 | IBMDSwitcherDownstreamKeyIterator::Next method | 470 |
| 5.2.17 | IBMDSwitcherDownstreamKey Interface | 471 |
| 5.2.17.1 | IBMDSwitcherDownstreamKey::GetInputCut method | 473 |
| 5.2.17.2 | IBMDSwitcherDownstreamKey::SetInputCut method | 474 |
| 5.2.17.3 | IBMDSwitcherDownstreamKey::GetInputFill method | 475 |
| 5.2.17.4 | IBMDSwitcherDownstreamKey::SetInputFill method | 476 |
| 5.2.17.5 | IBMDSwitcherDownstreamKey::GetFillInputAvailabilityMask method | 477 |
| 5.2.17.6 | IBMDSwitcherDownstreamKey::GetCutInputAvailabilityMask method | 478 |
| 5.2.17.7 | IBMDSwitcherDownstreamKey::GetTie method | 479 |
| 5.2.17.8 | IBMDSwitcherDownstreamKey::SetTie method | 479 |
| 5.2.17.9 | IBMDSwitcherDownstreamKey::GetRate method | 480 |
| 5.2.17.10 | IBMDSwitcherDownstreamKey::SetRate method | 481 |
| 5.2.17.11 | IBMDSwitcherDownstreamKey::GetOnAir method | 482 |
| 5.2.17.12 | IBMDSwitcherDownstreamKey::SetOnAir method | 482 |
| 5.2.17.13 | IBMDSwitcherDownstreamKey::PerformAutoTransition method | 483 |
| 5.2.17.14 | IBMDSwitcherDownstreamKey::IsTransitioning method | 483 |
| 5.2.17.15 | IBMDSwitcherDownstreamKey::IsAutoTransitioning method | 484 |
| 5.2.17.16 | IBMDSwitcherDownstreamKey::GetFramesRemaining method | 484 |
| 5.2.17.17 | IBMDSwitcherDownstreamKey::GetPreMultiplied method | 485 |
| 5.2.17.18 | IBMDSwitcherDownstreamKey::SetPreMultiplied method | 486 |

Table of Contents

| | | |
|-----------|--|-----|
| 5.2.17.19 | IBMDSwitcherDownstreamKey::GetClip method | 487 |
| 5.2.17.20 | IBMDSwitcherDownstreamKey::SetClip method | 487 |
| 5.2.17.21 | IBMDSwitcherDownstreamKey::GetGain method | 488 |
| 5.2.17.22 | IBMDSwitcherDownstreamKey::SetGain method | 488 |
| 5.2.17.23 | IBMDSwitcherDownstreamKey::GetInverse method | 489 |
| 5.2.17.24 | IBMDSwitcherDownstreamKey::SetInverse method | 489 |
| 5.2.17.25 | IBMDSwitcherDownstreamKey::GetMasked method | 490 |
| 5.2.17.26 | IBMDSwitcherDownstreamKey::SetMasked method | 490 |
| 5.2.17.27 | IBMDSwitcherDownstreamKey::GetMaskTop method | 491 |
| 5.2.17.28 | IBMDSwitcherDownstreamKey::SetMaskTop method | 491 |
| 5.2.17.29 | IBMDSwitcherDownstreamKey::GetMaskBottom method | 492 |
| 5.2.17.30 | IBMDSwitcherDownstreamKey::SetMaskBottom method | 492 |
| 5.2.17.31 | IBMDSwitcherDownstreamKey::GetMaskLeft method | 493 |
| 5.2.17.32 | IBMDSwitcherDownstreamKey::SetMaskLeft method | 493 |
| 5.2.17.33 | IBMDSwitcherDownstreamKey::GetMaskRight method | 494 |
| 5.2.17.34 | IBMDSwitcherDownstreamKey::SetMaskRight method | 494 |
| 5.2.17.35 | IBMDSwitcherDownstreamKey::ResetMask method | 495 |
| 5.2.17.36 | IBMDSwitcherDownstreamKey::AddCallback method | 496 |
| 5.2.17.37 | IBMDSwitcherDownstreamKey::RemoveCallback method | 497 |
| 5.2.18 | IBMDSwitcherDownstreamKeyCallback Interface | 498 |
| 5.2.18.1 | IBMDSwitcherDownstreamKeyCallback::Notify | 499 |

6 SuperSource

500

| | | |
|---------|---|-----|
| 6.1 | SuperSource Data Types | 500 |
| 6.1.1 | SuperSource Box Event Type | 500 |
| 6.1.2 | SuperSource Input Event Type | 501 |
| 6.1.3 | SuperSource Art Option | 502 |
| 6.2 | Interface Reference | 503 |
| 6.2.1 | IBMDSwitcherInputSuperSource Interface | 503 |
| 6.2.1.1 | IBMDSwitcherInputSuperSource::GetInputCut method | 506 |
| 6.2.1.2 | IBMDSwitcherInputSuperSource::SetInputCut method | 507 |
| 6.2.1.3 | IBMDSwitcherInputSuperSource::GetInputFill method | 508 |
| 6.2.1.4 | IBMDSwitcherInputSuperSource::SetInputFill method | 509 |
| 6.2.1.5 | IBMDSwitcherInputSuperSource::GetFillInputAvailabilityMask method | 510 |
| 6.2.1.6 | IBMDSwitcherInputSuperSource::GetCutInputAvailabilityMask method | 511 |

Table of Contents

| | | |
|----------|--|-----|
| 6.2.1.7 | IBMDSwitcherInputSuperSource::GetArtOption method | 512 |
| 6.2.1.8 | IBMDSwitcherInputSuperSource::SetArtOption method | 513 |
| 6.2.1.9 | IBMDSwitcherInputSuperSource::GetPreMultiplied method | 514 |
| 6.2.1.10 | IBMDSwitcherInputSuperSource::SetPreMultiplied method | 515 |
| 6.2.1.11 | IBMDSwitcherInputSuperSource::GetClip method | 516 |
| 6.2.1.12 | IBMDSwitcherInputSuperSource::SetClip method | 516 |
| 6.2.1.13 | IBMDSwitcherInputSuperSource::GetGain method | 517 |
| 6.2.1.14 | IBMDSwitcherInputSuperSource::SetGain method | 517 |
| 6.2.1.15 | IBMDSwitcherInputSuperSource::GetInverse method | 518 |
| 6.2.1.16 | IBMDSwitcherInputSuperSource::SetInverse method | 518 |
| 6.2.1.17 | IBMDSwitcherInputSuperSource::GetBorderEnabled method | 519 |
| 6.2.1.18 | IBMDSwitcherInputSuperSource::SetBorderEnabled method | 519 |
| 6.2.1.19 | IBMDSwitcherInputSuperSource::GetBorderBevel method | 520 |
| 6.2.1.20 | IBMDSwitcherInputSuperSource::SetBorderBevel method | 521 |
| 6.2.1.21 | IBMDSwitcherInputSuperSource::GetBorderWidthOut method | 522 |
| 6.2.1.22 | IBMDSwitcherInputSuperSource::SetBorderWidthOut method | 522 |
| 6.2.1.23 | IBMDSwitcherInputSuperSource::GetBorderWidthIn method | 523 |
| 6.2.1.24 | IBMDSwitcherInputSuperSource::SetBorderWidthIn method | 523 |
| 6.2.1.25 | IBMDSwitcherInputSuperSource::GetBorderSoftnessOut method | 524 |
| 6.2.1.26 | IBMDSwitcherInputSuperSource::SetBorderSoftnessOut method | 524 |
| 6.2.1.27 | IBMDSwitcherInputSuperSource::GetBorderSoftnessIn method | 525 |
| 6.2.1.28 | IBMDSwitcherInputSuperSource::SetBorderSoftnessIn method | 525 |
| 6.2.1.29 | IBMDSwitcherInputSuperSource::GetBorderBevelSoftness method | 526 |
| 6.2.1.30 | IBMDSwitcherInputSuperSource::SetBorderBevelSoftness method | 526 |
| 6.2.1.31 | IBMDSwitcherInputSuperSource::GetBorderBevelPosition method | 527 |
| 6.2.1.32 | IBMDSwitcherInputSuperSource::SetBorderBevelPosition method | 527 |
| 6.2.1.33 | IBMDSwitcherInputSuperSource::GetBorderHue method | 528 |
| 6.2.1.34 | IBMDSwitcherInputSuperSource::SetBorderHue method | 528 |
| 6.2.1.35 | IBMDSwitcherInputSuperSource::GetBorderSaturation method | 529 |
| 6.2.1.36 | IBMDSwitcherInputSuperSource::SetBorderSaturation method | 529 |
| 6.2.1.37 | IBMDSwitcherInputSuperSource::GetBorderLuma method | 530 |
| 6.2.1.38 | IBMDSwitcherInputSuperSource::SetBorderLuma method | 530 |
| 6.2.1.39 | IBMDSwitcherInputSuperSource::GetBorderLightSourceDirection method | 531 |
| 6.2.1.40 | IBMDSwitcherInputSuperSource::SetBorderLightSourceDirection method | 531 |
| 6.2.1.41 | IBMDSwitcherInputSuperSource::GetBorderLightSourceAltitude method | 532 |
| 6.2.1.42 | IBMDSwitcherInputSuperSource::SetBorderLightSourceAltitude method | 532 |

Table of Contents

| | | |
|----------|---|-----|
| 6.2.1.43 | IBMDSwitcherInputSuperSource::AddCallback method | 533 |
| 6.2.1.44 | IBMDSwitcherInputSuperSource::RemoveCallback method | 534 |
| 6.2.2 | IBMDSwitcherInputSuperSourceCallback Interface | 535 |
| 6.2.2.1 | IBMDSwitcherInputSuperSourceCallback::Notify method | 536 |
| 6.2.3 | IBMDSwitcherSuperSourceBoxIterator Interface | 537 |
| 6.2.3.1 | IBMDSwitcherSuperSourceBoxIterator::Next method | 538 |
| 6.2.4 | IBMDSwitcherSuperSourceBox Interface | 539 |
| 6.2.4.1 | IBMDSwitcherSuperSourceBox::GetEnabled method | 541 |
| 6.2.4.2 | IBMDSwitcherSuperSourceBox::SetEnabled method | 542 |
| 6.2.4.3 | IBMDSwitcherSuperSourceBox::GetInputSource method | 543 |
| 6.2.4.4 | IBMDSwitcherSuperSourceBox::SetInputSource method | 544 |
| 6.2.4.5 | IBMDSwitcherSuperSourceBox::GetPositionX method | 545 |
| 6.2.4.6 | IBMDSwitcherSuperSourceBox::SetPositionX method | 545 |
| 6.2.4.7 | IBMDSwitcherSuperSourceBox::GetPositionY method | 546 |
| 6.2.4.8 | IBMDSwitcherSuperSourceBox::SetPositionY method | 546 |
| 6.2.4.9 | IBMDSwitcherSuperSourceBox::GetSize method | 547 |
| 6.2.4.10 | IBMDSwitcherSuperSourceBox::SetSize method | 547 |
| 6.2.4.11 | IBMDSwitcherSuperSourceBox::GetCropped method | 548 |
| 6.2.4.12 | IBMDSwitcherSuperSourceBox::SetCropped method | 548 |
| 6.2.4.13 | IBMDSwitcherSuperSourceBox::GetCropTop method | 549 |
| 6.2.4.14 | IBMDSwitcherSuperSourceBox::SetCropTop method | 549 |
| 6.2.4.15 | IBMDSwitcherSuperSourceBox::GetCropBottom method | 550 |
| 6.2.4.16 | IBMDSwitcherSuperSourceBox::SetCropBottom method | 550 |
| 6.2.4.17 | IBMDSwitcherSuperSourceBox::GetCropLeft method | 551 |
| 6.2.4.18 | IBMDSwitcherSuperSourceBox::SetCropLeft method | 551 |
| 6.2.4.19 | IBMDSwitcherSuperSourceBox::GetCropRight method | 552 |
| 6.2.4.20 | IBMDSwitcherSuperSourceBox::SetCropRight method | 552 |
| 6.2.4.21 | IBMDSwitcherSuperSourceBox::ResetCrop method | 553 |
| 6.2.4.22 | IBMDSwitcherSuperSourceBox::GetInputAvailabilityMask method | 554 |
| 6.2.4.23 | IBMDSwitcherSuperSourceBox::AddCallback method | 555 |
| 6.2.4.24 | IBMDSwitcherSuperSourceBox::RemoveCallback method | 556 |
| 6.2.5 | IBMDSwitcherSuperSourceBoxCallback Interface | 557 |
| 6.2.5.1 | IBMDSwitcherSuperSourceBoxCallback::Notify method | 558 |

7 Audio Mixing 559

| | | |
|-----|-------------------------|-----|
| 7.1 | Audio Mixing Data Types | 559 |
|-----|-------------------------|-----|

Table of Contents

| | | |
|----------|--|-----|
| 7.1.1 | Audio Mixer Event Type | 559 |
| 7.1.2 | Audio Input Identifier | 559 |
| 7.1.3 | Audio Input Type | 559 |
| 7.1.4 | Audio Mix Option | 559 |
| 7.1.5 | Audio Input Event Type | 560 |
| 7.1.6 | Audio Monitor Output Event Type | 560 |
| 7.1.7 | Switcher Talkback Event Types | 560 |
| 7.2 | Interface Reference | 561 |
| 7.2.1 | IBMDSwitcherAudioMixer Interface | 561 |
| 7.2.1.1 | IBMDSwitcherAudioMixer::GetProgramOutGain method | 562 |
| 7.2.1.2 | IBMDSwitcherAudioMixer::SetProgramOutGain method | 562 |
| 7.2.1.3 | IBMDSwitcherAudioMixer::GetProgramOutBalance method | 563 |
| 7.2.1.4 | IBMDSwitcherAudioMixer::GetProgramOutFollowFadeToBlack method | 564 |
| 7.2.1.5 | IBMDSwitcherAudioMixer::SetProgramOutFollowFadeToBlack method | 565 |
| 7.2.1.6 | IBMDSwitcherAudioMixer::SetProgramOutBalance method | 566 |
| 7.2.1.7 | IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable method | 567 |
| 7.2.1.8 | IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks method | 568 |
| 7.2.1.9 | IBMDSwitcherAudioMixer::ResetAllLevelNotificationPeaks method | 568 |
| 7.2.1.10 | IBMDSwitcherAudioMixer::AddCallback method | 569 |
| 7.2.1.11 | IBMDSwitcherAudioMixer::RemoveCallback method | 570 |
| 7.2.1.12 | IBMDSwitcherAudioMixer::CreateIterator method | 571 |
| 7.2.2 | IBMDSwitcherAudioMixerCallback Interface | 572 |
| 7.2.2.1 | IBMDSwitcherAudioMixerCallback::Notify method | 573 |
| 7.2.2.2 | IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification method | 574 |
| 7.2.3 | IBMDSwitcherAudioInputIterator Interface | 575 |
| 7.2.3.1 | IBMDSwitcherAudioInputIterator::Next method | 576 |
| 7.2.3.2 | IBMDSwitcherAudioInputIterator::GetById method | 577 |
| 7.2.4 | IBMDSwitcherAudioInput Interface | 578 |
| 7.2.4.1 | IBMDSwitcherAudioInput::GetType method | 579 |
| 7.2.4.2 | IBMDSwitcherAudioInput::GetCurrentExternalPortType method | 580 |
| 7.2.4.3 | IBMDSwitcherAudioInput::GetMixOption method | 581 |
| 7.2.4.4 | IBMDSwitcherAudioInput::SetMixOption method | 582 |
| 7.2.4.5 | IBMDSwitcherAudioInput::GetGain method | 583 |
| 7.2.4.6 | IBMDSwitcherAudioInput::SetGain method | 583 |
| 7.2.4.7 | IBMDSwitcherAudioInput::GetBalance method | 584 |
| 7.2.4.8 | IBMDSwitcherAudioInput::SetBalance method | 585 |

Table of Contents

| | | |
|----------|--|-----|
| 7.2.4.9 | IBMDSwitcherAudioInput::IsMixedIn method | 586 |
| 7.2.4.10 | IBMDSwitcherAudioInput::GetAudioInputId method | 587 |
| 7.2.4.11 | IBMDSwitcherAudioInput::ResetLevelNotificationPeaks method | 587 |
| 7.2.4.12 | IBMDSwitcherAudioInput::AddCallback method | 588 |
| 7.2.4.13 | IBMDSwitcherAudioInput::RemoveCallback method | 589 |
| 7.2.5 | IBMDSwitcherAudioInputCallback Interface | 590 |
| 7.2.5.1 | IBMDSwitcherAudioInputCallback::Notify method | 591 |
| 7.2.5.2 | IBMDSwitcherAudioInputCallback::LevelNotification method | 592 |
| 7.2.6 | IBMDSwitcherAudioMonitorOutputIterator Interface | 593 |
| 7.2.6.1 | IBMDSwitcherAudioMonitorOutputIterator::Next method | 594 |
| 7.2.7 | IBMDSwitcherAudioMonitorOutput Interface | 595 |
| 7.2.7.1 | IBMDSwitcherAudioMonitorOutput::GetMonitorEnable method | 597 |
| 7.2.7.2 | IBMDSwitcherAudioMonitorOutput::SetMonitorEnable method | 598 |
| 7.2.7.3 | IBMDSwitcherAudioMonitorOutput::GetMute method | 599 |
| 7.2.7.4 | IBMDSwitcherAudioMonitorOutput::SetMute method | 599 |
| 7.2.7.5 | IBMDSwitcherAudioMonitorOutput::GetGain method | 600 |
| 7.2.7.6 | IBMDSwitcherAudioMonitorOutput::SetGain method | 600 |
| 7.2.7.7 | IBMDSwitcherAudioMonitorOutput::GetSolo method | 601 |
| 7.2.7.8 | IBMDSwitcherAudioMonitorOutput::SetSolo method | 601 |
| 7.2.7.9 | IBMDSwitcherAudioMonitorOutput::GetSoloInput method | 602 |
| 7.2.7.10 | IBMDSwitcherAudioMonitorOutput::SetSoloInput method | 603 |
| 7.2.7.11 | IBMDSwitcherAudioMonitorOutput::GetDim method | 604 |
| 7.2.7.12 | IBMDSwitcherAudioMonitorOutput::SetDim method | 604 |
| 7.2.7.13 | IBMDSwitcherAudioMonitorOutput::GetDimLevel method | 605 |
| 7.2.7.14 | IBMDSwitcherAudioMonitorOutput::SetDimLevel method | 605 |
| 7.2.7.15 | IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks method | 606 |
| 7.2.7.16 | IBMDSwitcherAudioMonitorOutput::AddCallback method | 607 |
| 7.2.7.17 | IBMDSwitcherAudioMonitorOutput::RemoveCallback method | 608 |
| 7.2.8 | IBMDSwitcherAudioMonitorOutputCallback Interface | 609 |
| 7.2.8.1 | IBMDSwitcherAudioMonitorOutputCallback::Notify method | 610 |
| 7.2.8.2 | IBMDSwitcherAudioMonitorOutputCallback::LevelNotification method | 611 |
| 7.2.9 | IBMDSwitcherTalkback Interface | 612 |
| 7.2.9.1 | IBMDSwitcherTalkback::GetMuteSDI method | 613 |
| 7.2.9.2 | IBMDSwitcherTalkback::SetMuteSDI method | 614 |
| 7.2.9.3 | IBMDSwitcherTalkback::AddCallback method | 615 |
| 7.2.9.4 | IBMDSwitcherTalkback::RemoveCallback method | 616 |

Table of Contents

| | | |
|----------|---|-----|
| 7.2.10 | IBMDSwitcherTalkbackCallback Interface | 617 |
| 7.2.10.1 | IBMDSwitcherSerialPortCallback::Notify method | 618 |

8 Camera Control 619

| | | |
|----------|--|-----|
| 8.1 | Camera Control Data Types | 619 |
| 8.1.1 | Switcher Camera Control Event Type | 619 |
| 8.1.2 | Switcher Camera Control Parameter Type | 619 |
| 8.2 | Interface Reference | 620 |
| 8.2.1 | Switcher Camera Control Parameter Iterator | 620 |
| 8.2.1.1 | IBMDSwitcherCameraControlParameterIterator::Next method | 621 |
| 8.2.2 | IBMDSwitcherCameraControlCallback Interface | 622 |
| 8.2.2.1 | IBMDSwitcherCameraControlCallback::Notify method | 623 |
| 8.2.3 | IBMDSwitcherCameraControl Interface | 624 |
| 8.2.3.1 | IBMDSwitcherCameraControl::CreateIterator method | 626 |
| 8.2.3.2 | IBMDSwitcherCameraControl::GetPeriodicFlushInterval method | 627 |
| 8.2.3.3 | IBMDSwitcherCameraControl::SetPeriodicFlushInterval method | 628 |
| 8.2.3.4 | IBMDSwitcherCameraControl::GetParameterInfo method | 629 |
| 8.2.3.5 | IBMDSwitcherCameraControl::GetParameterPeriodicFlushEnabled method | 630 |
| 8.2.3.6 | IBMDSwitcherCameraControl::SetParameterPeriodicFlushEnabled method | 631 |
| 8.2.3.7 | IBMDSwitcherCameraControl::SetFlags method | 632 |
| 8.2.3.8 | IBMDSwitcherCameraControl::ToggleFlags method | 633 |
| 8.2.3.9 | IBMDSwitcherCameraControl::GetFlags method | 634 |
| 8.2.3.10 | IBMDSwitcherCameraControl::SetBytes method | 635 |
| 8.2.3.11 | IBMDSwitcherCameraControl::OffsetBytes method | 636 |
| 8.2.3.12 | IBMDSwitcherCameraControl::GetBytes method | 637 |
| 8.2.3.13 | IBMDSwitcherCameraControl::SetInt16s method | 638 |
| 8.2.3.14 | IBMDSwitcherCameraControl::OffsetInt16s method | 639 |
| 8.2.3.15 | IBMDSwitcherCameraControl::GetInt16s method | 640 |
| 8.2.3.16 | IBMDSwitcherCameraControl::SetInt32s method | 641 |
| 8.2.3.17 | IBMDSwitcherCameraControl::OffsetInt32s method | 642 |
| 8.2.3.18 | IBMDSwitcherCameraControl::GetInt32s method | 643 |
| 8.2.3.19 | IBMDSwitcherCameraControl::SetInt64s method | 644 |
| 8.2.3.20 | IBMDSwitcherCameraControl::OffsetInt64s method | 645 |
| 8.2.3.21 | IBMDSwitcherCameraControl::GetInt64s method | 646 |
| 8.2.3.22 | IBMDSwitcherCameraControl::OffsetFloats method | 647 |

Table of Contents

| | | |
|----------|--|-----|
| 8.2.3.23 | IBMDSwitcherCameraControl::SetFloats method | 648 |
| 8.2.3.24 | IBMDSwitcherCameraControl::GetFloats method | 649 |
| 8.2.3.25 | IBMDSwitcherCameraControl::AddCallback method | 650 |
| 8.2.3.26 | IBMDSwitcherCameraControl::RemoveCallback method | 651 |

9 Macros

652

| | | |
|----------|---|-----|
| 9.1 | General Information | 652 |
| 9.1.1 | Macro Indexes and Identification | 652 |
| 9.1.2 | Recording a Macro | 652 |
| 9.1.3 | Downloading a Macro | 653 |
| 9.1.4 | Uploading a Macro | 653 |
| 9.1.5 | Unsupported Operations | 654 |
| 9.2 | Macro Data Types | 655 |
| 9.2.1 | Macro Pool Event Type | 655 |
| 9.2.2 | Macro Control Event Type | 655 |
| 9.2.3 | Macro Run Status | 655 |
| 9.2.4 | Macro Record Status | 655 |
| 9.3 | Interface Reference | 656 |
| 9.3.1 | IBMDSwitcherMacroPool Interface | 656 |
| 9.3.1.1 | IBMDSwitcherMacroPool::GetMaxCount method | 657 |
| 9.3.1.2 | IBMDSwitcherMacroPool::Delete method | 657 |
| 9.3.1.3 | IBMDSwitcherMacroPool::IsValid method | 658 |
| 9.3.1.4 | IBMDSwitcherMacroPool::HasUnsupportedOps method | 659 |
| 9.3.1.5 | IBMDSwitcherMacroPool::GetName method | 660 |
| 9.3.1.6 | IBMDSwitcherMacroPool::SetName method | 661 |
| 9.3.1.7 | IBMDSwitcherMacroPool::GetDescription method | 662 |
| 9.3.1.8 | IBMDSwitcherMacroPool::SetDescription method | 663 |
| 9.3.1.9 | IBMDSwitcherMacroPool::CreateMacro method | 664 |
| 9.3.1.10 | IBMDSwitcherMacroPool::Upload method | 665 |
| 9.3.1.11 | IBMDSwitcherMacroPool::Download method | 666 |
| 9.3.1.12 | IBMDSwitcherMacroPool::AddCallback method | 667 |
| 9.3.1.13 | IBMDSwitcherMacroPool::RemoveCallback method | 668 |
| 9.3.2 | IBMDSwitcherTransferMacro Interface | 669 |
| 9.3.2.1 | IBMDSwitcherTransferMacro::Cancel method | 670 |
| 9.3.2.2 | IBMDSwitcherTransferMacro::GetProgress method | 670 |

Table of Contents

| | | |
|----------|--|-----|
| 9.3.2.3 | IBMDSwitcherTransferMacro::GetMacro method | 671 |
| 9.3.3 | IBMDSwitcherMacro Interface | 672 |
| 9.3.3.1 | IBMDSwitcherMacro::GetSize method | 673 |
| 9.3.3.2 | IBMDSwitcherMacro::GetBytes method | 673 |
| 9.3.4 | IBMDSwitcherMacroPoolCallback Interface | 674 |
| 9.3.4.1 | IBMDSwitcherMacroPoolCallback::Notify method | 675 |
| 9.3.5 | IBMDSwitcherMacroControl Interface | 676 |
| 9.3.5.1 | IBMDSwitcherMacroControl::Run method | 677 |
| 9.3.5.2 | IBMDSwitcherMacroControl::GetLoop method | 678 |
| 9.3.5.3 | IBMDSwitcherMacroControl::SetLoop method | 679 |
| 9.3.5.4 | IBMDSwitcherMacroControl::ResumeRunning method | 680 |
| 9.3.5.5 | IBMDSwitcherMacroControl::StopRunning method | 680 |
| 9.3.5.6 | IBMDSwitcherMacroControl::Record method | 681 |
| 9.3.5.7 | IBMDSwitcherMacroControl::RecordUserWait method | 682 |
| 9.3.5.8 | IBMDSwitcherMacroControl::RecordPause method | 682 |
| 9.3.5.9 | IBMDSwitcherMacroControl::StopRecording method | 683 |
| 9.3.5.10 | IBMDSwitcherMacroControl::GetRunStatus method | 684 |
| 9.3.5.11 | IBMDSwitcherMacroControl::GetRecordStatus method | 685 |
| 9.3.5.12 | IBMDSwitcherMacroControl::AddCallback method | 686 |
| 9.3.5.13 | IBMDSwitcherMacroControl::RemoveCallback method | 687 |
| 9.3.6 | IBMDSwitcherMacroControlCallback Interface | 688 |
| 9.3.6.1 | IBMDSwitcherMacroControlCallback::Notify method | 689 |

SECTION 1 Introduction

1.1 Welcome

Thanks for downloading the Blackmagic Design Switcher Software Developers Kit (SDK).

1.2 Overview

The Switcher SDK provides a stable, cross- platform interface to a Blackmagic Design Switcher product line. The SDK provides both low-level control of hardware and high-level interfaces to allow developers to easily perform common tasks.

The Switcher SDK consists of a set of interface descriptions & sample applications which demonstrate the use of the features of the Switcher hardware. The details of the SDK are described in this document. Some Switcher capabilities, such as uncompressed USB 3 video capture and H.264 video streaming, must be accessed using the separate DeckLink SDK.

The Switcher SDK supports Microsoft Windows and Mac OS X.

You can download the Switcher SDK and DeckLink SDK from the Blackmagic Design support center at: **www.blackmagicdesign.com/support**
The product family is ATEM Live production switchers.

If you're looking for detailed answers regarding technologies used by Blackmagic Design, such as codecs, core media, APIs, SDK and more, visit the Blackmagic Software Developers Forum. The forum is a helpful place for you to engage with both Blackmagic support staff and other forum members who can answer developer specific questions and provide further information. The Software Developers forum can be found within the Blackmagic Design Forum at **forum.blackmagicdesign.com**

If you wish to ask questions outside of the software developers forum, please contact us at: **developer@blackmagicdesign.com**

1.3 API Design

1.3.1 Overview

The libraries supporting the Blackmagic SDK are shipped as part of the product installers for each supported product line. Applications built against the interfaces shipped in the SDK will dynamically link against the library installed on the end-user's system.

1.3.2 Object Model

The SDK interface is modeled on Microsoft's Component Object Model (COM). On Microsoft Windows platforms, it is provided as a native COM interface registered with the operating system. On other platforms application code is provided to allow the same COM style interface to be used.

The COM model provides a paradigm for creating flexible and extensible interfaces without imposing much overhead or baggage.

1.3.3 Object Interfaces

The Switcher API provides programmatic access to all current Blackmagic Design ATEM Switchers.

The Switcher API provides high-level interfaces for configuring switcher inputs and performing switcher operations such as making a transition. Some switcher devices delivering uncompressed video over USB 3 or H.264 video streams over USB 2, but this capability must be accessed using the DeckLink API. Refer to the documentation for the DeckLink SDK at www.blackmagicdesign.com/support.

Functionality within the API is accessed via "object interfaces". Each object in the system may inherit from and be accessed via a number of object interfaces. Typically the developer is able to interact with object interfaces and leave the underlying objects to manage themselves.

Each object interface class has a Globally Unique ID (GUID) called an "Interface ID". On platforms with native COM support, an IID may be used to obtain a handle to an exported interface object from the OS, which is effectively an entry point to an installed API.

Each interface may have related interfaces that are accessed by providing an IID to an existing object interface (see `IUnknown::QueryInterface`). This mechanism allows new interfaces to be added to the API without breaking API or ABI compatibility.

1.3.4 Reference Counting

The API uses reference counting to manage the life cycle of object interfaces. The developer may need to add or remove references on object interfaces (**see IUnknown::AddRef and IUnknown::Release**) to influence their life cycle as appropriate in the application.

1.3.5 Interface Stability

The SDK provides a set of stable interfaces for accessing Blackmagic Design hardware. Whilst the published interfaces will remain stable, developers need to be aware of some issues they may encounter as new products, features and interfaces become available.

1.3.5.1 New Interfaces

Major pieces of new functionality may be added to the SDK as a whole new object interface. Already released applications will not be affected by the additional functionality. Developers making use of the new functionality should be sure to check the return of **CoCreateInstance** and/or **QueryInterface** as these interfaces will not be available on users systems which are running an older release of the Blackmagic software.

Developers can choose to either reduce the functionality of their application when an interface is not available, or to notify the user that they must install a later version of the Blackmagic software.

1.3.5.2 Updated Interfaces

As new functionality is added to the SDK, some existing interfaces may need to be modified or extended. To maintain compatibility with released software, the original interface will be deprecated but will remain available and maintain its unique identifier (IID). The replacement interface will have a new identifier and remain as similar to the original as possible.

1.3.5.3 Deprecated Interfaces

Interfaces which have been replaced with an updated version, or are no longer recommended for use are “deprecated”. Deprecated interfaces are moved out of the main interface description files into an interface description file named according to the release in which the interface was deprecated. Deprecated interfaces are also renamed with a suffix indicating the release prior to the one in which they were deprecated.

It is recommended that developers update their applications to use the most recent SDK interfaces when they release a new version of their applications. As an interim measure, developers may include the deprecated interface descriptions, and updating the names of the interfaces in their application to access the original interface functionality.

1.3.5.4 Removed interfaces

Interfaces that have been deprecated for some time may eventually be removed in a major driver update if they become impractical to support.

1.4 Interface Reference

Every object interface subclasses the **IUnknown** interface.

1.4.1 IUnknown Interface

Each API interface is a subclass of the standard COM base class – **IUnknown**. The **IUnknown** object interface provides reference counting and the ability to look up related interfaces by interface ID. The interface ID mechanism allows interfaces to be added to the API without impacting existing applications.

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| QueryInterface | Provides access to supported child interfaces of the object. |
| AddRef | Increments the reference count of the object. |
| Release | Decrements the reference count of the object. When the final reference is removed, the object is freed. |

1.4.1.1 IUnknown::QueryInterface method

The **QueryInterface** method looks up a related interface of an object interface.

Syntax

```
HRESULT QueryInterface(REFIID id, void **outputInterface);
```

Parameters

| Name | Direction | Description |
|------------------|-----------|--|
| id | in | Interface ID of interface to lookup. |
| output Interface | out | New object interface or NULL on failure. |

Return Values

| Value | Description |
|---------------|--------------------------|
| E_NOINTERFACE | Interface was not found. |
| S_OK | Success. |

1.4.1.2 IUnknown::AddRef method

The **AddRef** method increments the reference count for an object interface.

Syntax

```
ULONG          AddRef();
```

Return Values

| Value | Description |
|-------|--|
| Count | New reference count – for debug purposes only. |

1.4.1.3 IUnknown::Release method

The Release method decrements the reference count for an object interface. When the last reference is removed from an object, the object will be destroyed.

Syntax

```
ULONG          Release();
```

Return Values

| Value | Description |
|-------|--|
| Count | New reference count – for debug purposes only. |

1.5 Using the Switcher API in a project

The supplied sample applications provide examples of how to include the Switcher API in a project on each supported platform.

To use the Switcher API in your project, one or more files need to be included:

Windows Switchers X.Y\Win\Include\BMDSwitcherAPI.idl

Mac OS X Switchers X.Y/Mac/Include/BMDSwitcherAPI.h

Switchers X.Y/Mac/Include/BMDSwitcherAPIDispatch.cpp

1.5.1 Basic Types

boolean

boolean is represented differently on each platform by using its system type:

| | |
|----------|------|
| Windows | BOOL |
| Mac OS X | bool |

string

Strings are represented differently on each platform, using the most appropriate system type:

| | |
|----------|-------------|
| Windows | BSTR |
| Mac OS X | CFStringRef |

int64_t

The signed 64 bit integer type is represented differently on each platform, using the most appropriate system type:

| | |
|----------|-----------|
| Windows | long long |
| Mac OS X | int64_t |

int32_t

The signed 32 bit integer type is represented differently on each platform, using the most appropriate system type:

| | |
|----------|---------|
| Windows | int |
| Mac OS X | int32_t |

uint32_t

The unsigned 32 bit integer type is represented differently on each platform, using the most appropriate system type:

| | |
|----------|--------------|
| Windows | unsigned int |
| Mac OS X | uint32_t |

int16_t

The signed 16 bit integer type is represented differently on each platform, using the most appropriate system type:

| | |
|----------|---------|
| Windows | short |
| Mac OS X | int16_t |

1.5.2 Accessing Switcher devices

Switcher devices are accessed via the **IBMDSwitcherDiscovery** interface. How a reference to an **IBMDSwitcherDiscovery** is obtained varies between platforms depending on their level of support for COM:

1.5.2.1 Windows

The main entry point to the Switcher API is the **CBMDSwitcherDiscovery** class. This class should be obtained from COM using `CoCreateInstance`:

```
IBMDSwitcherDiscovery* switcherDiscovery = NULL;

CoCreateInstance(CLSID_CBMDSwitcherDiscovery, NULL, CLSCTX_ALL, IID_IBMDSwitcherDiscovery,
                (void**)&switcherDiscovery));
```

On success, `CoCreateInstance` returns an `HRESULT` of `S_OK` and `switcherDiscovery` points to a new **IBMDSwitcherDiscovery** object interface.

1.5.2.2 Mac OS X

On Mac OS X a C++ entry point is provided to access an **IBMDSwitcherDiscovery** interface:

```
IBMDSwitcherDiscovery* switcherDiscovery = CreateBMDSwitcherDiscoveryInstance();
```

On success, switcherDiscovery will point to a new **IBMDSwitcherDiscovery** object interface otherwise it will be set to NULL.

SECTION 2 Basic Switcher Control

2 Basic Switcher Control

The Switcher API provides a framework for controlling ATEM switcher devices. The API enables operations such as configuring switcher inputs, performing a transition and making a cut.

2.1 General Information


2.1.1 Switcher Configuration and Transitions

An application for controlling a switcher may perform the following steps:

- Use **IBMDSwitcherDiscovery::ConnectTo** to connect to a switcher device and obtain an **IBMDSwitcher** object interface
- Use **IBMDSwitcher::CreateIterator** to get an **IBMDSwitcherInputIterator** object interface
- For each **IBMDSwitcherInput** returned by **IBMDSwitcherInputIterator::Next** retrieve the input's unique Id using **IBMDSwitcherInput::GetInputId** and retrieve other properties of the input, such as the input's name, using **IBMDSwitcherInput::GetString** or **IBMDSwitcherInput::GetInt**
- Use **IBMDSwitcher::CreateIterator** to get an **IBMDSwitcherMixEffectBlockIterator** object interface
- Obtain an **IBMDSwitcherMixEffectBlock** object interface using **IBMDSwitcherMixEffectBlockIterator::Next**
- Use **IBMDSwitcherMixEffectBlock::SetInt** to configure the Program and Preview inputs to the mix effect block by assigning the input Ids returned by **IBMDSwitcherInput::GetInputId**
- Perform a transition between Program and Preview inputs by calling **IBMDSwitcherMixEffectBlock::PerformTransition**
- Install a callback using **IBMDSwitcherMixEffectBlock::AddCallback** and receive **IBMDSwitcherMixEffectBlockCallback::PropertyChanged** callbacks to determine progress through the transition and when the transition is complete

SECTION 2 Basic Switcher Control

2.1.2 Switcher Interface Diagram



SECTION 2 Basic Switcher Control

2.2 Switcher Data Types

2.2.1 Basic Switcher Data Types

BMDSwitcherInputId

BMDSwitcherInputId is a signed 64 bit integer type and used as a unique Id for each switcher input.

2.2.2 Switcher Event Type

BMDSwitcherEventType enumerates the possible event types for **IBMDSwitcher**.

bmdSwitcherEventTypeVideoModeChanged

The video standard changed.

bmdSwitcherEventTypeMethodForDownConvertedSDChanged

The method for down converted SD output has changed.

bmdSwitcherEventTypeDownConvertedHDVideoModeChanged

The down converted HD output video standard changed for a particular core video standard.

bmdSwitcherEventTypeMultiViewVideoModeChanged

The MultiView standard changed for a particular core video standard.

bmdSwitcherEventTypePowerStatusChanged

The power status changed.

bmdSwitcherEventTypeDisconnected

The switcher disconnected.

2.2.3 Switcher Power Status

BMDSwitcherPowerStatus enumerates the possible power status flags. This type is used by the **IBMDSwitcher** object interface.

bmdSwitcherPowerStatusSupply1

Supply 1 has power.

bmdSwitcherPowerStatusSupply2

Supply 2 has power.

SECTION 2 Basic Switcher Control

2.2.4 Switcher Video Mode

BMDSwitcherVideoMode enumerates the video standards employed by the switcher.

| | |
|---|---|
| bmdSwitcherVideoMode525i5994NTSC | 525 pixels high, interlaced at 59.94Hz (NTSC). |
| bmdSwitcherVideoMode625i50PAL | 625 pixels high, interlaced at 50Hz (PAL). |
| bmdSwitcherVideoMode525i5994Anamorphic | 525 pixels high, interlaced at 59.94Hz (anamorphic 16:9 widescreen). |
| bmdSwitcherVideoMode625i50Anamorphic | 625 pixels high, interlaced at 50Hz (anamorphic 16:9 widescreen). |
| bmdSwitcherVideoMode720p50 | 720 pixels high, progressively scanned at 50Hz. |
| bmdSwitcherVideoMode720p5994 | 720 pixels high, progressively scanned at 59.94Hz. |
| bmdSwitcherVideoMode1080i50 | 1080 pixels high, interlaced at 50Hz. |
| bmdSwitcherVideoMode1080i5994 | 1080 pixels high, interlaced at 59.94Hz. |
| bmdSwitcherVideoMode1080p2398 | 1080 pixels high, progressively scanned at 23.98Hz. |
| bmdSwitcherVideoMode1080p24 | 1080 pixels high, progressively scanned at 24Hz. |
| bmdSwitcherVideoMode1080p25 | 1080 pixels high, progressively scanned at 25Hz. |
| bmdSwitcherVideoMode1080p2997 | 1080 pixels high, progressively scanned at 29.97Hz. |
| bmdSwitcherVideoMode1080p50 | 1080 pixels high, progressively scanned at 50Hz. |
| bmdSwitcherVideoMode1080p5994 | 1080 pixels high, progressively scanned at 59.94Hz. |
| bmdSwitcherVideoMode4KHDp2398 | 2160 pixels high, 3840 pixels wide, progressively scanned at 23.98Hz. |
| bmdSwitcherVideoMode4KHDp24 | 2160 pixels high, 3840 pixels wide, progressively scanned at 24Hz. |
| bmdSwitcherVideoMode4KHDp25 | 2160 pixels high, 3840 pixels wide, progressively scanned at 25Hz. |
| bmdSwitcherVideoMode4KHDp2997 | 2160 pixels high, 3840 pixels wide, progressively scanned at 29.97Hz. |
| bmdSwitcherVideoMode4KHDp50 | 2160 pixels high, 3840 pixels wide, progressively scanned at 50Hz. |
| bmdSwitcherVideoMode4KHDp5994 | 2160 pixels high, 3840 pixels wide, progressively scanned at 59.94Hz. |

SECTION 2 Basic Switcher Control

2.2.5 Switcher Down Conversion Methods

BMDSwitcherDownConversionMethod enumerates the possible methods for SD down conversion between broadcast standards.

| | |
|--|------------------------|
| bmdSwitcherDownConversionMethodCentreCut | Centre cut conversion. |
| bmdSwitcherDownConversionMethodLetterbox | Letter box conversion. |
| bmdSwitcherDownConversionMethodAnamorphic | Anamorphic conversion. |

2.2.6 Switcher Input Event Types

BMDSwitcherInputEventType enumerates the possible event types for a switcher input object.

| | |
|---|--|
| bmdSwitcherInputEventTypeShortNameChanged | The short name of the input changed. |
| bmdSwitcherInputEventTypeLongNameChanged | The long name of the input changed. |
| bmdSwitcherInputEventTypelsProgramTalliedChanged | Program tallying for this input was turned on or turned off. |
| bmdSwitcherInputEventTypelsPreviewTalliedChanged | Preview tallying for this input was turned on or turned off. |
| bmdSwitcherInputEventTypeAvailableExternalPortTypesChanged | The external port types available to this input changed. |
| bmdSwitcherInputEventTypeCurrentExternalPortTypeChanged | The current external port type of this input changed. |

SECTION 2 Basic Switcher Control

2.2.7 Switcher External Port Types

BMDSwitcherExternalPortType enumerates the different kinds of external port type for an input. This enumeration represents a bitset since an input port may support more than one connection type.

| | |
|---|---|
| bmdSwitcherExternalPortTypeSDI | SDI connection. |
| bmdSwitcherExternalPortTypeHDMI | HDMI connection. |
| bmdSwitcherExternalPortTypeComponent | Component connection. |
| bmdSwitcherExternalPortTypeComposite | Composite connection, only available in SD video modes. |
| bmdSwitcherExternalPortTypeSVideo | SVideo connection, only available in SD video modes. |
| bmdSwitcherExternalPortTypeXLR | XLR audio connection. |
| bmdSwitcherExternalPortTypeAESEBU | AES EBU audio connection. |
| bmdSwitcherExternalPortTypeRCA | RCA audio connection. |
| bmdSwitcherExternalPortTypeInternal | This is an internal input port. |

2.2.8 Switcher Port Types

BMDSwitcherPortType enumerates the possible switcher input port types available for switching.

| | |
|--|---|
| bmdSwitcherPortTypeExternal | The port is an external port with a physical connector. |
| bmdSwitcherPortTypeBlack | The port is a black video generator port. |
| bmdSwitcherPortTypeColorBars | The port is a colorbars generator port. |
| bmdSwitcherPortTypeColorGenerator | The port is a color generator port. |
| bmdSwitcherPortTypeMediaPlayerFill | The port is a media player fill port. |
| bmdSwitcherPortTypeMediaPlayerCut | The port is a media player cut port. |
| bmdSwitcherPortTypeSuperSource | The port is a super source port. |
| bmdSwitcherPortTypeMixEffectBlockOutput | The port is a mix effect block output port. |
| bmdSwitcherPortTypeAuxOutput | The port is an auxiliary output port. |

SECTION 2 Basic Switcher Control

2.2.9 Switcher Input Availability

BMDSwitcherInputAvailability enumerates the different kinds of input availability for a port.

This enumeration represents a bitset since an input can have multiple availabilities.

bmdSwitcherInputAvailabilityMixEffectBlock0

The input is available to be used by mix effect block 0.

bmdSwitcherInputAvailabilityMixEffectBlock1

The input is available to be used by mix effect block 1.

bmdSwitcherInputAvailabilityAuxOutputs

The input is available to be used by aux outputs.

bmdSwitcherInputAvailabilityMultiView

The input can be routed to a MultiView window.

bmdSwitcherInputAvailabilitySuperSourceArt

The input is available to be used for SuperSource Art.

bmdSwitcherInputAvailabilitySuperSourceBox

The input is available to be used within a SuperSource Box.

bmdSwitcherInputAvailabilityInputCut

The input is available to be used as a cut.

2.2.10 Switcher Mix Effect Block Properties

BMDSwitcherMixEffectBlockPropertyId enumerates the possible properties of a Mix Effect Block.

bmdSwitcherMixEffectBlockPropertyIdProgramInput

The program input as a **BMDSwitcherInputId**.

bmdSwitcherMixEffectBlockPropertyIdPreviewInput

The preview input as a **BMDSwitcherInputId**.

bmdSwitcherMixEffectBlockPropertyIdTransitionPosition

Float value between 0 and 1 representing the progress through a transition where 0 is the start of a transition and 1 is the end.

bmdSwitcherMixEffectBlockPropertyIdTransitionFramesRemaining

Number of frames remaining in a transition as an integer.

bmdSwitcherMixEffectBlockPropertyIdInTransition

State of mix effect block being in a transition as a boolean.

bmdSwitcherMixEffectBlockPropertyIdFadeToBlackFramesRemaining

Number of frames remaining in a fade to black as an integer.

bmdSwitcherMixEffectBlockPropertyIdInFadeToBlack

State of mix effect block being in a fade to black as a boolean.

bmdSwitcherMixEffectBlockPropertyIdPreviewLive

Boolean value which is true when preview is live.

bmdSwitcherMixEffectBlockPropertyIdPreviewTransition

Boolean value which is true when preview transition is active.

bmdSwitcherMixEffectBlockPropertyIdInputAvailabilityMask

The corresponding **BMDSwitcherInputAvailability** bit value for this mix effect block.

bmdSwitcherMixEffectBlockPropertyIdFadeToBlackRate

The fade to black rate in frames

SECTION 2 Basic Switcher Control

bmdSwitcherMixEffectBlockPropertyIdFadeToBlackFullyBlack
bmdSwitcherMixEffectBlockPropertyIdFadeToBlackInTransition

Boolean value which is true when fade to black is fully black
Boolean value which is true when fade to black is transitioning.

2.2.11 Switcher Connection Errors

BMDSwitcherConnectToFailure enumerates the possible errors that can occur when connecting to a switcher.

bmdSwitcherConnectToFailureNoResponse
bmdSwitcherConnectToFailureIncompatibleFirmware

The Switcher did not respond after a connection attempt was made.
The software on the Switcher is incompatible with the current version of the Switcher SDK.

bmdSwitcherConnectToFailureCorruptData
bmdSwitcherConnectToFailureStateSync
bmdSwitcherConnectToFailureStateSyncTimedOut

Corrupt data was received during a connection attempt.
State synchronisation failed during a connection attempt.
State synchronisation timed out during a connection attempt.

2.2.12 Switcher MultiView Layouts

BMDSwitcherMultiViewLayout enumerates the possible layout formats for MultiView.

bmdSwitcherMultiViewLayoutProgramTop
bmdSwitcherMultiViewLayoutProgramBottom
bmdSwitcherMultiViewLayoutProgramLeft
bmdSwitcherMultiViewLayoutProgramRight

Program and preview reside in upper section of the screen, windows reside below.
Program and preview reside in lower section of the screen, windows reside above.
Program and preview reside on left hand side, windows reside on the right.
Program and preview reside on right hand side, windows reside on the left.

2.2.13 Switcher Serial Port Functions

BMDSwitcherSerialPortFunction enumerates the functions the serial port can perform.

bmdSwitcherSerialPortFunctionNone
bmdSwitcherSerialPortFunctionPtzVisca
bmdSwitcherSerialPortFunctionGvg100

The serial port is not being used.
The serial port is used to control a Pan-Tilt-Zoom camera using the VISCA protocol.
If the serial port is set to this function, the switcher can be controlled by a connected GVG100 compatible editor/controller.

SECTION 2 Basic Switcher Control

2.2.14 Switcher Color Events

BMDSwitcherInputColorEventType enumerates the possible event types for **IBMDSwitcherInputColorCallback**.

| | |
|--|-------------------------|
| bmdSwitcherInputColorEventTypeHueChanged | The hue changed. |
| bmdSwitcherInputColorEventTypeSaturationChanged | The saturation changed. |
| bmdSwitcherInputColorEventTypeLumaChanged | The luma changed. |

2.2.15 Switcher Aux Events

BMDSwitcherInputAuxEventType enumerates the possible event types for **IBMDSwitcherInputAuxCallback**.

| | |
|---|---------------------------|
| bmdSwitcherInputAuxEventTypeInputSourceChanged | The input source changed. |
|---|---------------------------|

2.2.16 Switcher MultiView Events

BMDSwitcherMultiViewEventType enumerates the possible event types for **IBMDSwitcherMultiViewCallback**.

| | |
|---|--|
| bmdSwitcherMultiViewEventTypeLayoutChanged | The layout changed. |
| bmdSwitcherMultiViewEventTypeWindowChanged | Routing to a MultiView window has changed. |

2.2.17 Switcher Serial Port Event Types

BMDSwitcherSerialPortEventType enumerates the possible event types for **IBMDSwitcherSerialPortCallback**.

| | |
|--|--|
| bmdSwitcherSerialPortEventTypeFunctionChanged | The function of the serial port has changed. |
|--|--|

SECTION 2 Basic Switcher Control

2.3 Interface Reference

2.3.1 IBMDSwitcherDiscovery Interface

The **IBMDSwitcherDiscovery** object interface is used to connect to a physical switcher device.

A reference to an **IBMDSwitcherDiscovery** object interface may be obtained from **CoCreateInstance** on platforms with native COM support or from **CreateBMDSwitcherDiscoveryInstance** on other platforms.

Public Member Functions

| Method | Description |
|-----------|-----------------------|
| ConnectTo | Connect to a switcher |

SECTION 2 Basic Switcher Control

2.3.1.1 IBMDSwitcherDiscovery::ConnectTo method

The ConnectTo method connects to the specified switcher and returns an **IBMDSwitcher** object interface for the switcher.

Note: **ConnectTo** performs a synchronous network connection. This may take several seconds depending upon hostname resolution and network response times.

Syntax

```
HRESULT ConnectTo (string deviceAddress, IBMDSwitcher** switcherDevice,  
                    BMDSwitcherConnectToFailure* failReason);
```

Parameters

| Name | Direction | Description |
|----------------|-----------|--|
| deviceAddress | in | Network hostname or IP address of switcher to connect to. |
| switcherDevice | out | IBMDSwitcher object interface for the connected switcher. |
| failReason | out | Reason for connection failure as a BMDSwitcherConnectToFailure value. |

Return Values

| Value | Description |
|-----------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The switcherDevice or failReason parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2 IBMDSwitcher Interface

The **IBMDSwitcher** object interface represents a physical switcher device.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|--|
| IBMDSwitcherDiscovery | IID_IBMDSwitcherDiscovery | An IBMDSwitcher object will be returned after a successful call to the IBMDSwitcherDiscovery::ConnectTo method |

| Public Member Functions | |
|-------------------------------------|--|
| Method | Description |
| GetProductName | Get the product name of the switcher. |
| GetVideoMode | Get the current video standard applied across the switcher. |
| SetVideoMode | Set the video standard applied across the switcher. |
| DoesSupportVideoMode | Determines if a video standard is supported by the switcher. |
| GetMethodForDownConvertedSD | Get the SD conversion method applied when down converting between broadcast standards. |
| SetMethodForDownConvertedSD | Set the SD conversion method applied when down converting between broadcast standards. |
| GetDownConvertedHDVideoMode | Get the down converted HD video standard for a particular core video standard. |
| SetDownConvertedHDVideoMode | Set the down converted HD video standard for a particular core video standard. |
| DoesSupportDownConvertedHDVideoMode | Determines if a down converted HD video standard is supported by a particular core video standard. |
| GetMultiViewVideoMode | Get the MultiView video standard for a particular core video standard. |
| SetMultiViewVideoMode | Set the MultiView video standard for a particular core video standard. |
| DoesSupportMultiViewVideoMode | Determines if a MultiView video standard is supported by a particular core video standard. |
| GetPowerStatus | Gets the power status of the switcher. |
| CreateIterator | Create an iterator. |
| AddCallback | Add a callback to receive switcher events. |
| RemoveCallback | Remove a callback. |

SECTION 2 Basic Switcher Control

2.3.2.1 IBMDSwitcher:: GetProductName method

The **GetProductName** method gets the product name of the switcher.

Syntax

```
HRESULT GetProductName (string* productName);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|-----------------------------------|
| productName | out | The product name of the switcher. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The productName parameter is invalid. |

2.3.2.2 IBMDSwitcher:: GetVideoMode method

The **GetVideoMode** method gets the current video standard applied across the switcher.

Syntax

```
HRESULT GetVideoMode (BMDSwitcherVideoMode* videoMode);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| videoMode | out | The current video standard applied across the switcher. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The videoMode parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.3 IBMDSwitcher:: SetVideoMode method

The **SetVideoMode** method sets the video standard applied across the switcher.

Syntax

```
HRESULT SetVideoMode (BMDSwitcherVideoMode videoMode);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| videoMode | in | The video standard applied across the switcher. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The videoMode parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.4 IBMDSwitcher:: DoesSupportVideoMode method

The **DoesSupportVideoMode** method determines if a video standard is supported by the switcher.

Syntax

```
HRESULT DoesSupportVideoMode (BMDSwitcherVideoMode videoMode, boolean* supported);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| videoMode | in | The video standard. |
| supported | out | Boolean value that is true if the video standard is supported. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The supported parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.5 IBMDSwitcher:: GetMethodForDownConvertedSD method

The **GetMethodForDownConvertedSD** method gets the SD conversion method applied when down converting between broadcast standards.

Syntax

```
HRESULT GetMethodForDownConvertedSD (BMDSwitcherDownConversionMethod* method);
```

Parameters

| Name | Direction | Description |
|--------|-----------|------------------------|
| method | out | The conversion method. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The method parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.6 IBMDSwitcher:: SetMethodForDownConvertedSD method

The **SetMethodForDownConvertedSD** method sets the SD conversion method applied when down converting between broadcast standards.

Syntax

```
HRESULT SetMethodForDownConvertedSD (BMDSwitcherDownConversionMethod method);
```

Parameters

| Name | Direction | Description |
|--------|-----------|------------------------|
| method | in | The conversion method. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The method parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.7 IBMDSwitcher:: GetDownConvertedHDVideoMode method

The **GetDownConvertedHDVideoMode** method gets the down converted HD output video standard for a particular core video standard.

Syntax

```
HRESULT GetDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode* downConvertedHDVideoMode);
```

Parameters

| Name | Direction | Description |
|--------------------------|-----------|--|
| coreVideoMode | in | The core video standard to be down converted. |
| downConvertedHDVideoMode | out | The mode to which the core video standard is down converted. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_POINTER | The downConvertedHDVideoMode parameter is invalid. |
| E_INVALIDARG | The coreVideoMode parameter is invalid or not supported. |
| E_NOTIMPL | HD down conversion is not supported. |

SECTION 2 Basic Switcher Control

2.3.2.8 IBMDSwitcher:: SetDownConvertedHDVideoMode method

The **SetDownConvertedHDVideoMode** method sets the down converted HD output video standard for a particular core video standard.

Syntax

```
HRESULT SetDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode downConvertedHDVideoMode);
```

Parameters

| Name | Direction | Description |
|--------------------------|-----------|--|
| coreVideoMode | in | The core video standard to be down converted. |
| downConvertedHDVideoMode | in | The mode to which the core video standard is to be down converted. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_INVALIDARG | The coreVideoMode or downConvertedHDVideoMode parameter is invalid or not supported. |
| E_NOTIMPL | HD down conversion is not supported. |

SECTION 2 Basic Switcher Control

2.3.2.9 IBMDSwitcher:: DoesSupportDownConvertedHDVideoMode method

The **DoesSupportDownConvertedHDVideoMode** method determines if a down converted HD output video standard is supported by a particular core video standard.

Syntax

```
HRESULT DoesSupportDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode downConvertedHDVideoMode, boolean* supported);
```

Parameters

| Name | Direction | Description |
|--------------------------|-----------|--|
| coreVideoMode | in | The core video standard to be down converted. |
| downConvertedHDVideoMode | in | The down converted video standard to determine support for. |
| supported | out | Boolean value that is true if the downConvertedHDVideoMode is supported for the core video standard. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_POINTER | The supported parameter is invalid. |
| E_INVALIDARG | The downConvertedHDVideoMode parameter is invalid. |
| E_NOTIMPL | The switcher does not support HD down conversion. |

SECTION 2 Basic Switcher Control

2.3.2.10 IBMDSwitcher:: GetMultiViewVideoMode method

The **GetMultiViewVideoMode** method gets the MultiView video standard for a particular core video standard.

Syntax

```
HRESULT GetMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode* multiviewVideoMode);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| coreVideoMode | in | The core video standard. |
| multiviewVideoMode | out | The MultiView standard used with the core video standard. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_POINTER | The multiviewVideoMode parameter is invalid. |
| E_INVALIDARG | The coreVideoMode parameter is invalid or not supported. |

SECTION 2 Basic Switcher Control

2.3.2.11 IBMDSwitcher:: SetMultiViewVideoMode method

The **SetMultiViewVideoMode** method gets the MultiView video standard for a particular core video standard.

Syntax

```
HRESULT SetMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode multiviewVideoMode);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| coreVideoMode | in | The core video standard. |
| multiviewVideoMode | in | The MultiView standard to set with the core video standard. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_INVALIDARG | The coreVideoMode or multiviewVideoMode parameter is invalid or not supported. |

SECTION 2 Basic Switcher Control

2.3.2.12 IBMDSwitcher:: DoesSupportMultiViewVideoMode method

The **DoesSupportMultiViewVideoMode** method determines if a MultiView video standard is supported for a particular core video standard.

Syntax

```
HRESULT DoesSupportMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode, BMDSwitcherVideoMode multiviewVideoMode, boolean* supported);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|--|
| coreVideoMode | in | The core video standard. |
| multiviewVideoMode | in | The MultiView video standard to use for the coreVideoMode. |
| supported | out | Boolean value that is true if the MultiView video standard is supported for the coreVideoMode. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_POINTER | The supported parameter is invalid. |
| E_INVALIDARG | The multiviewVideoMode parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.13 IBMDSwitcher:: GetPowerStatus method

The **GetPowerStatus** method gets the connected power status, useful for models supporting multiple power sources.

Syntax

```
HRESULT GetPowerStatus (BMDSwitcherPowerStatus* powerStatus);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|-------------------|
| powerStatus | out | The power status. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The powerStatus parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.14 IBMDSwitcher:: CreateIterator method

The **CreateIterator** method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| iid | in | Iterator Interface ID to create an iterator for. |
| ppv | in | Pointer to return interface object. |

Return Values

| Value | Description |
|---------------|---|
| S_OK | Success. |
| E_POINTER | The ppv parameter is invalid. |
| E_OUTOFMEMORY | Insufficient memory to create interface object. |
| E_NOINTERFACE | Interface was not found. |

SECTION 2 Basic Switcher Control

2.3.2.15 IBMDSwitcher::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcher** object.

Pass an object implementing the **IBMDSwitcherCallback** interface to receive callbacks.

Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.2.16 IBMDSwitcher::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.3 IBMDSwitcherCallback Interface

The **IBMDSwitcherCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcher** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | An IBMDSwitcherCallback object interface is installed with IBMDSwitcher::AddCallback and removed with IBMDSwitcher::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 2 Basic Switcher Control

2.3.3.1 IBMDSwitcherCallback::Notify method

The **Notify** is called when **IBMDSwitcher** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherEventType eventType, BMDSwitcherVideoMode coreVideoMode);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| eventType | in | BMDSwitcherEventType that describes the type of event that has occurred. |
| coreVideoMode | in | Video standard for which the event was triggered. This parameter is used in bmdSwitcherEventTypeDownConverted , HDVideoModeChanged and bmdSwitcherEventTypeMultiViewVideoModeChanged event types. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.4 IBMDSwitcherInputIterator Interface

The **IBMDSwitcherInputIterator** object interface is used to enumerate the available switcher inputs.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::CreateIterator returns an IBMDSwitcherInputIterator object interface when the IID_IBMDSwitcherInputIterator IID is specified. |

Public Member Functions

| Method | Description |
|---------|--|
| Next | Returns the next available switcher input. |
| GetById | Returns a switcher input for an input Id. |

SECTION 2 Basic Switcher Control

2.3.4.1 IBMDSwitcherInputIterator::Next method

The **Next** method returns the next available **IBMDSwitcherInput** object interface.

The **IBMDSwitcherInput** object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherInput** input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--|
| input | out | IBMDSwitcherInput object interface. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| S_FALSE | No (more) inputs are available. |
| E_POINTER | The input parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.4.2 IBMDSwitcherInputIterator::GetById method

The **GetById** method returns the **IBMDSwitcherInput** object interface corresponding to the specified Id.

Syntax

```
HRESULT GetById (BMDSwitcherInputId inputId, IBMDSwitcherInput** input);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | in | BMDSwitcherInputId of input. |
| input | out | IBMDSwitcherInput object interface. |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The inputId parameter is invalid. |
| E_POINTER | The input parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.5 IBMDSwitcherInput Interface

The **IBMDSwitcherInput** object interface represents a physical switcher device.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------------------|---------------------------------------|--|
| IBMDSwitcherInputDiscovery | IID_IBMDSwitcherInputDiscovery | An IBMDSwitcherInput object will be returned after a successful call to the IBMDSwitcherInputDiscovery::ConnectTo method |

Public Member Functions

| Method | Description |
|----------------------|---|
| AddCallback | Add a callback to receive input property changes. |
| RemoveCallback | Remove a callback. |
| GetInputId | Get the unique ID for this input. |
| GetPortType | Get the port type as a BMDSwitcherPortType . |
| GetInputAvailability | Get the outputs this input can be routed to, as a BMDSwitcherInputAvailability object. |
| SetShortName | Set the short name describing the switcher input as a string limited to 4 ASCII characters. |
| GetShortName | Get the short name describing the switcher input as a string limited to 4 ASCII characters. |
| SetLongName | Set the long name describing the switcher input as a Unicode string limited to 20 bytes. |
| GetLongName | Get the long name describing the switcher input as a Unicode string limited to 20 bytes. |

SECTION 2 Basic Switcher Control

| Public Member Functions | |
|-------------------------------|--|
| Method | Description |
| ResetNames | Reset the long and short names for this switcher input to the factory defaults for this input. |
| IsProgramTallied | Returns a flag indicating whether the input is currently program tallied. |
| IsPreviewTallied | Returns a flag indicating whether the input is currently preview tallied. |
| GetAvailableExternalPortTypes | Get the available external port types as a bit mask of BMDSwitcherExternalPortType . |
| SetCurrentExternalPortType | Set the external port type for this input using a BMDSwitcherExternalPortType . |

SECTION 2 Basic Switcher Control

2.3.5.1 IBMDSwitcherInput::AddCallback method

The **AddCallback** method configures a callback to be called when a switcher input property changes.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherInputCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.5.2 IBMDSwitcherInput::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|----------------------------|
| callback | in | Callback object to remove. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

2.3.5.3 IBMDSwitcherInput::GetInputId method

The **GetInputId** method gets the unique Id for the switcher input.

Syntax

```
HRESULT GetInputId (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| inputId | out | unique Id for switcher input. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inputId parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.5.4 IBMDSwitcherInput::GetPortType method

The **GetPortType** method returns the port type of this switcher input as a **BMDSwitcherPortType**. This can be used to determine if this input is an external port (i.e. `bmdSwitcherPortTypeExternal`), or any of the internal port types such as color bars (i.e. `bmdSwitcherPortTypeColorBars`).

Syntax

```
HRESULT GetPortType(BMDSwitcherPortType* type);
```

Parameters

| Name | Direction | Description |
|------|-----------|----------------|
| type | out | The port type. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The type parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.5 IBMDSwitcherInput::GetInputAvailability method

The **GetInputAvailability** method determines which outputs this input can be routed to. The available output groups are given as a bit mask of **BMDSwitcherInputAvailability**. The value returned can be bit-wise AND-ed with any **BMDSwitcherInputAvailability** value (e.g. `bmdSwitcherInputAvailabilityAuxOutputs`) to determine the availability of this input to that output group.

Syntax

```
HRESULT GetInputAvailability(BMDSwitcherInputAvailability* availability);
```

Parameters

| Name | Direction | Description |
|--------------|-----------|--------------------------------|
| availability | out | The availability of the input. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| E_POINTER | The availability parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.6 IBMDSwitcherInput::SetShortName method

The **SetShortName** method assigns the short name describing the switcher input as a string limited to 4 ASCII characters.

Syntax

```
HRESULT SetShortName(string name);
```

Parameters

| Name | Direction | Description |
|------|-----------|---|
| name | in | The short name for the switcher input, limited to 4 ASCII characters. |

Return Values

| Value | Description |
|--------------|---|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The name parameter is not a valid pointer. |
| E_INVALIDARG | The name parameter contains non-ASCII characters. |

SECTION 2 Basic Switcher Control

2.3.5.7 IBMDSwitcherInput::GetShortName method

The **GetShortName** method gets the short name describing the switcher input as a string limited to 4 ASCII characters.

Syntax

```
HRESULT GetShortName(string* name);
```

Parameters

| Name | Direction | Description |
|------|-----------|---|
| name | out | The short name for the switcher input, limited to 4 ASCII characters. |

Return Values

| Value | Description |
|-----------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The name parameter is not a valid pointer. |

SECTION 2 Basic Switcher Control

2.3.5.8 IBMDSwitcherInput::SetLongName method

The **SetLongName** method sets the long name, describing the switcher input as a Unicode string in UTF-8 format with a maximum length of 20 bytes. If a string longer than 20 bytes is provided, it will be truncated to the longest valid UTF-8 string of 20 bytes or less.

Syntax

```
HRESULT SetLongName(string name);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| name | in | The long name describing the switcher input as a Unicode string with a maximum length of 20 bytes. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The name parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.9 IBMDSwitcherInput::GetLongName method

The **GetLongName** method gets the long name for the switcher input, describing the input as a Unicode string in UTF-8 format with a maximum length of 20 bytes.

Syntax

```
HRESULT GetLongName(string* name);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| name | out | The long name describing the switcher input as a Unicode string with a maximum length of 20 bytes. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The name parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.10 IBMDSwitcherInput::ResetNames method

The **ResetNames** method resets the long and short names for this switcher input to the factory defaults for this input.

Syntax

```
HRESULT ResetNames();
```

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.5.11 IBMDSwitcherInput::IsProgramTallied method

The **IsProgramTallied** method determines whether this switcher input is currently program tallied.

Syntax

```
HRESULT IsProgramTallied(bool* isTallied);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| isTallied | out | Flag indicating if the input is currently program tallied. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The isTallied parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.12 IBMDSwitcherInput::IsPreviewTallied method

The **IsPreviewTallied** method determines whether this switcher input is currently preview tallied.

Syntax

```
HRESULT IsPreviewTallied(bool* isTallied);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| isTallied | out | Flag indicating if the input is currently preview tallied. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The isTallied parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.13 IBMDSwitcherInput::GetAvailableExternalPortTypes method

The **GetAvailableExternalPortTypes** method gets the available external port types for this switcher input, given as a bit mask of **BMDSwitcherExternalPortType**. This bit mask can be bit-wise AND-ed with any value of **BMDSwitcherExternalPortType** (e.g. `bmdSwitcherExternalPortTypeSDI`) to determine if that external port type is available for this input.

Syntax

```
HRESULT GetAvailableExternalPortTypes(BMDSwitcherExternalPortType* types);
```

Parameters

| Name | Direction | Description |
|-------|-----------|---|
| types | out | The available external port types for this switcher input as a bit mask of BMDSwitcherExternalPortType . |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The types parameter is not valid. |

SECTION 2 Basic Switcher Control

2.3.5.14 IBMDSwitcherInput::SetCurrentExternalPortType method

The **SetCurrentExternalPortType** method sets the external port type for this input using a **BMDSwitcherExternalPortType**. The external port type is settable only for some inputs and not all external port types are valid for a given input. Call the **GetAvailableExternalPortTypes** function to determine the available external port types for this input.

Syntax

```
HRESULT SetCurrentExternalPortType(BMDSwitcherExternalPortType type);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| type | in | The external port type. |

Return Values

| Value | Description |
|--------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | The type parameter is not valid a valid external port type for this input. |

SECTION 2 Basic Switcher Control

2.3.6 IBMDSwitcherInputCallback Interface

The **IBMDSwitcherInputCallback** object interface is a callback class which is called when a switcher input event such as a property change occurs.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------|-----------------------|--|
| IBMDSwitcherInput | IID_IBMDSwitcherInput | An IBMDSwitcherInputCallback object interface may be installed with IBMDSwitcherInput::AddCallback |

Public Member Functions

| Method | Description |
|--------|--|
| Notify | A Switcher Input event occurred such as a property change. |

SECTION 2 Basic Switcher Control

2.3.6.1 IBMDSwitcherInputCallback::Notify method

The **Notify** method is called when a **IBMDSwitcherInput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherInputEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.7 IBMDSwitcherMixEffectBlocklterator Interface

The **IBMDSwitcherMixEffectBlocklterator** object interface is used to enumerate the available mix effect blocks.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::Createlterator returns an IBMDSwitcherMixEffectBlocklterator object interface when the IID_IBMDSwitcherMixEffectBlocklterator IID is specified. |

Public Member Functions

| Method | Description |
|--------|---|
| Next | Returns the next available switcher mix effect block. |

SECTION 2 Basic Switcher Control

2.3.7.1 IBMDSwitcherMixEffectBlockIterator::Next method

The **Next** method returns the next available **IBMDSwitcherMixEffectBlock** object interface.

The **IBMDSwitcherMixEffectBlock** object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherMixEffectBlock** mixEffectBlock);
```

Parameters

| Name | Direction | Description |
|----------------|-----------|--|
| mixEffectBlock | out | IBMDSwitcherMixEffectBlock object interface |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| S_FALSE | No (more) mix effect blocks are available. |
| E_POINTER | The mixEffectBlock parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.8 IBMDSwitcherMixEffectBlock Interface

The **IBMDSwitcherMixEffectBlock** object interface represents a mix effect block of a switcher device.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------------|--|---|
| IBMDSwitcherMixEffectBlockIterator | IID_IBMDSwitcherMixEffectBlockIterator | IBMDSwitcherMixEffectBlockIterator::Next returns IBMDSwitcherMixEffectBlock object interfaces for each available mix effect block of a switcher device. |

Public Member Functions

| Method | Description |
|----------------|--|
| CreateIterator | Create an iterator. |
| AddCallback | Add a callback to receive mix effect block property changes. |
| RemoveCallback | Remove a callback. |
| GetFlag | Get the current value of a boolean encoding mode setting. |
| GetInt | Get the current value of a int64_t encoding mode setting. |
| GetFloat | Get the current value of a double encoding mode setting. |
| GetString | Get the current value of a string encoding mode setting. |
| SetFlag | Set the value for a boolean encoding mode setting. |
| SetInt | Set the value for an int64_t encoding mode setting. |
| SetFloat | Set the value for a double encoding mode setting. |
| SetString | Set the value for a string encoding mode setting. |

SECTION 2 Basic Switcher Control

2.3.8.1 IBMDSwitcherMixEffectBlock::CreateIterator method

The **CreateIterator** method creates an iterator object interface for the specified interface Id.

Note: In the current version of the Switcher SDK there are no supported iterator IIDs for this method.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| iid | in | Iterator Interface ID to create an iterator for. |
| ppv | out | Pointer to return interface object. |

Return Values

| Value | Description |
|---------------|---|
| S_OK | Success. |
| E_POINTER | The ppv parameter is invalid. |
| E_OUTOFMEMORY | Insufficient memory to create interface object. |
| S_NOINTERFACE | Interface was not found. |

SECTION 2 Basic Switcher Control

2.3.8.2 IBMDSwitcherMixEffectBlock::AddCallback method

The **AddCallback** method configures a callback to be called when a mix effect block property changes.

Adding a new callback will not affect previously added callbacks. Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMixEffectBlockCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherMixEffectBlockCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.8.3 IBMDSwitcherMixEffectBlock::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMixEffectBlockCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|----------------------------|
| callback | in | Callback object to remove. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.8.4 IBMDSwitcherMixEffectBlock::GetFlag method

The **GetFlag** method gets the current value of the boolean property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT GetFlag (BMDSwitcherMixEffectBlockPropertyId propertyId, boolean* value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | BMDSwitcherMixEffectBlockPropertyId to get flag value. |
| value | out | The value corresponding to propertyId. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.5 IBMDSwitcherMixEffectBlock::GetInt method

The **GetInt** method gets the current value of the int64_t property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT GetInt (BMDSwitcherMixEffectBlockPropertyId propertyId, int64_t* value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--|
| propertyId | in | BMDSwitcherMixEffectBlockPropertyId to get integer value. |
| value | out | The value corresponding to propertyId. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.6 **IBMDSwitcherMixEffectBlock::GetFloat** method

The **GetFloat** gets the current value of the double property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT GetFloat (BMDSwitcherMixEffectBlockPropertyId propertyId, double* value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | BMDSwitcherMixEffectBlockPropertyId to get double value. |
| value | out | The value corresponding to propertyId. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.7 IBMDSwitcherMixEffectBlock::GetString method

The **GetString** current value of the string property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT GetString (BMDSwitcherMixEffectBlockPropertyId propertyId, string value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--|
| propertyId | in | BMDSwitcherMixEffectBlockPropertyId to get string value. |
| value | out | The value corresponding to propertyId. This allocated string must be released by the caller when no longer required. |

Return Values

| Value | Description |
|---------------|---------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |
| E_OUTOFMEMORY | Unable to allocate memory for string. |

SECTION 2 Basic Switcher Control

2.3.8.8 IBMDSwitcherMixEffectBlock::SetFlag method

The **SetFlag** method sets a boolean value into the property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT SetFlag (BMDSwitcherMixEffectBlockPropertyId propertyId, boolean value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--|
| propertyId | in | The ID of the property. |
| value | in | The boolean value to set into the selected property. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.9 IBMDSwitcherMixEffectBlock::SetInt method

The **SetInt** method sets an `int64_t` value into the property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT SetInt (BMDSwitcherMixEffectBlockPropertyId propertyId, int64_t value);
```

Parameters

| Name | Direction | Description |
|-------------------------|-----------|--|
| <code>propertyId</code> | in | The ID of the property. |
| <code>value</code> | in | The integer value to set into the selected property. |

Return Values

| Value | Description |
|---------------------------|-------------------------------------|
| <code>E_FAIL</code> | Failure. |
| <code>S_OK</code> | Success. |
| <code>E_INVALIDARG</code> | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.10 IBMDSwitcherMixEffectBlock::SetFloat method

The **SetFloat** method sets a double value into the property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT SetFloat (BMDSwitcherMixEffectBlockPropertyId propertyId, double value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | The ID of the property. |
| value | in | The double value to set into the selected property. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.11 IBMDSwitcherMixEffectBlock::SetString method

The **SetString** method sets a string value into the property associated with the given **BMDSwitcherMixEffectBlockPropertyId**.

Syntax

```
HRESULT SetString (BMDSwitcherMixEffectBlockPropertyId propertyId, string value);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | The ID of the property. |
| value | in | The string value to set into the selected property. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | One or more parameters are invalid. |

SECTION 2 Basic Switcher Control

2.3.8.12 **IBMDSwitcherMixEffectBlock::PerformAutoTransition** method

The **PerformAutoTransition** method initiates an automatic transition for the mix effect block.

When the transition begins the **bmdSwitcherMixEffectBlockPropertyIdInTransition** property will change to true and when the transition is complete it will become false. Throughout the transition the **bmdSwitcherMixEffectBlockPropertyIdTransitionPosition** and **bmdSwitcherMixEffectBlockPropertyIdTransitionFramesRemaining** properties will change to values corresponding to the progress through the transition.

Syntax

```
HRESULT PerformAutoTransition ();
```

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.8.13 **IBMDSwitcherMixEffectBlock::PerformCut** method

The **PerformCut** method initiates a cut for the mix effect block.

Syntax

```
HRESULT PerformCut ();
```

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

2.3.8.14 **IBMDSwitcherMixEffectBlock::PerformFadeToBlack** method

The **PerformFadeToBlack** method initiates a fade to black for the mix effect block.

When the fade to black begins the **bmdSwitcherMixEffectBlockPropertyIdInFadeToBlack** property will change to true and when the transition is complete it will become false. Throughout the fade to black the **bmdSwitcherMixEffectBlockPropertyIdFadeToBlackFramesRemaining** property will change to a value corresponding to the progress through the fade to black.

Syntax

```
HRESULT PerformFadeToBlack ();
```

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.9 IBMDSwitcherMixEffectBlockCallback Interface

The **IBMDSwitcherMixEffectBlockCallback** object interface is a callback class which is called when a mix effect block property changes.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|--|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherMixEffectBlockCallback object interface may be installed with IBMDSwitcherMixEffectBlock::AddCallback . |

Public Member Functions

| Method | Description |
|-----------------|------------------------------------|
| PropertyChanged | Mix effect block property changed. |

SECTION 2 Basic Switcher Control

2.3.9.1 IBMDSwitcherMixEffectBlockCallback::PropertyChanged method

The **PropertyChanged** method is called when a mix effect block property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT PropertyChanged (BMDSwitcherMixEffectBlockPropertyId propertyId);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | Id of the property that changed as a BMDSwitcherMixEffectBlockPropertyId |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.10 IBMDSwitcherInputColor Interface

The **IBMDSwitcherInputColor** object interface is used for managing a color generator input port.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------|-----------------------|---|
| IBMDSwitcherInput | IID_IBMDSwitcherInput | An IBMDSwitcherInputColor object interface can be obtained with IBMDSwitcherInput::QueryInterface . |

Public Member Functions

| Method | Description |
|----------------|-----------------------------------|
| GetHue | Get the current hue value. |
| SetHue | Set the hue value. |
| GetSaturation | Get the current saturation value. |
| SetSaturation | Set the saturation value. |
| GetLuma | Get the current luminance value. |
| SetLuma | Set the luminance value. |
| AddCallback | Add a color input callback. |
| RemoveCallback | Remove a color input callback. |

SECTION 2 Basic Switcher Control

2.3.10.1 IBMDSwitcherInputColor::GetHue method

The **GetHue** method gets the current hue value.

Syntax

```
HRESULT GetHue (double* hue);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| propertyId | in | Id of the property that changed as a BMDSwitcherMixEffectBlockPropertyId |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

SECTION 2 Basic Switcher Control

2.3.10.2 IBMDSwitcherInputColor::SetHue method

The **SetHue** method sets the hue value.

Syntax

```
HRESULT SetHue (double hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| hue | in | The desired hue value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

2.3.10.3 IBMDSwitcherInputColor::GetSaturation method

The **GetSaturation** method gets the current hue value.

Syntax

```
HRESULT GetSaturation (double* sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| sat | out | The current sat value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The sat parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.10.4 IBMDSwitcherInputColor::SetSaturation method

The **SetSaturation** method sets the hue value.

Syntax

```
HRESULT SetSaturation (double sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------|
| sat | in | The desired saturation value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

2.3.10.5 IBMDSwitcherInputColor::GetLuma method

The **GetLuma** method gets the current luminance value.

Syntax

```
HRESULT GetLuma (double* luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------------|
| luma | out | The current luminance value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The luma parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.10.6 IBMDSwitcherInputColor::SetLuma method

The **SetLuma** method sets the luminance value.

Syntax

```
HRESULT SetLuma (double luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------------|
| luma | in | The desired luminance value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.10.7 IBMDSwitcherInputColor::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherInputColor** object. Pass an object implementing the **IBMDSwitcherInputColorCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputColorCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputColorCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.10.8 IBMDSwitcherInputColor::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputColorCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputColorCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.11 IBMDSwitcherInputColorCallback Interface

The **IBMDSwitcherInputColorCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherInputColor** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------|----------------------------|---|
| IBMDSwitcherInputColor | IID_IBMDSwitcherInputColor | An IBMDSwitcherInputColorCallback object interface is installed with IBMDSwitcherInputColor::AddCallback and removed with IBMDSwitcherInputColor::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 2 Basic Switcher Control

2.3.11.1 IBMDSwitcherInputColorCallback::Notify method

The **Notify** method is called when **IBMDSwitcherInputColor** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputColorEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherInputColorEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.12 IBMDSwitcherInputAux Interface

The **IBMDSwitcherInputAux** object interface is used for managing an auxiliary output port.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------|-----------------------|---|
| IBMDSwitcherInput | IID_IBMDSwitcherInput | An IBMDSwitcherInputAux object interface can be obtained with IBMDSwitcherInput::QueryInterface . |

| Public Member Functions | |
|--------------------------|---|
| Method | Description |
| GetInputSource | Get the selected input source. |
| SetInputSource | Select the input source. |
| GetInputAvailabilityMask | Get the corresponding BMDSwitcherInputAvailability bit value for auxiliary port. |
| AddCallback | Add an aux callback. |
| RemoveCallback | Remove an aux callback. |

SECTION 2 Basic Switcher Control

2.3.12.1 IBMDSwitcherInputAux::GetInputSource method

The **GetInputSource** method returns the currently selected input source.

Syntax

```
HRESULT GetInputSource (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| inputId | out | The BMDSwitcherInputId of the selected input source. |

Return Values

| Value | Description |
|-----------|----------------------------|
| S_OK | Success. |
| E_POINTER | Invalid inputId parameter. |

SECTION 2 Basic Switcher Control

2.3.12.2 IBMDSwitcherInputAux::SetInputSource method

The **SetInputSource** method selects an input source for this auxiliary port.

Syntax

```
HRESULT SetInputSource (BMDSwitcherInputId inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | in | The BMDSwitcherInputId of the desired input source. |

Return Values

| Value | Description |
|--------------|----------------------------|
| S_OK | Success. |
| E_INVALIDARG | Invalid inputId parameter. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.12.3 IBMDSwitcherInputAux::GetInputAvailabilityMask method

The GetInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for this auxiliary port. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value to determine whether an input is available for use as a source for this auxiliary port.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|---|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

SECTION 2 Basic Switcher Control

2.3.12.4 IBMDSwitcherInputAux::AddCallback method

The AddCallback method configures a callback to be called when events occur for an **IBMDSwitcherInputAux** object. Pass an object implementing the **IBMDSwitcherInputAuxCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputAuxCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputAuxCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.12.5 IBMDSwitcherInputAux::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputAuxCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputAuxCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.13 IBMDSwitcherInputAuxCallback Interface

The **IBMDSwitcherInputAuxCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherInputAux** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------|--------------------------|---|
| IBMDSwitcherInputAux | IID_IBMDSwitcherInputAux | An IBMDSwitcherInputAuxCallback object interface is installed with IBMDSwitcherInputAux::AddCallback and removed with IBMDSwitcherInputAux::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 2 Basic Switcher Control

2.3.13.1 IBMDSwitcherInputAuxCallback::Notify method

The **Notify** method is called when **IBMDSwitcherInputAux** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputAuxEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherInputAuxEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.14 **IBMDSwitcherMultiViewIteator Interface**

The **IBMDSwitcherMultiViewIteator** is used to enumerate the available MultiViews.

A reference to an **IBMDSwitcherMultiViewIteator** object interface may be obtained from an **IBMDSwitcher** object interface using the **CreaterIteator** method. Pass **IID_IBMDSwitcherMultiViewIteator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::CreaterIteator can return an IBMDSwitcherMultiViewIteator object interface. |

Public Member Functions

| Method | Description |
|--------|--|
| Next | Returns a pointer to the next IBMDSwitcherMultiView object interface. |

SECTION 2 Basic Switcher Control

2.3.14.1 IBMDSwitcherMultiViewIterator::Next method

The **Next** method returns the next available **IBMDSwitcherMultiView** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherMultiView** multiView);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| multiView | out | IBMDSwitcherMultiView object interface. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherMultiView objects available. |
| E_POINTER | The multiView parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15 IBMDSwitcherMultiView Interface

The **IBMDSwitcherMultiView** object interface is used for accessing control functions of a MultiView output, such as setting up the layout format, or routing different inputs to windows.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------|-----------------------------------|---|
| IBMDSwitcherMultiViewIterator | IID_IBMDSwitcherMultiViewIterator | An IBMDSwitcherMultiView object will be returned after a successful call to IBMDSwitcherMultiViewIterator::Next method. |

Public Member Functions

| Method | Description |
|--------------------------|--|
| GetLayout | Get the current layout format. |
| SetLayout | Set layout format. |
| GetWindowInput | Get current input routing of a window. |
| SetWindowInput | Set input routing of a window. |
| GetWindowCount | Get number of windows available. |
| GetInputAvailabilityMask | Get the corresponding BMDSwitcherInputAvailability bit value for MultiView. |
| CanRouteInputs | Determine if this MultiView supports custom input-to-window routing. |
| AddCallback | Add a MultiView callback. |
| RemoveCallback | Remove a MultiView callback. |

SECTION 2 Basic Switcher Control

2.3.15.1 IBMDSwitcherMultiView::GetLayout method

The **GetLayout** method returns the current layout format.

Syntax

```
HRESULT GetLayout (BMDSwitcherMultiViewLayout* layout);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| layout | out | Current layout format as a BMDSwitcherMultiViewLayout . |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The layout parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.2 IBMDSwitcherMultiView::SetLayout method

The **SetLayout** method sets the layout format.

Syntax

```
HRESULT SetLayout (BMDSwitcherMultiViewLayout* layout);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| layout | in | Desired layout format in BMDSwitcherMultiViewLayout . |

Return Values

| Value | Description |
|--------------|---------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | Invalid layout parameter. |

SECTION 2 Basic Switcher Control

2.3.15.3 IBMDSwitcherMultiView::GetWindowInput method

The **GetWindowInput** method returns the current input source routed to the specified window.

Syntax

```
HRESULT GetWindowInput (uint32_t window, BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| window | in | Zero-based window index. |
| inputId | out | Input source as a BMDSwitcherInputId |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The window parameter is invalid. |
| E_POINTER | The inputId parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.4 IBMDSwitcherMultiView::SetWindowInput method

The **SetWindowInput** method routes an input source to the specified window.

Syntax

```
HRESULT SetWindowInput (uint32_t window, BMDSwitcherInputId inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| window | in | Zero-based window index. |
| inputId | in | BMDSwitcherInputId input source. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The window and/or inputId parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.5 IBMDSwitcherMultiView::GetWindowCount method

The **GetWindowCount** method returns the total number of windows available to this MultiView.

Syntax

```
HRESULT GetWindowCount (uint32_t* windowCount);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|--------------------------|
| windowCount | out | Total number of windows. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The windowCount parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.6 IBMDSwitcherMultiView::GetInputAvailabilityMask method

The **GetInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for this MultiView. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value to determine whether an input is available for viewing in a window.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|---|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

SECTION 2 Basic Switcher Control

2.3.15.7 IBMDSwitcherMultiView::CanRouteInputs method

The **CanRouteInputs** method returns whether this MultiView has custom input-to-window routing capability. This feature allows custom selection of input sources on each window, whereas without this feature the configuration is static and the window input sources cannot be changed. If the MultiView has no such capability, any call to **SetWindowInput** will fail.

Syntax

```
HRESULT CanRouteInputs (boolean* canRoute);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| canRoute | out | Boolean that indicates if this MultiView is capable of custom input-to-window routing. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The canRoute parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.8 IBMDSwitcherMultiView::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMultiView** object. Pass an object implementing the **IBMDSwitcherMultiViewCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMultiViewCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMultiViewCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.15.9 IBMDSwitcherMultiView::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMultiViewCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMultiViewCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.16 IBMDSwitcherMultiViewCallback Interface

The **IBMDSwitcherMultiViewCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherMultiView** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|--|
| IBMDSwitcherMultiView | IID_IBMDSwitcherMultiView | An IBMDSwitcherMultiViewCallback object interface is installed with IBMDSwitcherMultiView::AddCallback and removed with IBMDSwitcherMultiView::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 2 Basic Switcher Control

2.3.16.1 IBMDSwitcherMultiViewCallback::Notify method

The **Notify** method is called when **IBMDSwitcherMultiView** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMultiViewEventType eventType, int32_t window);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherMultiViewEventType that describes the type of event that has occurred. |
| window | in | This parameter is only valid when eventType is bmdSwitcherMultiViewEventTypeWindowChanged , it specifies the window index that was changed. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 2 Basic Switcher Control

2.3.17 IBMDSwitcherSerialPortIterator Interface

The **IBMDSwitcherSerialPortIterator** object interface is used to enumerate the available serial ports on the switcher.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|--|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::CreateIterator returns an IBMDSwitcherSerialPortIterator interface when the IID_IBMDSwitcherSerialPortIterator IID is specified. |

Public Member Functions

| Method | Description |
|--------|---|
| Next | Returns the next available serial port. |

SECTION 2 Basic Switcher Control

2.3.17.1 IBMDSwitcherSerialPortIterator::Next method

The **Next** method returns the next available **IBMDSwitcherSerialPort** object interface.

The **IBMDSwitcherSerialPort** object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherSerialPort** serialPort);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| serialPort | out | IBMDSwitcherSerialPort object interface. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| S_FALSE | No (more) serial ports available. |
| E_POINTER | The serialPort parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.18 IBMDSwitcherSerialPort Interface

The **IBMDSwitcherSerialPort** object interface is used for managing a serial port on the switcher.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------------|--|---|
| IBMDSwitcherSerialPortIterator | IID_ IBMDSwitcherSerialPortIterator | IBMDSwitcherSerialPortIterator::Next returns IBMDSwitcherSerialPort interfaces for each available serial port of a switcher device. |

Public Member Functions

| Method | Description |
|---------------------|---|
| SetFunction | Set the function of the serial port using a BMDSwitcherSerialPortFunction . |
| GetFunction | Returns the function of the serial port as a BMDSwitcherSerialPortFunction . |
| DoesSupportFunction | Check if a given BMDSwitcherSerialPortFunction is supported by the switcher. |
| AddCallback | Add a serial port callback. |
| RemoveCallback | Remove a serial port callback. |

SECTION 2 Basic Switcher Control

2.3.18.1 IBMDSwitcherSerialPort::SetFunction method

The **SetFunction** method sets the function of the serial port.

Syntax

```
HRESULT SetFunction (BMDSwitcherSerialPortFunction function);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| function | in | The function to which the serial port should be set. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The function parameter is not a valid serial port function. |

SECTION 2 Basic Switcher Control

2.3.18.2 IBMDSwitcherSerialPort::GetFunction method

The **GetFunction** method returns the current function of the serial port.

Syntax

```
HRESULT GetFunction (BMDSwitcherSerialPortFunction* function);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| function | out | A BMDSwitcherSerialPortFunction describing which function the serial port is currently set to. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| E_POINTER | The function parameter is not a valid pointer. |

SECTION 2 Basic Switcher Control

2.3.18.3 IBMDSwitcherSerialPort::DoesSupportFunction method

The **DoesSupportFunction** method is used to determine if a given serial port function is supported by the switcher.

Syntax

```
HRESULT DoesSupportFunction (BMDSwitcherSerialPortFunction function, boolean* supported);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| function | in | The serial port function being queried. |
| supported | out | Boolean value describing whether the specified function is supported by the switcher. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_POINTER | The supported parameter is not a valid pointer. |
| E_INVALIDARG | The function parameter is not a valid BMDSwitcherSerialPortFunction . |

SECTION 2 Basic Switcher Control

2.3.18.4 IBMDSwitcherSerialPort::AddCallback method

The **AddCallback** method configures a callback to be called when a switcher serial port property changes, such as a change in the serial port function.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherSerialPortCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherSerialPortCallback interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.18.5 IBMDSwitcherSerialPort::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherSerialPortCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|----------------------------|
| callback | in | Callback object to remove. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 2 Basic Switcher Control

2.3.19 IBMDSwitcherSerialPortCallback Interface

The **IBMDSwitcherSerialPortCallback** object interface is a callback class which is called when a switcher serial port event occurs, such as a change in the serial port function. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------|----------------------------|--|
| IBMDSwitcherSerialPort | IID_IBMDSwitcherSerialPort | An IBMDSwitcherSerialPortCallback interface may be installed with IBMDSwitcherSerialPort::AddCalback |

Public Member Functions

| Method | Description |
|--------|--|
| Notify | A Switcher Serial Port event occurred, such as a change in the serial port function. |

SECTION 2 Basic Switcher Control

2.3.19.1 IBMDSwitcherSerialPortCallback::Notify method

The **Notify** method is called when **IBMDSwitcherSerialPort** events occur, such as a change in the serial port function.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherSerialPortEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherSerialPortEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_FAIL | Failure. |
| S_OK | Success. |

SECTION 3 Advanced Transitions

3 Advanced Transitions

Transitions can be more advanced than making a simple cut between sources. This API provides a plethora of methods to enhance how a transition is performed.

3.1 Data Types

3.1.1 Mix Parameters Event Type

BMDSwitcherTransitionMixParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionMixParameters**.

bmdSwitcherTransitionMixParametersEventTypeRateChanged The rate changed.

3.1.2 Dip Parameters Event Type

BMDSwitcherTransitionDipParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionDipParameters**.

bmdSwitcherTransitionDipParametersEventTypeRateChanged The rate changed.

bmdSwitcherTransitionDipParametersEventTypeInputDipChanged The dip input changed.

3.1.3 Wipe Parameters Event Type

BMDSwitcherTransitionWipeParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionWipeParameters**.

bmdSwitcherTransitionWipeParametersEventTypeRateChanged The rate changed.

bmdSwitcherTransitionWipeParametersEventTypePatternChanged The pattern changed.

bmdSwitcherTransitionWipeParametersEventTypeBorderSizeChanged The border size changed.

bmdSwitcherTransitionWipeParametersEventTypeInputBorderChanged The border input changed.

bmdSwitcherTransitionWipeParametersEventTypeSymmetryChanged The symmetry changed.

bmdSwitcherTransitionWipeParametersEventTypeSoftnessChanged The softness changed.

bmdSwitcherTransitionWipeParametersEventTypeHorizontalOffsetChanged The horizontal offset changed.

bmdSwitcherTransitionWipeParametersEventTypeVerticalOffsetChanged The vertical offset changed.

bmdSwitcherTransitionWipeParametersEventTypeReverseChanged The reverse flag changed.

bmdSwitcherTransitionWipeParametersEventTypeFlipFlopChanged The flip flop flag changed.

SECTION 3 Advanced Transitions

3.1.4 DVE Parameters Event Type

BMDSwitcherTransitionDVEParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionDVEParameters**.

| | |
|--|----------------------------------|
| bmdSwitcherTransitionDVEParametersEventTypeRateChanged | The rate changed. |
| bmdSwitcherTransitionDVEParametersEventTypeLogoRateChanged | The logo rate changed. |
| bmdSwitcherTransitionDVEParametersEventTypeReverseChanged | The reverse flag changed. |
| bmdSwitcherTransitionDVEParametersEventTypeFlipFlopChanged | The flip flop flag changed. |
| bmdSwitcherTransitionDVEParametersEventTypeStyleChanged | The style changed. |
| bmdSwitcherTransitionDVEParametersEventTypeInputFillChanged | The fill input changed. |
| bmdSwitcherTransitionDVEParametersEventTypeInputCutChanged | The cut input changed. |
| bmdSwitcherTransitionDVEParametersEventTypeEnableKeyChanged | The enable key flag changed. |
| bmdSwitcherTransitionDVEParametersEventTypePreMultipliedChanged | The pre-multiplied flag changed. |
| bmdSwitcherTransitionDVEParametersEventTypeClipChanged | The clip changed. |
| bmdSwitcherTransitionDVEParametersEventTypeGainChanged | The gain changed. |
| bmdSwitcherTransitionDVEParametersEventTypeInverseChanged | The inverse flag changed. |

SECTION 3 Advanced Transitions

3.1.5 Stinger Parameters Event Type

BMDSwitcherTransitionStingerParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionStingerParameters**.

| | |
|--|----------------------------------|
| bmdSwitcherTransitionStingerParametersEventTypeSourceChanged | The source changed. |
| bmdSwitcherTransitionStingerParametersEventTypePreMultipliedChanged | The pre-multiplied flag changed. |
| bmdSwitcherTransitionStingerParametersEventTypeClipChanged | The clip changed. |
| bmdSwitcherTransitionStingerParametersEventTypeGainChanged | The gain changed. |
| bmdSwitcherTransitionStingerParametersEventTypeInverseChanged | The inverse flag changed. |
| bmdSwitcherTransitionStingerParametersEventTypePrerollChanged | The preroll changed. |
| bmdSwitcherTransitionStingerParametersEventTypeClipDurationChanged | The clip duration changed. |
| bmdSwitcherTransitionStingerParametersEventTypeTriggerPointChanged | The trigger point changed. |
| bmdSwitcherTransitionStingerParametersEventTypeMixRateChanged | The mix rate changed. |

3.1.6 Transition Parameters Event Type

BMDSwitcherTransitionParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionParameters**.

| | |
|---|--|
| bmdSwitcherTransitionParametersEventTypeTransitionStyleChanged | The transition style changed. |
| bmdSwitcherTransitionParametersEventTypeNextTransitionStyleChanged | The next transition style changed. |
| bmdSwitcherTransitionParametersEventTypeTransitionSelectionChanged | The transition selection changed. |
| bmdSwitcherTransitionParametersEventTypeNextTransitionSelectionChanged | The next transition selection changed. |

SECTION 3 Advanced Transitions

3.1.7 Transition Style

BMDSwitcherTransitionStyle enumerates the possible transition styles, used by the **IBMDSwitcherTransitionParameters** object interface.

| | |
|--|----------------|
| bmdSwitcherTransitionStyleMix | Mix style. |
| bmdSwitcherTransitionStyleDip | Dip style. |
| bmdSwitcherTransitionStyleWipe | Wipe style. |
| bmdSwitcherTransitionStyleDVE | DVE style. |
| bmdSwitcherTransitionStyleStinger | Stinger style. |

3.1.8 Transition Selection

BMDSwitcherTransitionSelection is a bit set that enumerates what to include in a transition. This type is used by **IBMDSwitcherTransitionParameters** and **IBMDSwitcherKey** object interfaces.

| | |
|---|-----------------------------------|
| bmdSwitcherTransitionSelectionBackground | Include background in transition. |
| bmdSwitcherTransitionSelectionKey1 | Include key 1 in transition. |
| bmdSwitcherTransitionSelectionKey2 | Include key 2 in transition. |
| bmdSwitcherTransitionSelectionKey3 | Include key 3 in transition. |
| bmdSwitcherTransitionSelectionKey4 | Include key 4 in transition. |

SECTION 3 Advanced Transitions

3.1.9 DVE Transition Style

BMDSwitcherDVETransitionStyle enumerates the possible transition styles.

This type is used by the **IBMDSwitcherTransitionDVEParameters** object interface.

| | |
|--|-------------------------------------|
| bmdSwitcherDVETransitionStyleSwooshTopLeft | Top left swoosh. |
| bmdSwitcherDVETransitionStyleSwooshTop | Top swoosh. |
| bmdSwitcherDVETransitionStyleSwooshTopRight | Top right swoosh. |
| bmdSwitcherDVETransitionStyleSwooshLeft | Left swoosh. |
| bmdSwitcherDVETransitionStyleSwooshRight | Right swoosh. |
| bmdSwitcherDVETransitionStyleSwooshBottomLeft | Bottom left swoosh. |
| bmdSwitcherDVETransitionStyleSwooshBottom | Bottom swoosh. |
| bmdSwitcherDVETransitionStyleSwooshBottomRight | Bottom right swoosh. |
| bmdSwitcherDVETransitionStyleSpinCWTopLeft | Top left clockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCWTopRight | Top right clockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCWBottomLeft | Bottom left clockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCWBottomRight | Bottom right clockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCCWTopLeft | Top left counterclockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCCWTopRight | Top right counterclockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCCWBottomLeft | Bottom left counterclockwise spin. |
| bmdSwitcherDVETransitionStyleSpinCCWBottomRight | Bottom right counterclockwise spin. |
| bmdSwitcherDVETransitionStyleSqueezeTopLeft | Top left squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeTop | Top squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeTopRight | Top right squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeLeft | Left squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeRight | Right squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeBottomLeft | Bottom left squeeze. |

SECTION 3 Advanced Transitions

| | |
|--|--------------------------------|
| bmdSwitcherDVETransitionStyleSqueezeBottom | Bottom squeeze. |
| bmdSwitcherDVETransitionStyleSqueezeBottomRight | Bottom right squeeze. |
| bmdSwitcherDVETransitionStylePushTopLeft | Top left push. |
| bmdSwitcherDVETransitionStylePushTop | Top push. |
| bmdSwitcherDVETransitionStylePushTopRight | Top right push. |
| bmdSwitcherDVETransitionStylePushLeft | Left push. |
| bmdSwitcherDVETransitionStylePushRight | Right push. |
| bmdSwitcherDVETransitionStylePushBottomLeft | Bottom left push. |
| bmdSwitcherDVETransitionStylePushBottom | Bottom push. |
| bmdSwitcherDVETransitionStylePushBottomRight | Bottom right push. |
| bmdSwitcherDVETransitionStyleGraphicCWSpin | Clockwise graphic spin. |
| bmdSwitcherDVETransitionStyleGraphicCCWSpin | Counterclockwise graphic spin. |
| bmdSwitcherDVETransitionStyleGraphicLogoWipe | Graphic logo wipe. |

3.1.10 Stinger Transition Source

BMDSwitcherStingerTransitionSource enumerates the possible transition sources. This type is used by the **IBMDSwitcherTransitionStingerParameters** object interface.

| | |
|---|-----------------|
| bmdSwitcherStingerTransitionSourceMediaPlayer1 | Media player 1. |
| bmdSwitcherStingerTransitionSourceMediaPlayer2 | Media player 2. |
| bmdSwitcherStingerTransitionSourceMediaPlayer3 | Media player 3. |
| bmdSwitcherStingerTransitionSourceMediaPlayer4 | Media player 4. |
| bmdSwitcherStingerTransitionSourceNone | None. |

SECTION 3 Advanced Transitions

3.2 Interface Reference

3.2.1 IBMDSwitcherTransitionMixParameters Interface

The IBMDSwitcherTransitionMixParameters object interface is used for manipulating transition settings specific to mix parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|---|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherTransitionMixParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

Public Member Functions

| Method | Description |
|----------------|-----------------------|
| GetRate | Get the current rate. |
| SetRate | Set the rate. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.1.1 IBMDSwitcherTransitionMixParameters::GetRate method

The **GetRate** method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-------------------|
| frames | out | The current rate. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.1.2 IBMDSwitcherTransitionMixParameters::SetRate method

The **SetRate** method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------|
| frames | in | The desired rate in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.1.3 IBMDSwitcherTransitionMixParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionMixParameters** object. Pass an object implementing the **IBMDSwitcherTransitionMixParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionMixParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionMixParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.1.4 IBMDSwitcherTransitionMixParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionMixParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionMixParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.2 IBMDSwitcherTransitionMixParametersCallback Interface

The **IBMDSwitcherTransitionMixParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionMixParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------------|---|--|
| IBMDSwitcherTransitionMixParameters | IID_ IBMDSwitcherTransitionMixParameters | An IBMDSwitcherTransitionMixParametersCallback object interface is installed with IBMDSwitcherTransitionMixParameters::AddCallback and removed with IBMDSwitcherTransitionMixParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.2.1 IBMDSwitcherTransitionMixParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionMixParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionMixParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherTransitionMixParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.3 IBMDSwitcherTransitionDipParameters Interface

The **IBMDSwitcherTransitionDipParameters** object interface is used for manipulating transition settings specific to dip parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|---|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherTransitionDipParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

Public Member Functions

| Method | Description |
|----------------|-----------------------|
| GetRate | Get the current rate. |
| SetRate | Set the rate. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.3.1 IBMDSwitcherTransitionDipParameters::GetRate method

The **GetRate** method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-------------------|
| frames | out | The current rate. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.3.2 IBMDSwitcherTransitionDipParameters::SetRate method

The **SetRate** method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------|
| frames | in | The desired rate in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.3.3 IBMDSwitcherTransitionDipParameters::GetInputDip method

The **GetInputDip** method returns the current dip input.

Syntax

```
HRESULT GetInputDip (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | out | The current dip input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.3.4 IBMDSwitcherTransitionDipParameters::SetInputDip method

The **SetInputDip** method sets the dip input.

Syntax

```
HRESULT SetInputDip (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | in | The desired dip input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

3.2.3.5 **IBMDSwitcherTransitionDipParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionDipParameters** object. Pass an object implementing the **IBMDSwitcherTransitionDipParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDipParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionDipParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.3.6 IBMDSwitcherTransitionDipParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionDipParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionDipParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.4 IBMDSwitcherTransitionDipParametersCallback Interface

The **IBMDSwitcherTransitionDipParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionDipParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------------|---|--|
| IBMDSwitcherTransitionDipParameters | IID_IBMDSwitcherTransitionDipParameters | An IBMDSwitcherTransitionDipParametersCallback object interface is installed with IBMDSwitcherTransitionDipParameters::AddCallback and removed with IBMDSwitcherTransitionDipParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.4.1 IBMDSwitcherTransitionDipParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionDipParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionDipParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherTransitionDipParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.5 IBMDSwitcherTransitionWipeParametersCallback Interface

The **IBMDSwitcherTransitionWipeParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionWipeParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------------------|--|--|
| IBMDSwitcherTransitionWipeParameters | IID_IBMDSwitcherTransitionWipeParameters | IBMDSwitcherTransitionWipeParametersCallback object interface is installed with IBMDSwitcherTransitionWipeParameters::AddCallback and removed with IBMDSwitcherTransitionWipeParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.5.1 IBMDSwitcherTransitionWipeParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionWipeParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherTransitionWipeParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | IBMDSwitcherTransitionWipeParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6 IBMDSwitcherTransitionWipeParameters Interface

The **IBMDSwitcherTransitionWipeParameters** object interface is used for manipulating transition settings specific to wipe parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|--|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherTransitionWipeParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

Public Member Functions

| Method | Description |
|---------------------|------------------------------------|
| GetRate | Get the current rate. |
| SetRate | Set the rate. |
| GetPattern | Get the current pattern. |
| SetPattern | Set the pattern. |
| GetBorderSize | Get the current border size. |
| SetBorderSize | Set the border size. |
| GetInputBorder | Get the current border input. |
| SetInputBorder | Set the border input. |
| GetSymmetry | Get the current symmetry. |
| SetSymmetry | Set the symmetry. |
| GetSoftness | Get the current softness. |
| SetSoftness | Set the softness. |
| GetHorizontalOffset | Get the current horizontal offset. |
| SetHorizontalOffset | Set the horizontal offset. |

SECTION 3 Advanced Transitions

| Public Member Functions | |
|-------------------------|----------------------------------|
| Method | Description |
| GetVerticalOffset | Get the current vertical offset. |
| SetVerticalOffset | Set the vertical offset. |
| GetReverse | Get the current reverse flag. |
| SetReverse | Set the reverse flag. |
| GetFlipFlop | Get the current flip flop flag. |
| SetFlipFlop | Set the flip flop flag. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.6.1 IBMDSwitcherTransitionWipeParameters::GetRate method

The **GetRate** method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-------------------|
| frames | out | The current rate. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.2 IBMDSwitcherTransitionWipeParameters::SetRate method

The **SetRate** method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------|
| frames | in | The desired rate in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.3 IBMDSwitcherTransitionWipeParameters::GetPattern method

The **GetPattern** method returns the current pattern style.

Syntax

```
HRESULT GetPattern (BMDSwitcherPatternStyle* pattern);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------|
| pattern | out | The current pattern. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The pattern parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.4 IBMDSwitcherTransitionWipeParameters::SetPattern method

The **SetPattern** method sets the rate in frames.

Syntax

```
HRESULT SetPattern (BMDSwitcherPatternStyle pattern);
```

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------|
| frames | in | The desired pattern. |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The pattern parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.5 IBMDSwitcherTransitionWipeParameters::GetBorderSize method

The **GetBorderSize** method returns the current border size.

Syntax

```
HRESULT GetBorderSize (double* size);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------|
| size | out | The current border size. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The size parameter is invalid. |

3.2.6.6 IBMDSwitcherTransitionWipeParameters::SetBorderSize method

The **SetBorderSize** method sets the border size.

Syntax

```
HRESULT SetBorderSize (double size);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------|
| size | in | The desired border size. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.7 IBMDSwitcherTransitionWipeParameters::GetInputBorder method

The **GetInputBorder** method returns the current border input.

Syntax

```
HRESULT GetInputBorder (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|---------------------------|
| input | out | The current border input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.8 IBMDSwitcherTransitionWipeParameters::SetInputBorder method

The **SetInputBorder** method sets the border input.

Syntax

```
HRESULT SetInputBorder (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|---------------------------|
| input | in | The desired border input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

3.2.6.9 IBMDSwitcherTransitionWipeParameters::GetSymmetry method

The **GetSymmetry** method returns the current symmetry.

Syntax

```
HRESULT GetSymmetry (double* symmetry);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------|
| symmetry | out | The current symmetry. |

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

3.2.6.10 IBMDSwitcherTransitionWipeParameters::SetSymmetry method

The **SetSymmetry** method sets the symmetry.

Syntax

```
HRESULT SetSymmetry (double symmetry);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------|
| symmetry | in | The desired symmetry. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.11 IBMDSwitcherTransitionWipeParameters::GetSoftness method

The **GetSoftness** method returns the current softness.

Syntax

```
HRESULT GetSoftness (double* soft);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| soft | out | The current softness. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The soft parameter is invalid. |

3.2.6.12 IBMDSwitcherTransitionWipeParameters::SetSoftness method

The **SetSoftness** method sets the softness.

Syntax

```
HRESULT SetSoftness (double soft);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| soft | in | The desired softness. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

3.2.6.13 IBMDSwitcherTransitionWipeParameters::GetHorizontalOffset method

The **GetHorizontalOffset** method returns the current horizontal offset.

Syntax

HRESULT GetHorizontalOffset (double* hOffset);

Parameters

| Name | Direction | Description |
|---------|-----------|--------------------------------|
| hOffset | out | The current horizontal offset. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The hOffset parameter is invalid. |

3.2.6.14 IBMDSwitcherTransitionWipeParameters::SetHorizontalOffset method

The **SetHorizontalOffset** method sets the horizontal offset.

Syntax

HRESULT SetHorizontalOffset (double hOffset);

Parameters

| Name | Direction | Description |
|---------|-----------|--------------------------------|
| hOffset | in | The desired horizontal offset. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.15 IBMDSwitcherTransitionWipeParameters::GetVerticalOffset method

The **GetVerticalOffset** method returns the current vertical offset.

Syntax

```
HRESULT GetVerticalOffset (double* vOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|------------------------------|
| vOffset | out | The current vertical offset. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The vOffset parameter is invalid. |

3.2.6.16 IBMDSwitcherTransitionWipeParameters::SetVerticalOffset method

The **SetVerticalOffset** method sets the vertical offset.

Syntax

```
HRESULT SetVerticalOffset (double vOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|------------------------------|
| vOffset | in | The desired vertical offset. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.17 IBMDSwitcherTransitionWipeParameters::GetReverse method

The **GetReverse** method returns the current reverse flag.

Syntax

```
HRESULT GetReverse (boolean* reverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| reverse | out | The current reverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The reverse parameter is invalid. |

3.2.6.18 IBMDSwitcherTransitionWipeParameters::SetReverse method

The **SetReverse** method sets the reverse flag.

Syntax

```
HRESULT SetReverse (boolean reverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| reverse | in | The desired reverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.19 IBMDSwitcherTransitionWipeParameters::GetFlipFlop method

The **GetFlipFlop** method returns the current flip flop flag.

Syntax

```
HRESULT GetFlipFlop (boolean* flipflop);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| flipflop | out | The current flip flop flag. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The flipflop parameter is invalid. |

3.2.6.20 IBMDSwitcherTransitionWipeParameters::SetFlipFlop method

The **SetFlipFlop** method sets the flip flop flag.

Syntax

```
HRESULT SetFlipFlop (boolean flipflop);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| flipflop | in | The desired flip flop flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.6.21 IBMDSwitcherTransitionWipeParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionWipeParameters** object. Pass an object implementing the **IBMDSwitcherTransitionWipeParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionWipeParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherTransitionWipeParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.6.22 IBMDSwitcherTransitionWipeParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionWipeParametersCallback* allback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherTransitionWipeParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7 IBMDSwitcherTransitionDVEParameters Interface

The **IBMDSwitcherTransitionDVEParameters** object interface is used for manipulating transition settings specific to DVE parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|---|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherTransitionDVEParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

| Public Member Functions | |
|-------------------------|---------------------------------|
| Method | Description |
| GetRate | Get the current rate. |
| SetRate | Set the rate. |
| GetLogoRate | Get the current logo rate. |
| SetLogoRate | Set the logo rate. |
| GetReverse | Get the current reverse flag. |
| SetReverse | Set the reverse flag. |
| GetFlipFlop | Get the current flip flop flag. |
| SetFlipFlop | Set the flip flop flag. |
| GetStyle | Get the current style. |
| SetStyle | Set the style. |
| GetInputFill | Get the current fill input. |
| SetInputFill | Set the fill input. |
| GetInputCut | Get the current cut input. |
| SetInputCut | Set the cut input. |

SECTION 3 Advanced Transitions

| Public Member Functions | |
|------------------------------|---|
| Method | Description |
| GetFillInputAvailabilityMask | Get the availability mask for the fill of this input. |
| GetCutInputAvailabilityMask | Get the availability mask for the cut of this input. |
| GetEnableKey | Get the current enable key. |
| SetEnableKey | Set the enable key. |
| GetPreMultiplied | Get the current pre-multiplied flag. |
| SetPreMultiplied | Set the pre-multiplied flag. |
| GetClip | Get the current clip value. |
| SetClip | Set the clip value. |
| GetGain | Get the current gain. |
| SetGain | Set the gain. |
| GetInverse | Get the current inverse flag. |
| SetInverse | Set the inverse flag. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.7.1 IBMDSwitcherTransitionDVEParameters::GetRate method

The **GetRate** method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-------------------|
| frames | out | The current rate. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.2 IBMDSwitcherTransitionDVEParameters::SetRate method

The **SetRate** method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------|
| frames | in | The desired rate in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.3 IBMDSwitcherTransitionDVEParameters::GetLogoRate method

The **GetLogoRate** method returns the current logo rate in frames.

Syntax

```
HRESULT GetLogoRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|------------------------|
| frames | out | The current logo rate. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.4 IBMDSwitcherTransitionDVEParameters::SetLogoRate method

The **SetLogoRate** method sets the logo rate in frames.

Syntax

```
HRESULT SetLogoRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------------------|
| frames | in | The desired logo rate in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The frames parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.5 IBMDSwitcherTransitionDVEParameters::GetReverse method

The **GetReverse** method returns the current reverse flag.

Syntax

```
HRESULT GetReverse (boolean* reverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| reverse | out | The current reverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The reverse parameter is invalid. |

3.2.7.6 IBMDSwitcherTransitionDVEParameters::SetReverse method

The **SetReverse** method sets the reverse flag.

Syntax

```
HRESULT SetReverse (boolean reverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| reverse | in | The desired reverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.7.7 IBMDSwitcherTransitionDVEParameters::GetFlipFlop method

The **GetFlipFlop** method returns the current flip flop flag.

Syntax

```
HRESULT GetFlipFlop (boolean* flipflop);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| flipflop | out | The current flip flop flag. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The flipflop parameter is invalid. |

3.2.7.8 IBMDSwitcherTransitionDVEParameters::SetFlipFlop method

The **SetFlipFlop** method sets the flip flop flag.

Syntax

```
HRESULT SetFlipFlop (boolean flipflop);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| flipflop | in | The desired flip flop flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.7.9 IBMDSwitcherTransitionDVEParameters::GetStyle method

The **GetStyle** method returns the current style.

Syntax

```
HRESULT GetStyle (BMDSwitcherDVETransitionStyle* style);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------------|
| style | out | The current style. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The style parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.10 IBMDSwitcherTransitionDVEParameters::SetStyle method

The **SetStyle** method sets the style.

Syntax

```
HRESULT SetStyle (BMDSwitcherDVETransitionStyle style);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------------|
| style | in | The desired style. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The style parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.11 IBMDSwitcherTransitionDVEParameters::GetInputFill method

The **GetInputFill** method returns the current fill input.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------|
| input | out | The current fill input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.12 IBMDSwitcherTransitionDVEParameters::SetInputFill method

The **SetInputFill** method sets the fill input.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------|
| input | in | The desired fill input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.13 IBMDSwitcherTransitionDVEParameters::GetInputCut method

The **GetInputCut** method returns the current cut input.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | out | The current cut input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.14 IBMDSwitcherTransitionDVEParameters::SetInputCut method

The **SetInputCut** method sets the cut input.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | in | The desired cut input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.15 IBMDSwitcherTransitionDVEParameters::GetFillInputAvailabilityMask method

The **GetFillInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for fill inputs available to this DVE transition. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this DVE transition.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

3.2.7.16 IBMDSwitcherTransitionDVEParameters::GetCutInputAvailabilityMask method

The **GetCutInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this DVE transition. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this DVE transition.

Syntax

HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

SECTION 3 Advanced Transitions

3.2.7.17 IBMDSwitcherTransitionDVEParameters::GetEnableKey method

The **GetEnableKey** method returns the current enableKey flag.

Syntax

```
HRESULT GetEnableKey (boolean* enableKey);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------|
| enableKey | out | The current enableKey flag. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The enableKey parameter is invalid. |

3.2.7.18 IBMDSwitcherTransitionDVEParameters::SetEnableKey method

The **SetEnableKey** method sets the enableKey flag.

Syntax

```
HRESULT SetEnableKey (boolean enableKey);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------|
| enableKey | in | The desired enableKey flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

3.2.7.19 IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method

The **GetPreMultiplied** method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | out | The current pre-multiplied flag. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The preMultiplied parameter is invalid. |

3.2.7.20 IBMDSwitcherTransitionDVEParameters::SetPreMultiplied method

The **SetPreMultiplied** method sets the pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | in | The desired pre-multiplied flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.7.21 IBMDSwitcherTransitionDVEParameters::GetClip method

The **GetClip** method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | out | The current clip value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The clip parameter is invalid. |

3.2.7.22 IBMDSwitcherTransitionDVEParameters::SetClip method

The **SetClip** method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | in | The desired clip value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.7.23 IBMDSwitcherTransitionDVEParameters::GetGain method

The **GetGain** method returns the current clip.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | out | The current gain. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

3.2.7.24 IBMDSwitcherTransitionDVEParameters::SetGain method

The **SetGain** method sets the gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | in | The desired gain. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

3.2.7.25 IBMDSwitcherTransitionDVEParameters::GetInverse method

The **GetInverse** method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

3.2.7.26 IBMDSwitcherTransitionDVEParameters::SetInverse method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.7.27 IBMDSwitcherTransitionDVEParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionDVEParameters** object. Pass an object implementing the **IBMDSwitcherTransitionDVEParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDVEParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionDVEParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.7.28 IBMDSwitcherTransitionDVEParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDVEParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionDVEParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.8 IBMDSwitcherTransitionDVEParametersCallback Interface

The **IBMDSwitcherTransitionDVEParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionDVEParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--|--|--|
| IBMDSwitcherTransitionDVEParametersCallback | IID_IBMDSwitcherTransitionDVEParameters | An IBMDSwitcherTransitionDVEParametersCallback object interface is installed with IBMDSwitcherTransitionDVEParameters::AddCallback and removed with IBMDSwitcherTransitionDVEParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|---------------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.8.1 IBMDSwitcherTransitionDVEParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionDVEParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionDVEParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherTransitionDVEParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9 IBMDSwitcherTransitionStingerParameters Interface

The **IBMDSwitcherTransitionStingerParameters** object interface is used for manipulating transition settings specific to stinger parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|---|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | An IBMDSwitcherTransitionStingerParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

| Public Member Functions | |
|-------------------------|--------------------------------------|
| Method | Description |
| GetSource | Get the current source. |
| SetSource | Set the source. |
| GetPreMultiplied | Get the current pre-multiplied flag. |
| SetPreMultiplied | Set the pre-multiplied flag. |
| GetClip | Get the current clip value. |
| SetClip | Set the clip value. |
| GetGain | Get the current gain. |
| SetGain | Set the gain. |
| GetInverse | Get the current inverse flag. |
| SetInverse | Set the inverse flag. |
| GetPreroll | Get the current pre-roll. |
| SetPreroll | Set the pre-roll. |
| GetClipDuration | Get the current clip duration. |
| SetClipDuration | Set the clip duration. |

SECTION 3 Advanced Transitions

| Public Member Functions | |
|-------------------------|--------------------------------|
| Method | Description |
| GetTriggerPoint | Get the current trigger point. |
| SetTriggerPoint | Set the trigger point. |
| GetMixRate | Get the current mix rate. |
| SetMixRate | Set the mix rate. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.9.1 IBMDSwitcherTransitionStingerParameters::GetSource method

The **GetSource** method returns the current source.

Syntax

```
HRESULT GetSource (BMDSwitcherStingerTransitionSource* src);
```

Parameters

| Name | Direction | Description |
|------|-----------|---------------------|
| src | out | The current source. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The src parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.9.2 IBMDSwitcherTransitionStingerParameters::SetSource method

The **SetSource** method sets the rate in frames.

Syntax

```
HRESULT SetSource (BMDSwitcherStingerTransitionSource src);
```

Parameters

| Name | Direction | Description |
|------|-----------|---------------------|
| src | in | The desired source. |

Return Values

| Value | Description |
|--------------|-------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The src parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.9.3 IBMDSwitcherTransitionStingerParameters::GetPreMultiplied method

The **GetPreMultiplied** method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | out | The current pre-multiplied flag. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The preMultiplied parameter is invalid. |

3.2.9.4 IBMDSwitcherTransitionStingerParameters::SetPreMultiplied method

The **SetPreMultiplied** method sets the pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | in | The desired pre-multiplied flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.5 IBMDSwitcherTransitionStingerParameters::GetClip method

The **GetClip** method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | out | The current clip value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The clip parameter is invalid. |

3.2.9.6 IBMDSwitcherTransitionStingerParameters::SetClip method

The **SetClip** method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | in | The desired clip value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.7 IBMDSwitcherTransitionStingerParameters::GetGain method

The **GetGain** method returns the current clip.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | out | The current gain. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

3.2.9.8 IBMDSwitcherTransitionStingerParameters::SetGain method

The **SetGain** method sets the gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | in | The desired gain. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

3.2.9.9 IBMDSwitcherTransitionStingerParameters::GetInverse method

The **GetInverse** method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

3.2.9.10 IBMDSwitcherTransitionStingerParameters::SetInverse method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.11 IBMDSwitcherTransitionStingerParameters::GetPreroll method

The **GetPreroll** method returns the current pre-roll.

Syntax

```
HRESULT GetPreroll (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------------|
| frames | out | The current pre-roll in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

3.2.9.12 IBMDSwitcherTransitionStingerParameters::SetPreroll method

The **SetPreroll** method sets the pre-roll.

Syntax

```
HRESULT SetPreroll (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------------|
| frames | in | The desired pre-roll in frames. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.13 IBMDSwitcherTransitionStingerParameters::GetClipDuration method

The **GetClipDuration** method returns the current clip duration.

Syntax

```
HRESULT GetClipDuration (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------------|
| frames | out | The current clip duration in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

3.2.9.14 IBMDSwitcherTransitionStingerParameters::SetClipDuration method

The **SetClipDuration** method sets the clip duration.

Syntax

```
HRESULT SetClipDuration (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------------|
| frames | in | The desired clip duration in frames. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.15 IBMDSwitcherTransitionStingerParameters::GetTriggerPoint method

The **GetTriggerPoint** method returns the current trigger point.

Syntax

```
HRESULT GetTriggerPoint (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------------|
| frames | out | The current trigger point in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

3.2.9.16 IBMDSwitcherTransitionStingerParameters::SetTriggerPoint method

The **SetTriggerPoint** method sets the trigger point.

Syntax

```
HRESULT SetTriggerPoint (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------------|
| frames | in | The desired trigger point in frames. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

3.2.9.17 **IBMDSwitcherTransitionStingerParameters::GetMixRate** method

The **GetMixRate** method returns the current mix rate.

Syntax

```
HRESULT GetMixRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------------|
| frames | out | The current mix rate in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

3.2.9.18 **IBMDSwitcherTransitionStingerParameters::SetMixRate** method

The **SetMixRate** method sets the mix rate.

Syntax

```
HRESULT SetMixRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------------|
| frames | in | The desired mix rate in frames. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.9.19 IBMDSwitcherTransitionStingerParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionStingerParameters** object. Pass an object implementing the **IBMDSwitcherTransitionStingerParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionStingerParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionStingerParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.9.20 IBMDSwitcherTransitionStingerParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionStingerParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTransitionStingerParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.10 IBMDSwitcherTransitionStingerParametersCallback Interface

The **IBMDSwitcherTransitionStingerParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionStingerParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|---|---|--|
| IBMDSwitcherTransitionStingerParameters | IID_IBMDSwitcherTransitionStingerParameters | An IBMDSwitcherTransitionStingerParametersCallback object interface is installed with IBMDSwitcherTransitionStingerParameters::AddCallback and removed with IBMDSwitcherTransitionStingerParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.10.1 IBMDSwitcherTransitionStingerParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionStingerParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherTransitionStingerParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | IBMDSwitcherTransitionStingerParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

SECTION 3 Advanced Transitions

3.2.11 IBMDSwitcherTransitionParameters Interface

The IBMDSwitcherTransitionParameters object interface is used for manipulating transition settings specific to Stinger parameters.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------------|--------------------------------------|--|
| IBMDSwitcherTransitionParameters | IID_IBMDSwitcherTransitionParameters | An IBMDSwitcherTransitionParameters object interface can be obtained with IBMDSwitcherMixEffectBlock::QueryInterface . |

Public Member Functions

| Method | Description |
|----------------------------|---------------------------------------|
| GetTransitionStyle | Get the current transition style. |
| GetNextTransitionStyle | Get the next transition style. |
| SetNextTransitionStyle | Set the next transition style. |
| GetTransitionSelection | Get the current transition selection. |
| SetNextTransitionSelection | Set the next transition selection. |
| GetNextTransitionSelection | Get the next transition selection. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

SECTION 3 Advanced Transitions

3.2.11.1 IBMDSwitcherTransitionParameters::GetTransitionStyle method

The **GetTransitionStyle** method returns the current transition style.

Syntax

```
HRESULT GetTransitionStyle (BMDSwitcherTransitionStyle* style);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------------|
| style | out | The current transition style. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The style parameter is invalid. |

3.2.11.2 IBMDSwitcherTransitionParameters::GetNextTransitionStyle method

The **GetNextTransitionStyle** method returns the next transition style.

Syntax

```
HRESULT GetNextTransitionStyle (BMDSwitcherTransitionStyle* style);
```

Parameters

| Name | Direction | Description |
|-------|-----------|----------------------------|
| style | out | The next transition style. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The style parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.3 IBMDSwitcherTransitionParameters::SetNextTransitionStyle method

The **SetNextTransitionStyle** method sets the rate in frames.

Syntax

```
HRESULT SetNextTransitionStyle (BMDSwitcherTransitionStyle style);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------------|
| style | in | The desired style. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The style parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.4 IBMDSwitcherTransitionParameters::GetTransitionSelection method

The **GetTransitionSelection** method returns the current transition selection.

Syntax

```
HRESULT GetTransitionSelection (BMDSwitcherTransitionSelection* selection);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------------|
| selection | out | The current transition selection. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The selection parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.5 IBMDSwitcherTransitionParameters::SetNextTransitionSelection method

The **SetNextTransitionSelection** method sets the next transition selection.

Syntax

```
HRESULT SetNextTransitionSelection (BMDSwitcherTransitionSelection selection);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| selection | in | The desired next transition selection. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The selection parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.6 IBMDSwitcherTransitionParameters::GetNextTransitionSelection method

The **GetNextTransitionSelection** method returns the next transition selection.

Syntax

```
HRESULT GetNextTransitionSelection (BMDSwitcherTransitionSelection* selection);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--------------------------------|
| selection | out | The next transition selection. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The selection parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.7 IBMDSwitcherTransitionParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionParameters** object. Pass an object implementing the **IBMDSwitcherTransitionParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherTransitionParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.11.8 IBMDSwitcherTransitionParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherTransitionParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

SECTION 3 Advanced Transitions

3.2.12 IBMDSwitcherTransitionParametersCallback Interface

The **IBMDSwitcherTransitionParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherTransitionParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|---|---|---|
| IBMDSwitcherTransitionParameters | IID_IBMDSwitcherTransitionParameters | An IBMDSwitcherTransitionParametersCallback object interface is installed with IBMDSwitcherTransitionParameters::AddCallback and removed with IBMDSwitcherTransitionParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

SECTION 3 Advanced Transitions

3.2.12.1 IBMDSwitcherTransitionParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTransitionParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherTransitionParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

4 Switcher Media

All media used by the switcher comes from its media pool, which consists of still images or video clips. Developers can upload and download from the media pool of a switcher using this SDK.

4.1 General Information

4.1.1 Uploading a Still or Clip

Here are the basic steps of uploading media to a switcher:

1. Ensure you are connected to a switcher and have a switcher object. Please refer to the Basic Switcher Control section for how to do this.
2. Get the **IBMDSwitcherMediaPool** interface from the switcher object, and use **IBMDSwitcherMediaPool::GetStills** to get the interface dedicated to all stills or **IBMDSwitcherMediaPool::GetClip** to get the interface dedicated to a particular clip.
3. **IBMDSwitcherStills::Lock** and **IBMDSwitcherClip::Lock** requests a lock of the switcher's stills/clip and the **IBMDSwitcherLockCallback** interface should then be used to be informed of when a lock is obtained. Many media pool operations require you to have a lock first.
4. If you are transferring to a clip then you probably want to stop users playing/downloading any frame in the clip by calling **IBMDSwitcherClip::SetInvalid**.
5. Use **IBMDSwitcherMediaPool::CreateFrame** to generate a frame object that will eventually be passed to the upload system. Populate this with your image data by filling in the frame's buffer, which is available via **IBMDSwitcherFrame::GetBytes**. Note that you do not need a lock to create a frame, but it is important that the chosen dimensions for the frame match those of the switcher's video mode when you proceed with the upload step.
6. Call **IBMDSwitcherStill::Upload** or **IBMDSwitcherClip::UploadFrame** to begin the transfer of the frame to the switcher. You will be notified of the outcome of this process by the **IBMDSwitcherStillsCallback** or **IBMDSwitcherClipCallback** interfaces. Regardless of outcome, this notification will also include the frame that was sent.
7. If you are transferring to a clip then you may want to repeatedly perform steps 4 and 5, although only one frame is permitted to be transferred at a time, and upon completing clip transfers you need to use **IBMDSwitcherClip::SetValid**.

SECTION 4 Switcher Media

8. Unlock the stills or clip. If you are uploading multiple stills then you may want to repeatedly lock and unlock the stills pool to allow other users to obtain a lock.

4.1.2 Downloading a Still or Clip

The steps are very similar to uploading:

9. Ensure you are connected to a switcher and have a switcher object. Please refer to the Basic Switcher Control section for how to do this.
10. Get the **IBMDSwitcherMediaPool** interface from the switcher object, and use **IBMDSwitcherMediaPool::GetStills** to get the interface dedicated to all stills or **IBMDSwitcherMediaPool::GetClip** to get the interface dedicated to a particular clip.
11. **IBMDSwitcherStills::Lock** and **IBMDSwitcherClip::Lock** requests a lock of the switcher's stills/clip and the **IBMDSwitcherLockCallback** interface should then be used to be informed of when a lock is obtained. Many media pool operations require you to have a lock first.
12. Call **IBMDSwitcherStill::Download** or **IBMDSwitcherClip::DownloadFrame** to begin the transfer of a frame from the switcher. You will be notified of the outcome of this process by the **IBMDSwitcherStillsCallback** or **IBMDSwitcherClipCallback** interfaces. For successful downloads, this notification will also include the frame that was requested.
13. Unlock the stills or clip. If you are downloading multiple stills then you may want to repeatedly lock and unlock the stills pool to allow other users to obtain a lock.

SECTION 4 Switcher Media

4.2 Media Data Types

4.2.1 Switcher Pixel Format

BMDSwitcherPixelFormat enumerates the possible pixel formats for `IBMDSwitcherFrame`.

| | |
|--|---|
| bmdSwitcherPixelFormat8BitARGB | Four bytes per pixel, alpha, red, green, blue. |
| bmdSwitcherPixelFormat8BitXRGB | Four bytes per pixel, padding, red, green, blue. |
| bmdSwitcherPixelFormat8BitYUV | Four bytes per two pixels, cb, y0, cr, y1. |
| bmdSwitcherPixelFormat10BitYUVA | Eight bytes per two pixels, a0, cb, y0, a1, cr, y1. |

4.2.2 Media Player Source Type

BMDSwitcherMediaPlayerSourceType enumerates the possible source types for `IBMDSwitcherMediaPlayer`.

| | |
|--|--------|
| bmdSwitcherMediaPlayerSourceTypeStill | Still. |
| bmdSwitcherMediaPlayerSourceTypeClip | Clip. |

4.2.3 Media Pool Event Type

BMDSwitcherMediaPoolEventType enumerates the possible event types for `IBMDSwitcherStillsCallback` and `IBMDSwitcherClipCallback`.

| | |
|---|--|
| bmdSwitcherMediaPoolEventTypeValidChanged | The validity has changed. |
| bmdSwitcherMediaPoolEventTypeNameChanged | The name has changed. |
| bmdSwitcherMediaPoolEventTypeHashChanged | The hash has changed. |
| bmdSwitcherMediaPoolEventTypeAudioValidChanged | The audio validity has changed. |
| bmdSwitcherMediaPoolEventTypeLockBusy | All clients receive this when any client obtains a lock. |
| bmdSwitcherMediaPoolEventTypeLockIdle | All clients receive this when no client has lock. |
| bmdSwitcherMediaPoolEventTypeTransferCompleted | The transfer has completed. |
| bmdSwitcherMediaPoolEventTypeTransferCancelled | The transfer has cancelled. |
| bmdSwitcherMediaPoolEventTypeTransferFailed | The transfer has failed. |
| bmdSwitcherMediaPoolEventTypeAudioNameChanged | The audio name has changed. |
| bmdSwitcherMediaPoolEventTypeAudioHashChanged | The audio hash has changed. |

4.3 Interface Reference

4.3.1 **IBMDSwitcherMediaPlayerCallback** Interface

The **IBMDSwitcherMediaPlayerCallback** object interface is a callback class containing methods that are called when the source, state or properties change for an **IBMDSwitcherMediaPlayer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------|-----------------------------|--|
| IBMDSwitcherMediaPlayer | IID_IBMDSwitcherMediaPlayer | An IBMDSwitcherMediaPlayerCallback object interface is installed with IBMDSwitcherMediaPlayer::AddCallback and removed with IBMDSwitcherMediaPlayer::RemoveCallback |

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| SourceChanged | Called when the source changes. |
| PlayingChanged | Called when playing changes. |
| LoopChanged | Called when loop changes. |
| AtBeginningChanged | Called when the current clip frame index changes to or from zero. |
| ClipFrameChanged | Called when the clip frame index is set. |

4.3.1.1 IBMDSwitcherMediaPlayerCallback::SourceChanged method

The **SourceChanged** method is called when the media player source changes.

Syntax

```
HRESULT SourceChanged (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.1.2 IBMDSwitcherMediaPlayerCallback::PlayingChanged method

The **PlayingChanged** method is called when the media player playing state changes.

Syntax

```
HRESULT PlayingChanged (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.1.3 IBMDSwitcherMediaPlayerCallback::LoopChanged method

The **LoopChanged** method is called when the media player loop property changes.

Syntax

```
HRESULT LoopChanged (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.1.4 IBMDSwitcherMediaPlayerCallback::AtBeginningChanged method

The **AtBeginningChanged** method is called when the media player current clip frame index changes to or from zero.

Syntax

```
HRESULT AtBeginningChanged (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

SECTION 4 Switcher Media

4.3.1.5 IBMDSwitcherMediaPlayerCallback::ClipFrameChanged method

The **ClipFrameChanged** method is called when the media player clip frame index is set.

Syntax

```
HRESULT ClipFrameChanged (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.2 IBMDSwitcherMediaPlayerIterator Interface

The **IBMDSwitcherMediaPlayerIterator** is used to enumerate the available media players.

A reference to an **IBMDSwitcherMediaPlayerIterator** object interface may be obtained from an **IBMDSwitcher** object interface using the **CreateIterator** method. Pass **IID_IBMDSwitcherMediaPlayerIterator** for the **iid** parameter.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|--|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::CreateIterator can return an IBMDSwitcherMediaPlayerIterator object interface. |

Public Member Functions

| Method | Description |
|--------|--|
| Next | Returns a pointer to the next IBMDSwitcherMediaPlayer object interface. |

4.3.2.1 IBMDSwitcherMediaPlayerIterator::Next method

The Next method returns the next available **IBMDSwitcherMediaPlayer** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherMediaPlayer** mediaPlayer);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---|
| mediaPlayer | out | IBMDSwitcherMediaPlayer object interface or NULL when no more media players are available. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| E_FALSE | Failure. |
| S_OK | Success. |
| E_POINTER | The mediaPlayer parameter is invalid. |

SECTION 4 Switcher Media

4.3.3 IBMDSwitcherMediaPlayer Interface

The **IBMDSwitcherMediaPlayer** object interface provides the ability to play stills and clips sourced from the media pool.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------------|-------------------------------------|--|
| IBMDSwitcherMediaPlayerIterator | IID_IBMDSwitcherMediaPlayerIterator | IBMDSwitcherMediaPlayerIterator::Next returns an IBMDSwitcherMediaPlayer object interface for each available media player. |

Public Member Functions

| Method | Description |
|----------------|---|
| GetSource | Gets the media player source. |
| SetSource | Sets the media player source. |
| GetPlaying | Gets the media player playing state. |
| SetPlaying | Sets the media player playing state. |
| GetLoop | Gets the media player loop property. |
| SetLoop | Sets the media player loop property. |
| GetAtBeginning | Gets the media player at beginning state. |
| SetAtBeginning | Sets the media player at beginning state. |
| GetClipFrame | Gets the media player clip frame index. |
| SetClipFrame | Sets the media player clip frame index. |
| AddCallback | Adds a media player callback. |
| RemoveCallback | Removes a media player callback. |

4.3.3.1 **IBMDSwitcherMediaPlayer::GetSource** method

The **GetSource** method gets the source type and index for the media player.

Syntax

```
HRESULT GetSource (BMDSwitcherMediaPlayerSourceType* type, uint32_t* index);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| <code>type</code> | out | BMDSwitcherMediaPlayerSourceType specifying the source as a still or clip. |
| <code>index</code> | out | Integer specifying the index of the source. |

Return Values

| Value | Description |
|------------------------|---|
| <code>E_FAIL</code> | Failure. |
| <code>S_OK</code> | Success. |
| <code>E_POINTER</code> | The type or index parameter is invalid. |

4.3.3.2 IBMDSwitcherMediaPlayer::SetSource method

The **SetSource** method sets the source type and index for the media player.

Syntax

```
HRESULT SetSource (BMDSwitcherMediaPlayerSourceType type, uint32_t index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|---|
| type | in | BMDSwitcherMediaPlayerSourceType specifying the source as a still or clip. |
| index | in | Integer specifying the index of the source. |

Return Values

| Value | Description |
|--------------|---|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | The type or index parameter is invalid. |

4.3.3.3 IBMDSwitcherMediaPlayer::GetPlaying method

The **GetPlaying** method gets the playing state for the media player.

Syntax

HRESULT GetPlaying (boolean* playing);

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| playing | out | Boolean value specifying the playing state. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The playing parameter is invalid. |

4.3.3.4 IBMDSwitcherMediaPlayer::SetPlaying method

The **SetPlaying** method sets the playing state for the media player.

Syntax

HRESULT SetPlaying (boolean playing);

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| playing | in | Boolean value specifying the playing state. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.3.5 IBMDSwitcherMediaPlayer::GetLoop method

The **GetLoop** method gets the loop property for the media player.

Syntax

HRESULT GetLoop (boolean* loop);

Parameters

| Name | Direction | Description |
|------|-----------|---|
| loop | out | Boolean value specifying the loop property. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The loop parameter is invalid. |

4.3.3.6 IBMDSwitcherMediaPlayer::SetLoop method

The **SetLoop** method sets the loop property for the media player.

Syntax

HRESULT SetLoop (boolean loop);

Parameters

| Name | Direction | Description |
|------|-----------|---|
| loop | in | Boolean value specifying the loop property. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.3.7 IBMDSwitcherMediaPlayer::GetAtBeginning method

The **GetAtBeginning** method gets the at beginning property for the media player.

Syntax

HRESULT GetAtBeginning (boolean* atBeginning);

Parameters

| Name | Direction | Description |
|-------------|-----------|--|
| atBeginning | out | Boolean value that is true when the current frame index is zero and false otherwise. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The atBeginning parameter is invalid. |

4.3.3.8 IBMDSwitcherMediaPlayer::SetAtBeginning method

The **SetAtBeginning** method sets the current frame index to zero for the media player.

Syntax

```
HRESULT SetAtBeginning ();
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.3.9 IBMDSwitcherMediaPlayer::GetClipFrame method

The **GetClipFrame** method gets the clip frame index for the media player when it is not playing.

Syntax

```
HRESULT GetClipFrame (uint32_t* clipFrameIndex);
```

Parameters

| Name | Direction | Description |
|----------------|-----------|--|
| clipFrameIndex | out | Integer value specifying the clip frame index. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| E_POINTER | The clipFrameIndex parameter is invalid. |

4.3.3.10 IBMDSwitcherMediaPlayer::SetClipFrame method

The **SetClipFrame** method sets the clip frame index for the media player if it is not playing.

Syntax

```
HRESULT SetClipFrame (uint32_t clipFrameIndex);
```

Parameters

| Name | Direction | Description |
|----------------|-----------|--|
| clipFrameIndex | in | Integer value specifying the clip frame index. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.3.11 IBMDSwitcherMediaPlayer::AddCallback method

The **AddCallback** method configures a callback to be called when the properties change for an **IBMDSwitcherMediaPlayer** object. Pass an object implementing the **IBMDSwitcherMediaPlayerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMediaPlayerCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMediaPlayerCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.3.12 IBMDSwitcherMediaPlayer::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT AddCallback (IBMDSwitcherMediaPlayerCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMediaPlayerCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.4 IBMDSwitcherFrame Interface

The **IBMDSwitcherFrame** object interface represents a frame and provides access to the frame's buffer and frame properties.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|---|
| IBMDSwitcherMediaPool | IID_IBMDSwitcherMediaPool | IBMDSwitcherMediaPool::CreateFrame returns an IBMDSwitcherFrame object. |

| Public Member Functions | |
|-------------------------|---------------------------------------|
| Method | Description |
| GetWidth | Gets the frame width in pixels. |
| GetHeight | Gets the frame height in pixels. |
| GetRowBytes | Gets the frame row size in bytes. |
| GetPixelFormat | Gets the pixel format. |
| GetBytes | Gets a pointer to the frame's buffer. |

4.3.4.1 IBMDSwitcherFrame::GetWidth method

The **GetWidth** method returns the width of the frame in pixels.

Syntax

```
int32 _t      GetWidth (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|------------------------|
| Width | Frame width in pixels. |

4.3.4.2 IBMDSwitcherFrame::GetHeight method

The **GetHeight** method returns the height of the frame in pixels.

Syntax

```
int32 _t      GetHeight (void);
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------------------|
| Height | Frame height in pixels. |

4.3.4.3 IBMDSwitcherFrame::GetRowBytes method

The **GetRowBytes** method returns the number of bytes per row in the frame.

Syntax

```
int32 _t      GetRowBytes (void);
```

Parameters

none.

Return Values

| Value | Description |
|-----------|--------------------------|
| ByteCount | Frame row size in bytes. |

4.3.4.4 IBMDSwitcherFrame::GetPixelFormat method

The **GetPixelFormat** method returns the pixel format of the frame.

Syntax

```
BMDSwitcherPixelFormat      GetPixelFormat (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------------|---------------------|
| PixelFormat | Frame pixel format. |

4.3.4.5 IBMDSwitcherFrame::GetBytes method

The **GetBytes** method allows direct access to the data buffer of the frame.
 The audio format is raw 24 bit, 2 channel, 48 khz.

Syntax

HRESULT GetBytes (void** buffer);

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| buffer | out | Pointer to the frame's raw buffer – only valid while while object remains valid. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_POINTER | The buffer parameter is invalid. |
| S_OK | Success. |

SECTION 4 Switcher Media

4.3.5 IBMDSwitcherAudio Interface

The **IBMDSwitcherAudio** object interface represents audio and provides access to the audio's buffer and audio size.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|---|
| IBMDSwitcherMediaPool | IID_IBMDSwitcherMediaPool | IBMDSwitcherMediaPool::CreateAudio returns an IBMDSwitcherAudio object. |

Public Member Functions

| Method | Description |
|----------|--------------------------------|
| GetSize | Gets the audio size in bytes. |
| GetBytes | Gets the audio buffer pointer. |

4.3.5.1 IBMDSwitcherFrame::GetSize method

The **GetSize** method returns the size of the audio in bytes.

Syntax

```
int32_t      GetSize (void);
```

Parameters

none.

Return Values

| Value | Description |
|-----------|----------------------|
| ByteCount | Audio size in bytes. |

4.3.5.2 IBMDSwitcherAudio::GetBytes method

The **GetBytes** method allows direct access to the data buffer of the audio.

Syntax

```
HRESULT      GetBytes (void** buffer);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| buffer | out | Pointer to the audio's raw buffer – only valid while object remains valid. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_POINTER | The buffer parameter is invalid. |
| S_OK | Success. |

4.3.6 IBMDSwitcherLockCallback Interface

The **IBMDSwitcherLockCallback** object interface is a callback class with an **Obtained** method that is called when the client receives a lock. Like all callback methods, **Obtained** may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------|------------------------|--|
| IBMDSwitcherStills | IID_IBMDSwitcherStills | An IBMDSwitcherLockCallback object interface is installed with IBMDSwitcherStills::Lock and removed with IBMDSwitcherStills::Unlock |
| IBMDSwitcherClip | IID_IBMDSwitcherClip | An IBMDSwitcherLockCallback object interface is installed with IBMDSwitcherClip::Lock and removed with IBMDSwitcherClip::Unlock |

Public Member Functions

| Method | Description |
|----------|---|
| Obtained | Called when the client receives a lock. |

4.3.6.1 IBMDSwitcherLockCallback::Obtained method

The **Obtained** method is called only for the client that receives the lock.

Syntax

```
HRESULT      Obtained (void);
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.7 **IBMDSwitcherStillsCallback Interface**

The **IBMDSwitcherStillsCallback** object interface is a callback class with a **Notify** method that is called when an event occurs for an **IBMDSwitcherStills** object. Like all callback methods, **Notify** may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------|------------------------|---|
| IBMDSwitcherStills | IID_IBMDSwitcherStills | An IBMDSwitcherStillsCallback object interface is installed with IBMDSwitcherStills::AddCallback and removed with IBMDSwitcherStills::RemoveCallback |

| Public Member Functions | |
|-------------------------|-------------------------------------|
| Method | Description |
| Notify | Called when an stills event occurs. |

4.3.7.1 IBMDSwitcherStillsCallback::Notify method

The **Notify** method is called when a stills event occurs. See **BMDSwitcherMediaPoolEventType** for a list of event types that may occur.

| | |
|---|---|
| bmdSwitcherMediaPoolEventTypeTransferCompleted | IBMDSwitcherStills::Upload and IBMDSwitcherStills::Download . |
| bmdSwitcherMediaPoolEventTypeTransferCancelled | IBMDSwitcherStills::Upload only. |
| bmdSwitcherMediaPoolEventTypeTransferFailed | BMDSwitcherStills::Upload only. |

IBMDSwitcherFrame ::AddRef must be called on the frame to extend its lifetime beyond the scope of this method.

Syntax

```
HRESULT Notify (BMDSwitcherMediaPoolEventType eventType, IBMDSwitcherFrame* frame, int32_t index);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherMediaPoolEventType that describes the type of event that has occurred. |
| frame | in | The IBMDSwitcherFrame that is being transferred. May be NULL . |
| index | in | Specifies the still for the eventType. The index is -1 when eventType is not specific to an individual still. |

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

SECTION 4 Switcher Media

4.3.8 IBMDSwitcherStills Interface

The **IBMDSwitcherStills** object interface represents the media pool stills.

The switcher stills interface provides methods to transfer stills and change still properties.

No more than one transfer can occur at a time.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|--|
| IBMDSwitcherMediaPool | IID_IBMDSwitcherMediaPool | IBMDSwitcherMediaPool::GetStills returns an IBMDSwitcherStills object. |

| Public Member Functions | |
|-------------------------|---------------------------------|
| Method | Description |
| GetCount | Gets the number of stills. |
| IsValid | Gets the validity of a still. |
| GetName | Gets the name of a still. |
| GetHash | Gets the hash of a still. |
| SetInvalid | Invalidates a still. |
| Lock | Locks all stills. |
| Unlock | Unlocks all stills. |
| Upload | Uploads a still. |
| Download | Downloads a still. |
| CancelTransfer | Cancels the upload or download. |
| GetProgress | Gets the transfer progress. |
| AddCallback | Adds a stills callback. |
| RemoveCallback | Removes a stills callback. |

4.3.8.1 IBMDSwitcherStills::GetCount method

The **GetCount** method returns the number of stills.

Syntax

```
HRESULT GetCount (uint32_t* count);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------|
| count | out | Number of stills. |

Return Values

| Value | Description |
|-----------|------------------------------|
| E_POINTER | The count parameter is NULL. |
| S_OK | Success. |

4.3.8.2 IBMDSwitcherStills::IsValid method

The **IsValid** method returns the validity of a still. A valid still can be downloaded and used by the media player.

Syntax

```
HRESULT IsValid (uint32_t index, bool* valid);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| index | in | Still index. |
| valid | out | Validity of the still. |

Return Values

| Value | Description |
|-----------|------------------------------|
| E_POINTER | The valid parameter is NULL. |
| S_OK | Success. |

4.3.8.3 **IBMDSwitcherStills::GetName** method

The **GetName** method returns the name of a still.

Syntax

```
HRESULT GetName (uint32_t index, string* name);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Still index. |
| name | out | Still name. |

Return Values

| Value | Description |
|-----------|-----------------------------|
| E_POINTER | The name parameter is NULL. |
| S_OK | Success. |

4.3.8.4 IBMDSwitcherStills::SetName method

The **SetName** method sets the name of a still.

Syntax

```
HRESULT SetName (uint32_t index, string name);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------|
| index | in | Still index. |
| name | in | The still name. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The name parameter is invalid. |
| E_INVALIDARG | The index parameter is invalid. |

4.3.8.5 IBMDSwitcherStills::GetHash method

The **GetHash** method returns the hash of a still.

Syntax

```
HRESULT GetHash (uint32_t index, BMDSwitcherHash* hash);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Still index. |
| hash | out | Still hash. |

Return Values

| Value | Description |
|-----------|-----------------------------|
| E_POINTER | The hash parameter is NULL. |
| S_OK | Success. |

4.3.8.6 IBMDSwitcherStills::SetInvalid method

The **SetInvalid** method invalidates a still for all switcher users. A still is set valid after a successful upload. This method will only be successful if you have a lock or no other connected client has a lock.

Syntax

```
HRESULT SetInvalid (uint32_t index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Still index. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.8.7 IBMDSwitcherStills::Lock method

The **Lock** method obtains a client lock for stills. Pass an object implementing the **IBMDSwitcherLockCallback** interface to receive **IBMDSwitcherLockCallback::Obtained** when the client obtains the stills lock.

Syntax

HRESULT Lock (IBMDSwitcherLockCallback* lockCallback);

Parameters

| Name | Direction | Description |
|--------------|-----------|--|
| lockCallback | in | Callback object implementing the IBMDSwitcherLockCallback object interface. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The lockCallback parameter is invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.8.8 IBMDSwitcherStills::Unlock method

The **Unlock** method releases the previous client lock for stills.

Syntax

HRESULT `Unlock (IBMDSwitcherLockCallback* lockCallback);`

Parameters

| Name | Direction | Description |
|--------------|-----------|--|
| lockCallback | in | Callback object implementing the IBMDSwitcherLockCallback object interface. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The lockCallback parameter is invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.8.9 IBMDSwitcherStills::Upload method

The **Upload** method transfers a still to the media pool. The client must hold the stills lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the frame’s buffer during the transfer.

Syntax

```
HRESULT Upload (uint32_t index, string* name, IBMDSwitcherFrame* frame);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| <code>index</code> | in | Destination still index. |
| <code>name</code> | in | Destination still name. |
| <code>frame</code> | in | Still frame to upload. The frame dimensions must match the switcher video mode. |

Return Values

| Value | Description |
|-----------------------------|--|
| <code>E_POINTER</code> | The lockCallback parameter is invalid. |
| <code>E_FAIL</code> | Failure. |
| <code>S_OK</code> | Success. |
| <code>E_INVALIDARG</code> | The index parameter is invalid. |
| <code>E_OUTOFMEMORY</code> | Unable to allocate required memory. |
| <code>E_ACCESSDENIED</code> | The client is not holding the stills lock. |

4.3.8.10 IBMDSwitcherStills::Download method

The **Download** method transfers a still from the media pool. The client must hold the stills lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT Download (uint32_t index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------------------|
| index | in | Index of still to download. |

Return Values

| Value | Description |
|----------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | The index parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_ACCESSDENIED | The client is not holding the stills lock. |

4.3.8.11 IBMDSwitcherStills::CancelTransfer method

The **CancelTransfer** method cancels the pending transfer. If there is no pending transfer then this method has no effect.

Syntax

HRESULT CancelTransfer ();

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.8.12 IBMDSwitcherStills::GetProgress method

The **GetProgress** method gets the progress of the pending transfer. If there is no pending transfer then progress is zero.

Syntax

HRESULT GetProgress (double* progress);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| progress | out | Transfer progress. Range is between 0.0 and 1.0. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| E_POINTER | The progress parameter is invalid. |
| S_OK | Success. |

4.3.8.13 IBMDSwitcherStills::AddCallback method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherStills** object. Pass an object implementing the **IBMDSwitcherStillsCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

IBMDSwitcherStillsCallback ::Notify will be called immediately on the provided **IBMDSwitcherStillsCallback** callback object with one of the following **BMDSwitcherMediaPoolEventType** eventTypes:

- bmdSwitcherMediaPoolEventTypeLockBusy**
- bmdSwitcherMediaPoolEventTypeLockIdle**

Syntax

```
HRESULT AddCallback (IBMDSwitcherStillsCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherStillsCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.8.14 **IBMDSwitcherStills::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherStillsCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherStillsCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.9 IBMDSwitcherClipCallback Interface

The **IBMDSwitcherClipCallback** object interface is a callback class with a **Notify** method that is called when an event occurs for an **IBMDSwitcherClip** object. Like all callback methods, **Notify** may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------|----------------------|---|
| IBMDSwitcherClip | IID_IBMDSwitcherClip | An IBMDSwitcherClipCallback object interface is installed with IBMDSwitcherClip::AddCallback and removed with IBMDSwitcherClip::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

4.3.9.1 **IBMDSwitcherClipCallback::Notify** method

The **Notify** method is called when a clip event occurs. See **BMDSwitcherMediaPoolEventType** for a list of event types that may occur.

The frame is set during the following transfer events, otherwise it is NULL:

| | |
|---|---|
| bmdSwitcherMediaPoolEventTypeTransferCompleted | IBMDSwitcherClip::Upload and IBMDSwitcherClip::Download . |
| bmdSwitcherMediaPoolEventTypeTransferCancelled | IBMDSwitcherClip::Upload only. |
| bmdSwitcherMediaPoolEventTypeTransferFailed | IBMDSwitcherClip::Upload only. |

The audio is set during the following transfer events, otherwise it is NULL:

| | |
|---|---|
| bmdSwitcherMediaPoolEventTypeTransferCompleted | IBMDSwitcherClip::UploadAudio and IBMDSwitcherClip::DownloadAudio . |
| bmdSwitcherMediaPoolEventTypeTransferCancelled | IBMDSwitcherClip::UploadAudio only. |
| bmdSwitcherMediaPoolEventTypeTransferFailed | IBMDSwitcherClip::UploadAudio only. |

IBMDSwitcherFrame ::AddRef must be called on the frame to extend its lifetime beyond the scope of this method.

IBMDSwitcherAudio ::AddRef must be called on the audio to extend its lifetime beyond the scope of this method.

Syntax

```
HRESULT Notify (BMDSwitcherMediaPoolEventType eventType, IBMDSwitcherFrame* frame,
                int32_t frameIndex, IBMDSwitcherAudio* audio, int32_t clipIndex);
```

SECTION 4 Switcher Media

Parameters

| Name | Direction | Description |
|-------------------------|-----------|--|
| <code>eventType</code> | in | BMDSwitcherMediaPoolEventType that describes the type of event that has occurred. |
| <code>frame</code> | in | The IBMDSwitcherFrame that is being transferred. May be NULL. |
| <code>frameIndex</code> | in | Specifies the frame for the eventType. The index is -1 when eventType is not specific to an individual clip frame. |
| <code>audio</code> | in | The IBMDSwitcherAudio that is being transferred. May be NULL. |
| <code>clipIndex</code> | in | Specifies the clip for the eventType. |

Return Values

| Value | Description |
|-------------------|-------------|
| <code>S_OK</code> | Success. |

4.3.10 IBMDSwitcherClip Interface

The **IBMDSwitcherClip** object interface represents the media pool clips.

The switcher clip interface provides methods to transfer clip frames and audio and to change clip properties. No more than one transfer can occur at a time.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|----------------------|--|
| IBMDSwitcherMediaPool | IID_IBMDSwitcherClip | IBMDSwitcherMediaPool::GetClip returns an IBMDSwitcherClip object. |

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetIndex | Gets the clip index. |
| IsValid | Gets the validity of the clip. |
| GetName | Gets the name of the clip. |
| SetValid | Sets the clip name and frame count and sets the clip valid. |
| SetInvalid | Invalidates the clip. |
| GetFrameCount | Gets the current clip frame count. |
| GetMaxFrameCount | Gets the maximum clip frame count. |
| IsFrameValid | Gets the validity of a clip frame. |
| GetFrameHash | Gets the hash of a clip frame. |
| IsAudioValid | Gets the validity of the clip audio. |
| GetAudioName | Gets the name of the clip audio. |
| GetAudioHash | Gets the hash of the clip audio. |
| SetAudioInvalid | Invalidates the clip audio. |

SECTION 4 Switcher Media

| Public Member Functions | |
|-------------------------|-----------------------------|
| Method | Description |
| Lock | Locks the clip. |
| Unlock | Unlocks the clip. |
| UploadFrame | Uploads a clip frame. |
| DownloadFrame | Downloads a clip frame. |
| UploadAudio | Uploads the clip audio. |
| DownloadAudio | Downloads the clip audio. |
| CancelTransfer | Cancel the transfer. |
| GetProgress | Gets the transfer progress. |
| AddCallback | Adds a clip callback. |
| RemoveCallback | Removes a clip callback. |

SECTION 4 Switcher Media

4.3.10.1 IBMDSwitcherClip::GetIndex method

The **GetIndex** method returns the clip index.

Syntax

```
HRESULT GetIndex (uint32_t* index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------|
| index | out | The clip index. |

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.10.2 IBMDSwitcherClip::IsValid method

The **IsValid** method returns the validity of the clip. A valid clip can be downloaded and played by the media player.

Syntax

```
HRESULT IsValid (bool* valid);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------------|
| valid | out | Validity of the clip. |

Return Values

| Value | Description |
|-----------|------------------------------|
| E_POINTER | The valid parameter is NULL. |
| S_OK | Success. |

4.3.10.3 IBMDSwitcherClip::GetName method

The **GetName** method returns the name of the clip.

Syntax

```
HRESULT      GetName (string* name);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------|
| name | out | Clip name. |

Return Values

| Value | Description |
|-----------|-----------------------------|
| E_POINTER | The name parameter is NULL. |
| S_OK | Success. |

4.3.10.4 IBMDSwitcherClip::SetName method

The **SetName** method sets the name of the clip.

Syntax

HRESULT `SetName (string name);`

Parameters

| Name | Direction | Description |
|------|-----------|----------------|
| name | in | The clip name. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The name parameter is invalid. |

4.3.10.5 IBMDSwitcherClip::SetValid method

The **SetValid** method sets the clip name and frame count and sets the clip valid. **SetValid** has no effect unless all frames up to frameCount are valid. A valid clip can be downloaded and played by the media player.

Syntax

```
HRESULT SetValid (string name, uint32_t frameCount);
```

Parameters

| Name | Direction | Description |
|------------|-----------|-------------------|
| name | in | Clip name. |
| frameCount | in | Clip frame count. |

Return Values

| Value | Description |
|-----------|------------------------------|
| E_POINTER | The valid parameter is NULL. |
| S_OK | Success. |

4.3.10.6 IBMDSwitcherClip::SetInvalid method

The **SetInvalid** method invalidates every frame of a clip for all users, and should be done before uploading a new clip. A clip should then be set to valid once uploading is complete. This method will only be successful if you have a lock or no other connected client has a lock.

Syntax

```
HRESULT SetInvalid ();
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.10.7 **IBMDSwitcherClip::GetFrameCount** method

The **GetFrameCount** method gets the current frame count of the clip.

Syntax

```
HRESULT GetFrameCount (uint32_t* frameCount);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| name | out | Clip frame count. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| E_POINTER | The frameCount parameter is NULL. |
| S_OK | Success. |

4.3.10.8 **IBMDSwitcherClip::GetMaxFrameCount** method

The **GetMaxFrameCount** method gets the maximum frame count for the clip.
 The maximum frame count can be set using **IBMDSwitcherMediaPool::SetClipMaxFrameCounts**.

Syntax

```
HRESULT GetMaxFrameCount (uint32_t* maxFrameCount);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|---------------------------|
| maxFrameCount | out | Maximum clip frame count. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| E_POINTER | The maxFrameCount parameter is NULL. |
| S_OK | Success. |

4.3.10.9 **IBMDSwitcherClip::IsFrameValid** method

The **IsFrameValid** method returns the validity of a clip frame.

Syntax

```
HRESULT IsFrameValid (uint32_t frameIndex, bool* valid);
```

Parameters

| Name | Direction | Description |
|------------|-----------|-----------------------------|
| frameIndex | in | Clip frame index. |
| valid | out | Validity of the clip frame. |

Return Values

| Value | Description |
|--------------|--------------------------------------|
| E_POINTER | The valid parameter is NULL. |
| E_INVALIDARG | The frameIndex parameter is invalid. |
| S_OK | Success. |

4.3.10.10 **IBMDSwitcherClip::GetFrameHash** method

The **GetFrameHash** method returns the hash of a clip frame.

Syntax

```
HRESULT GetFrameHash (uint32_t frameIndex, BMDSwitcherHash* hash);
```

Parameters

| Name | Direction | Description |
|------------|-----------|-------------------|
| frameIndex | in | Clip frame index. |
| hash | out | Clip frame hash. |

Return Values

| Value | Description |
|--------------|--------------------------------------|
| E_POINTER | The hash parameter is NULL. |
| E_INVALIDARG | The frameIndex parameter is invalid. |
| S_OK | Success. |

4.3.10.11 IBMDSwitcherClip::IsAudioValid method

The **IsAudioValid** method returns the validity of the clip audio. Valid clip audio can be downloaded and played by the media player.

Syntax

```
HRESULT IsAudioValid (bool* valid);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------------------|
| valid | out | Validity of the clip audio. |

Return Values

| Value | Description |
|-----------|------------------------------|
| E_POINTER | The valid parameter is NULL. |
| S_OK | Success. |

4.3.10.12 IBMDSwitcherClip::GetAudioName method

The **GetAudioName** method returns the name of the clip audio.

Syntax

HRESULT GetAudioName (string* name);

Parameters

| Name | Direction | Description |
|------|-----------|------------------|
| name | out | Clip audio name. |

Return Values

| Value | Description |
|-----------|-----------------------------|
| E_POINTER | The name parameter is NULL. |
| S_OK | Success. |

4.3.10.13 **IBMDSwitcherClip::SetAudioName** method

The **SetAudioName** method sets the name of the clip audio.

Syntax

HRESULT SetAudioName (string name);

Parameters

| Name | Direction | Description |
|------|-----------|-----------------|
| name | in | The still name. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The name parameter is invalid. |

4.3.10.14 IBMDSwitcherClip::GetAudioHash method

The **GetAudioHash** method returns the hash of the clip audio.

Syntax

HRESULT GetAudioHash (BMDSwitcherHash* hash);

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| hash | out | Clip audio frame hash. |

Return Values

| Value | Description |
|-----------|-----------------------------|
| E_POINTER | The hash parameter is NULL. |
| S_OK | Success. |

4.3.10.15 IBMDSwitcherClip::SetAudioInvalid method

The **SetAudioInvalid** method invalidates the clip audio. Clip audio is set valid after a successful clip audio upload.

Syntax

HRESULT SetAudioInvalid ();

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.10.16 IBMDSwitcherClip::Lock method

The **Lock** method obtains a client lock for the clip. Pass an object implementing the **IBMDSwitcherLockCallback** interface to receive **IBMDSwitcherLockCallback::Obtained** when the client obtains the clip lock.

Syntax

HRESULT Lock (IBMDSwitcherLockCallback* lockCallback);

Parameters

| Name | Direction | Description |
|--------------|-----------|--|
| lockCallback | in | Callback object implementing the IBMDSwitcherLockCallback object interface. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The lockCallback parameter is invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.10.17 IBMDSwitcherClip::Unlock method

The **Unlock** method releases the previous client lock for the clip.

Syntax

HRESULT `Unlock (IBMDSwitcherLockCallback* lockCallback);`

Parameters

| Name | Direction | Description |
|--------------|-----------|--|
| lockCallback | in | Callback object implementing the IBMDSwitcherLockCallback object interface. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The lockCallback parameter is invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.10.18 IBMDSwitcherClip::UploadFrame method

The **UploadFrame** method transfers a clip frame to a clip in the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the frame’s buffer during the transfer.

Syntax

```
HRESULT UploadFrame (uint32_t frameIndex, IBMDSwitcherFrame* frame);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--|
| frameIndex | in | frameIndex |
| frame | in | Clip frame to upload. The frame dimensions must match the switcher video mode. |

Return Values

| Value | Description |
|----------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The frame parameter is invalid. |
| E_INVALIDARG | The frameIndex parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_ACCESSDENIED | The client is not holding the clip lock. |

4.3.10.19 IBMDSwitcherClip::DownloadFrame method

The **DownloadFrame** method transfers a clip frame from the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT DownloadFrame (uint32_t frameIndex);
```

Parameters

| Name | Direction | Description |
|------------|-----------|----------------------------------|
| frameIndex | in | Index of clip frame to download. |

Return Values

| Value | Description |
|----------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | The frameIndex parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_ACCESSDENIED | The client is not holding the clip lock. |

4.3.10.20 IBMDSwitcherClip::UploadAudio method

The **UploadAudio** method transfers audio to a clip in the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the audio's buffer during the transfer.

Syntax

```
HRESULT UploadAudio (IBMDSwitcherAudio* audio);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-----------------------|
| audio | in | Clip audio to upload. |

Return Values

| Value | Description |
|----------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The audio parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_ACCESSDENIED | The client is not holding the clip lock. |

4.3.10.21 **IBMDSwitcherClip::DownloadAudio** method

The **Download** method transfers a clip from the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT DownloadAudio ();
```

Parameters

none.

Return Values

| Value | Description |
|----------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_ACCESSDENIED | The client is not holding the clip lock. |

4.3.10.22 IBMDSwitcherClip::CancelTransfer method

The **CancelTransfer** method cancels the pending transfer. If there is no pending transfer then this method has no effect.

Syntax

HRESULT CancelTransfer ();

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.10.23 IBMDSwitcherClip::GetProgress method

The **GetProgress** method gets the progress of the pending transfer. If there is no pending transfer then progress is zero.

Syntax

HRESULT GetProgress (double* progress);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| progress | out | Transfer progress. Range is between 0.0 and 1.0. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| E_POINTER | The progress parameter is invalid. |
| S_OK | Success. |

4.3.10.24 IBMDSwitcherClip::AddCallback method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherClip** object. Pass an object implementing the **IBMDSwitcherClipCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

IBMDSwitcherClipCallback ::Notify will be called immediately on the provided **IBMDSwitcherClipCallback** callback object with one of the following **BMDSwitcherMediaPoolEventType** eventTypes:

- bmdSwitcherMediaPoolEventTypeLockBusy**
- bmdSwitcherMediaPoolEventTypeLockIdle**

Syntax

```
HRESULT AddCallback (IBMDSwitcherClipCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherClipCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.10.25 IBMDSwitcherClip::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherClipCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherClipCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.11 IBMDSwitcherMediaPoolCallback Interface

The **IBMDSwitcherMediaPoolCallback** object interface is a callback class containing methods that are called when a property changes on an **IBMDSwitcherMediaPool** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|--|
| IBMDSwitcherMediaPool | IID_IBMDSwitcherMediaPool | An IBMDSwitcherMediaPoolCallback object interface is installed with IBMDSwitcherMediaPool::AddCallback and removed with IBMDSwitcherMediaPool::RemoveCallback |

| Public Member Functions | |
|---------------------------|--|
| Method | Description |
| ClipFrameMaxCountsChanged | Called when the maximum frame count changes for one or more clips. |
| FrameTotalForClipsChanged | Called when the total number of frames available to clips changes. |

4.3.11.1 IBMDSwitcherMediaPoolCallback::ClipFrameMaxCountsChanged method

The **ClipFrameMaxCountsChanged** method is called when the maximum frame count changes for one or more clips. Call **IBMDSwitcherMediaPool::GetClipMaxFrameCounts** to get the maximum frame counts for clips.

Syntax

```
HRESULT ClipFrameMaxCountsChanged ();
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

4.3.11.2 IBMDSwitcherMediaPoolCallback::FrameTotalForClipsChanged method

The **FrameTotalForClipsChanged** method is called when the total number of frames available to clips changes. Call **IBMDSwitcherMediaPool::GetFrameTotalForClips** to get the the total number of frames available to clips.

Syntax

```
HRESULT FrameTotalForClipsChanged ();
```

Parameters

none.

Return Values

| Value | Description |
|-------|-------------|
| S_OK | Success. |

SECTION 4 Switcher Media

4.3.12 IBMDSwitcherMediaPool Interface

The **IBMDSwitcherMediaPool** object interface provides for the creation of frames and audio and for accessing and modifying stills and clips.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | An IBMDSwitcherMediaPool object interface can be obtained with IBMDSwitcher::QueryInterface . |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| GetStills | Gets the IBMDSwitcherStills object interface. |
| GetClip | Gets a IBMDSwitcherClip object interface. |
| GetClipCount | Gets the number of clips. |
| CreateFrame | Creates an IBMDSwitcherFrame object. |
| CreateAudio | Creates an IBMDSwitcherAudio object. |
| GetFrameTotalForClips | Gets the total number of frames available to clips. |
| GetClipMaxFrameCounts | Gets the maximum frame count for all clips. |
| SetClipMaxFrameCounts | Sets the maximum frame count for all clips. |
| AddCallback | Adds a media pool callback. |
| RemoveCallback | Removes a media pool callback. |

4.3.12.1 IBMDSwitcherMediaPool::GetStills method

The **GetStills** method gets the **IBMDSwitcherStills** object interface.

Syntax

```
HRESULT GetStills (IBMDSwitcherStills** stills);
```

Parameters

| Name | Direction | Description |
|--------|-----------|------------------------------|
| stills | out | The stills object interface. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_POINTER | The stills parameter is invalid. |
| S_OK | Success. |

4.3.12.2 IBMDSwitcherMediaPool::GetClip method

The **GetClip** method gets the **IBMDSwitcherClip** object interface.

Syntax

```
HRESULT GetClip (uint32_t clipIndex, IBMDSwitcherClip** clip);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|----------------------------|
| clipIndex | in | The clip index. |
| clip | out | The clip object interface. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| E_POINTER | The stills parameter is invalid. |
| E_INVALIDARG | The clipIndex parameter is invalid. |
| S_OK | Success. |

4.3.12.3 IBMDSwitcherMediaPool::GetClipCount method

The **GetClipCount** method gets the number of clips.

Syntax

```
HRESULT GetClipCount (uint32_t* clipCount);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|----------------------|
| clipCount | out | The number of clips. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| E_POINTER | The clipCount parameter is invalid. |
| S_OK | Success. |

4.3.12.4 IBMDSwitcherMediaPool::CreateFrame method

The **CreateFrame** method creates an **IBMDSwitcherFrame** object.

Syntax

```
HRESULT CreateFrame (BMDSwitcherPixelFormat pixelFormat, uint32_t width, uint32_t height,
                    IBMDSwitcherFrame** frame);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|--|
| pixelFormat | in | The pixel format. See BMDSwitcherPixelFormat for a list of supported pixel formats. |
| width | in | The frame width in pixels. |
| height | in | The frame height in pixels. |
| frame | out | The newly created frame. |

Return Values

| Value | Description |
|---------------|--|
| E_POINTER | The frame parameter is invalid. |
| E_INVALIDARG | The pixelFormat, width or height parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.12.5 **IBMDSwitcherMediaPool::CreateAudio** method

The **CreateAudio** method creates an **IBMDSwitcherAudio** object.

Syntax

```
HRESULT CreateAudio (uint32_t sizeBytes, IBMDSwitcherAudio** audio);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------------|
| sizeBytes | in | The audio's buffer size in bytes. |
| audio | out | The newly created audio object. |

Return Values

| Value | Description |
|---------------|-------------------------------------|
| E_POINTER | The audio parameter is invalid. |
| E_INVALIDARG | The sizeBytes parameter is invalid. |
| E_OUTOFMEMORY | Unable to allocate required memory. |
| E_FAIL | Failure. |
| S_OK | Success. |

4.3.12.6 **IBMDSwitcherMediaPool::GetFrameTotalForClips** method

The **GetFrameTotalForClips** method gets the total number of frames available to clips.

Syntax

```
HRESULT GetFrameTotalForClips (uint32_t* total);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|----------------------|
| clipCount | out | The number of clips. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| E_POINTER | The total parameter is invalid. |
| S_OK | Success. |

4.3.12.7 IBMDSwitcherMediaPool::GetClipMaxFrameCounts method

The **GetClipMaxFrameCounts** method gets the maximum frame count for all clips.

Syntax

HRESULT GetFrameTotalForClips (uint32_t clipCount, uint32_t* clipMaxFrameCounts);

Parameters

| Name | Direction | Description |
|--------------------|-----------|--|
| clipCount | in | Length of clipMaxFrameCounts array. This must match the switcher clip count. |
| clipMaxFrameCounts | out | A clipCount length array, where each element receives the maximum frame count for its respective clip index. |

Return Values

| Value | Description |
|--------------|--|
| E_POINTER | The clipMaxFrameCounts parameter is invalid. |
| E_INVALIDARG | The clipCount parameter is invalid. |
| S_OK | Success. |

4.3.12.8 IBMDSwitcherMediaPool::Clear method

The **Clear** method invalidates all stills, clips and clip audio.

Syntax

```
HRESULT Clear ();
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

4.3.12.9 **IBMDSwitcherMediaPool::SetClipMaxFrameCounts** method

The **SetClipMaxFrameCounts** method sets the maximum frame count for all clips.

Syntax

```
HRESULT SetClipMaxFrameCounts (uint32_t clipCount, const uint32_t* clipMaxFrameCounts);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|--|
| clipCount | in | Length of clipMaxFrameCounts array. This must match the switcher clip count. |
| clipMaxFrameCounts | in | A clipCount length array, where each element sets the maximum frame count for its respective clip index. |

Return Values

| Value | Description |
|--------------|--|
| E_POINTER | The clipMaxFrameCounts parameter is invalid. |
| E_INVALIDARG | The clipCount parameter is invalid. |
| S_OK | Success. |

4.3.12.10 IBMDSwitcherMediaPool::AddCallback method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherMediaPool** object. Pass an object implementing the **IBMDSwitcherMediaPoolCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

HRESULT SetClipMaxFrameCounts (uint32_t clipCount, const uint32_t* clipMaxFrameCounts);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMediaPoolCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

4.3.12.11 IBMDSwitcherMediaPool::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMediaPoolCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMediaPoolCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5 Keyers

Any form of a keyer available in our switchers use these API components to perform chroma keying.

5.1 Key Data Types

5.1.1 Key Type

BMDSwitcherKeyType enumerates the possible key types, used by **IBMDSwitcherKey** object interface.

| | |
|----------------------------------|----------------|
| bmdSwitcherKeyTypeLuma | Luminance key. |
| bmdSwitcherKeyTypeChroma | Chroma key. |
| bmdSwitcherKeyTypePattern | Pattern key. |
| bmdSwitcherKeyTypeDVE | DVE key. |

5.1.2 Fly Key Frames

BMDSwitcherFlyKeyFrame is a bit set that enumerates possible key frames for a fly key, used by **IBMDSwitcherKeyFlyParameters** object interface.

| | |
|--|--------------------------------------|
| bmdSwitcherFlyKeyFrameFull | Full screen. |
| bmdSwitcherFlyKeyFrameInfinityCentreOfKey | Infinity at centre of key. |
| bmdSwitcherFlyKeyFrameInfinityTopLeft | Infinity at top left of screen. |
| bmdSwitcherFlyKeyFrameInfinityTop | Infinity at top centre of screen. |
| bmdSwitcherFlyKeyFrameInfinityTopRight | Infinity at top right of screen. |
| bmdSwitcherFlyKeyFrameInfinityLeft | Infinity at mid left of screen. |
| bmdSwitcherFlyKeyFrameInfinityCentre | Infinity at centre of screen. |
| bmdSwitcherFlyKeyFrameInfinityRight | Infinity at mid right of screen. |
| bmdSwitcherFlyKeyFrameInfinityBottomLeft | Infinity at bottom left of screen. |
| bmdSwitcherFlyKeyFrameInfinityBottom | Infinity at bottom centre of screen. |
| bmdSwitcherFlyKeyFrameInfinityBottomRight | Infinity at bottom right of screen. |
| bmdSwitcherFlyKeyFrameA | User-defined key frame A. |
| bmdSwitcherFlyKeyFrameB | User-defined key frame B. |

5.1.3 Border Bevel Options

BMDSwitcherBorderBevelOption enumerates possible border bevel style options.

This type is used by **IBMDSwitcherKeyDVEParameters** and **IBMDSwitcherInputSuperSource** object interfaces.

| | |
|--|-----------------------------|
| bmdSwitcherBorderBevelOptionNone | No bevel. |
| bmdSwitcherBorderBevelOptionInOut | Both inner and outer bevel. |
| bmdSwitcherBorderBevelOptionIn | Inner bevel only. |
| bmdSwitcherBorderBevelOptionOut | Outer bevel only. |

5.1.4 Key Event Type

BMDSwitcherKeyEventType enumerates the possible event types for **IBMDSwitcherKeyCallback**.

| | |
|--|--------------------------------|
| bmdSwitcherKeyEventTypeTypeChanged | The type changed. |
| bmdSwitcherKeyEventTypeInputCutChanged | The cut input source changed. |
| bmdSwitcherKeyEventTypeInputFillChanged | The fill input source changed. |
| bmdSwitcherKeyEventTypeOnAirChanged | The on-air flag changed. |
| bmdSwitcherKeyEventTypeCanBeDVEKeyChanged | The can-be-DVE flag changed. |
| bmdSwitcherKeyEventTypeMaskedChanged | The masked flag changed. |
| bmdSwitcherKeyEventTypeMaskTopChanged | The mask top value changed. |
| bmdSwitcherKeyEventTypeMaskBottomChanged | The mask bottom value changed. |
| bmdSwitcherKeyEventTypeMaskLeftChanged | The mask left value changed. |
| bmdSwitcherKeyEventTypeMaskRightChanged | The mask right value changed. |

5.1.5 Luminance Key Parameters Event Type

BMDSwitcherKeyLumaParametersEventType enumerates the possible event types for **IBMDSwitcherKeyLumaParametersCallback**.

| | |
|--|----------------------------------|
| bmdSwitcherKeyLumaParametersEventTypePreMultipliedChanged | The pre-multiplied flag changed. |
| bmdSwitcherKeyLumaParametersEventTypeClipChanged | The clip value changed. |
| bmdSwitcherKeyLumaParametersEventTypeGainChanged | The gain value changed. |
| bmdSwitcherKeyLumaParametersEventTypeInverseChanged | The inverse flag changed. |

5.1.6 Chroma Key Parameters Event Type

BMDSwitcherKeyChromaParametersEventType enumerates the possible event types for **IBMDSwitcherKeyChromaParametersCallback**.

| | |
|--|-------------------------------|
| bmdSwitcherKeyChromaParametersEventTypeHueChanged | The hue value changed. |
| bmdSwitcherKeyChromaParametersEventTypeGainChanged | The gain value changed. |
| bmdSwitcherKeyChromaParametersEventTypeYSuppressChanged | The y-suppress value changed. |
| bmdSwitcherKeyChromaParametersEventTypeLiftChanged | The lift value changed. |
| bmdSwitcherKeyChromaParametersEventTypeNarrowChanged | The narrow flag changed. |

5.1.7 Pattern Key Parameters Event Type

BMDSwitcherKeyPatternParametersEventType enumerates the possible event types for **IBMDSwitcherKeyPatternParametersCallback**.

| | |
|--|--------------------------------|
| bmdSwitcherKeyPatternParametersEventTypePatternChanged | The pattern style changed. |
| bmdSwitcherKeyPatternParametersEventTypeSizeChanged | The size value changed. |
| bmdSwitcherKeyPatternParametersEventTypeSymmetryChanged | The symmetry value changed. |
| bmdSwitcherKeyPatternParametersEventTypeSoftnessChanged | The softness value changed. |
| bmdSwitcherKeyPatternParametersEventTypeHorizontalOffsetChanged | The horizontal offset changed. |
| bmdSwitcherKeyPatternParametersEventTypeVerticalOffsetChanged | The vertical offset changed. |
| bmdSwitcherKeyPatternParametersEventTypeInverseChanged | The inverse flag changed. |

5.1.8 DVE Key Parameters Event Type

BMDSwitcherKeyDVEParametersEventType enumerates the possible event types for **IBMDSwitcherKeyDVEParametersCallback**.

bmdSwitcherKeyDVEParametersEventTypeShadowChanged

The shadow flag changed.

bmdSwitcherKeyDVEParametersEventTypeLightSourceDirectionChanged

The light source direction value changed.

bmdSwitcherKeyDVEParametersEventTypeLightSourceAltitudeChanged

The light source altitude value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderEnabledChanged

The border enabled flag changed.

bmdSwitcherKeyDVEParametersEventTypeBorderBevelChanged

The border bevel option changed.

bmdSwitcherKeyDVEParametersEventTypeBorderWidthInChanged

The border inner width value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderWidthOutChanged

The border outer width value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderSoftnessInChanged

The border inner softness value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderSoftnessOutChanged

The border outer softness value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderBevelSoftnessChanged

The border bevel softness value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderBevelPositionChanged

The border bevel position value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderOpacityChanged

The border opacity value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderHueChanged

The border hue value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderSaturationChanged

The border saturation value changed.

bmdSwitcherKeyDVEParametersEventTypeBorderLumaChanged

The border luminance value changed.

bmdSwitcherKeyDVEParametersEventTypeMaskedChanged

The masked flag changed.

bmdSwitcherKeyDVEParametersEventTypeMaskTopChanged

The mask top value changed.

bmdSwitcherKeyDVEParametersEventTypeMaskBottomChanged

The mask bottom value changed.

bmdSwitcherKeyDVEParametersEventTypeMaskLeftChanged

The mask left value changed.

bmdSwitcherKeyDVEParametersEventTypeMaskRightChanged

The mask right value changed.

5.1.9 Fly Key Parameters Event Type

BMDSwitcherKeyFlyParametersEventType enumerates the possible event types for **IBMDSwitcherKeyFlyParametersCallback**.

| | |
|--|---------------------------------------|
| bmdSwitcherKeyFlyParametersEventTypeFlyChanged | The fly flag changed. |
| bmdSwitcherKeyFlyParametersEventTypeCanFlyChanged | The can-fly flag changed. |
| bmdSwitcherKeyFlyParametersEventTypeRateChanged | The rate value changed. |
| bmdSwitcherKeyFlyParametersEventTypeSizeXChanged | The size x value changed. |
| bmdSwitcherKeyFlyParametersEventTypeSizeYChanged | The size y value changed. |
| bmdSwitcherKeyFlyParametersEventTypePositionXChanged | The position x value changed. |
| bmdSwitcherKeyFlyParametersEventTypePositionYChanged | The position y value changed. |
| bmdSwitcherKeyFlyParametersEventTypeRotationChanged | The rotation value changed. |
| bmdSwitcherKeyFlyParametersEventTypelsKeyFrameStoredChanged | The is-key-frame-stored flag changed. |
| bmdSwitcherKeyFlyParametersEventTypelsAtKeyFramesChanged | The is-at-key-frames status changed. |
| bmdSwitcherKeyFlyParametersEventTypelsRunningChanged | The is-running status changed. |

5.1.10 Downstream Key Event Type

BMDSwitcherDownstreamKeyEventType enumerates the possible event types for **IBMDSwitcherDownstreamKeyCallback**.

| | |
|--|---|
| bmdSwitcherDownstreamKeyEventTypeInputCutChanged | The cut input source changed. |
| bmdSwitcherDownstreamKeyEventTypeInputFillChanged | The fill input source changed. |
| bmdSwitcherDownstreamKeyEventTypeTieChanged | The tie flag changed. |
| bmdSwitcherDownstreamKeyEventTypeRateChanged | The rate value changed. |
| bmdSwitcherDownstreamKeyEventTypeOnAirChanged | The on-air flag changed. |
| bmdSwitcherDownstreamKeyEventTypeIsTransitioningChanged | The is-transitioning flag changed. |
| bmdSwitcherDownstreamKeyEventTypeIsAutoTransitioningChanged | The is-auto-transitioning flag changed. |
| bmdSwitcherDownstreamKeyEventTypeFramesRemainingChanged | The frames remaining value changed. |
| bmdSwitcherDownstreamKeyEventTypePreMultipliedChanged | The pre-multiplied flag changed. |
| bmdSwitcherDownstreamKeyEventTypeClipChanged | The clip value changed. |
| bmdSwitcherDownstreamKeyEventTypeGainChanged | The gain value changed. |
| bmdSwitcherDownstreamKeyEventTypeInverseChanged | The inverse flag changed. |
| bmdSwitcherDownstreamKeyEventTypeMaskedChanged | The masked flag changed. |
| bmdSwitcherDownstreamKeyEventTypeMaskTopChanged | The mask top value changed. |
| bmdSwitcherDownstreamKeyEventTypeMaskBottomChanged | The mask bottom value changed. |
| bmdSwitcherDownstreamKeyEventTypeMaskLeftChanged | The mask left value changed. |
| bmdSwitcherDownstreamKeyEventTypeMaskRightChanged | The mask right value changed. |

5.2 Interface Reference

5.2.1 IBMDSwitcherKeylterator Interface

The **IBMDSwitcherKeylterator** is used to enumerate the available keys for each mix effect block.

A reference to an **IBMDSwitcherKeylterator** object interface may be obtained from an **IBMDSwitcherMixEffectBlock** object interface using the **Createlterator** method. Pass **IID_IBMDSwitcherKeylterator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|--|
| IBMDSwitcherMixEffectBlock | IID_IBMDSwitcherMixEffectBlock | IBMDSwitcherMixEffectBlock::Createlterator can return an IBMDSwitcherKeylterator object interface. |

Public Member Functions

| Method | Description |
|--------|---|
| Next | Returns a pointer to the next IBMDSwitcherKey object interface. |

5.2.1.1 **IBMDSwitcherMediaPool::AddCallback** method

The **Next** method returns the next available **IBMDSwitcherKey** object interface.

Syntax

HRESULT Next (IBMDSwitcherKey** key);

Parameters

| Name | Direction | Description |
|------|-----------|--|
| key | out | IBMDSwitcherKey object interface. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherKey objects available. |
| E_POINTER | The key parameter is invalid. |

5.2.2 IBMDSwitcherKey Interface

The **IBMDSwitcherKey** object interface is used for manipulating the basic settings of a key. Please note that the mask settings in this interface only apply to luminance, chroma and pattern key types; DVE type key uses its own mask settings available in the **IBMDSwitcherKeyDVEParameters** interface.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------|-----------------------------|---|
| IBMDSwitcherKeyIterator | IID_IBMDSwitcherKeyIterator | An IBMDSwitcherKey object will be returned after a successful call to IBMDSwitcherKeyIterator::Next method. |

| Public Member Functions | |
|------------------------------|---|
| Method | Description |
| GetType | Get the current key type. |
| SetType | Set the key type. |
| GetInputCut | Get the current cut input source. |
| SetInputCut | Set the cut input source. |
| GetInputFill | Get the current fill input source. |
| SetInputFill | Set the fill input source. |
| GetFillInputAvailabilityMask | Get the availability mask for the fill of this input. |
| GetCutInputAvailabilityMask | Get the availability mask for the cut of this input. |
| GetOnAir | Get the on-air flag. |
| SetOnAir | Set the on-air flag. |
| GetCanBeDVEKey | Determine if this key can be set to DVE type. |
| GetMasked | Get the current masked flag. |
| SetMasked | Set the masked flag. |

| Public Member Functions | |
|----------------------------|--|
| Method | Description |
| GetMaskTop | Get the current mask top value. |
| SetMaskTop | Set the mask top value. |
| GetMaskBottom | Get the current mask bottom value. |
| SetMaskBottom | Set the mask bottom value. |
| GetMaskLeft | Get the current mask left value. |
| SetMaskLeft | Set the mask left value. |
| GetMaskRight | Get the current mask right value. |
| SetMaskRight | Set the mask right value. |
| ResetMask | Reset mask to default values. |
| GetTransitionSelectionMask | Get the corresponding BMDSwitcherTransitionSelection bit mask for this key. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.2.1 IBMDSwitcherKey::GetType method

The **GetType** method returns the current key type.

Syntax

```
HRESULT GetType (BMDSwitcherKeyType* type);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| type | out | The current key type. |

Return Values

| Value | Description |
|--------------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The type parameter is invalid. |
| E_UNEXPECTED | Unexpected error occurred. |

5.2.2.2 IBMDSwitcherKey::SetType method

The **SetType** method sets the key to the specified type.

Syntax

```
HRESULT SetType (BMDSwitcherKeyType type);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| type | in | The desired key type. |

Return Values

| Value | Description |
|--------------|--------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The type parameter is invalid. |

5.2.2.3 IBMDSwitcherKey::GetInputCut method

The **GetInputCut** method returns the selected cut input source.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| inputId | out | BMDSwitcherInputId of the selected cut input source. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inputId parameter is invalid. |

5.2.2.4 IBMDSwitcherKey::SetInputCut method

The **SetInputCut** method sets the cut input source.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | in | The desired cut input source's BMDSwitcherInputId . |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The inputId parameter is invalid. |

5.2.2.5 IBMDSwitcherKey::GetInputFill method

The **GetInputFill** method returns the selected fill input source.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | out | BMDSwitcherInputId of the selected fill input source. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inputId parameter is invalid. |

5.2.2.6 IBMDSwitcherKey::SetInputFill method

The **SetInputFill** method sets the fill input source.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| inputId | in | The desired fill input source's BMDSwitcherInputId . |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The inputId parameter is invalid. |

5.2.2.7 **IBMDSwitcherKey::GetFillInputAvailabilityMask** method

The GetFillInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for fill inputs available to this key. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this key.

Syntax

HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

5.2.2.8 IBMDSwitcherKey::GetCutInputAvailabilityMask method

The GetCutInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this key. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this key.

Syntax

```
HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

5.2.2.9 IBMDSwitcherKey::GetOnAir method

The **GetOnAir** method returns the on-air flag.

Syntax

```
HRESULT GetOnAir (boolean* onAir);
```

Parameters

| Name | Direction | Description |
|-------|-----------|----------------------|
| onAir | out | Boolean on-air flag. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The onAir parameter is invalid. |

5.2.2.10 IBMDSwitcherKey::SetOnAir method

The **SetOnAir** method sets the on-air flag.

Syntax

```
HRESULT SetOnAir (boolean onAir);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------------------|
| onAir | in | The desired on-air flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.11 IBMDSwitcherKey::CanBeDVEKey method

The **CanBeDVEKey** method returns a status flag of whether this key can be set to the DVE type. The DVE hardware is a shared resource; if another component is currently using the resource, it may not be available for this key.

Syntax

HRESULT CanBeDVEKey (boolean* canDVE);

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| canDVE | out | Boolean status of whether this key can be a DVE key. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The canDVE parameter is invalid. |

5.2.2.12 IBMDSwitcherKey::GetMasked method

The **GetMasked** method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| masked | out | Boolean flag of whether masking is enabled. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The masked parameter is invalid. |

5.2.2.13 IBMDSwitcherKey::SetMasked method

Use **SetMasked** method to enable or disable masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------|
| masked | in | The desired masked value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.14 IBMDSwitcherKey::GetMaskTop method

The **GetMaskTop** method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | out | The current mask top value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The maskTop parameter is invalid. |

5.2.2.15 IBMDSwitcherKey::SetMaskTop method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | in | The desired mask top value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.16 **IBMDSwitcherKey::GetMaskBottom** method

The **GetMaskBottom** method returns the current mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | out | The current mask bottom value. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskBottom parameter is invalid. |

5.2.2.17 **IBMDSwitcherKey::SetMaskBottom** method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | in | The desired mask bottom value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.18 IBMDSwitcherKey::GetMaskLeft method

The **GetMaskLeft** method returns the current mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | out | The current mask left value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskLeft parameter is invalid. |

5.2.2.19 IBMDSwitcherKey::SetMaskLeft method

The **SetMaskLeft** method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | in | The desired mask left value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.20 IBMDSwitcherKey::GetMaskRight method

The **GetMaskRight** method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | out | The current mask right value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskRight parameter is invalid. |

5.2.2.21 IBMDSwitcherKey::SetMaskRight method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | in | The desired mask right value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.22 **IBMDSwitcherKey::ResetMask** method

Use the **ResetMask** method to reset mask settings to default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.2.23 **IBMDSwitcherKey::GetTransitionSelectionMask** method

The **GetTransitionSelectionMask** method returns the corresponding **BMDSwitcherTransitionSelection** bit mask for this key.

Syntax

```
HRESULT GetTransitionSelectionMask (BMDSwitcherTransitionSelection* selectionMask);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|---|
| selectionMask | out | BMDSwitcherTransitionSelection bit mask. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The selectionMask parameter is invalid. |

5.2.2.24 IBMDSwitcherKey::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKey** object. Pass an object implementing the **IBMDSwitcherKeyCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

HRESULT AddCallback (IBMDSwitcherKeyCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.2.25 IBMDSwitcherKey::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherKeyCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.3 **IBMDSwitcherKeyCallback Interface**

The **IBMDSwitcherKeyCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKey** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|--|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyCallback object interface is installed with IBMDSwitcherKey::AddCallback and removed with IBMDSwitcherKey::RemoveCallback . |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.3.1 **IBMDSwitcherKeyCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherKey** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherKeyEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.4 IBMDSwitcherKeyLumaParameters Interface

The **IBMDSwitcherKeyLumaParameters** object interface is used for manipulating parameters specific to luminance type key.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|--|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyLumaParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface . |

| Public Member Functions | |
|-------------------------|--------------------------------------|
| Method | Description |
| GetPreMultiplied | Get the current pre-multiplied flag. |
| SetPreMultiplied | Set pre-multiplied flag. |
| GetClip | Get the current clip value. |
| SetClip | Set the clip value. |
| GetGain | Get the current gain value. |
| SetGain | Set gain value. |
| GetInverse | Get the current inverse flag. |
| SetInverse | Set the inverse flag. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.4.1 IBMDSwitcherKeyLumaParameters::GetPreMultiplied method

The **GetPreMultiplied** method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | out | The current pre-multiplied flag. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The preMultiplied parameter is invalid. |

5.2.4.2 IBMDSwitcherKeyLumaParameters::SetPreMultiplied method

The **SetPreMultiplied** method sets the pre-multiplied flag.

Note that clip, gain and inverse controls are not used when pre-multiplied flag is set to true.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | in | The desired pre-multiplied flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.4.3 IBMDSwitcherKeyLumaParameters::GetClip method

The **GetClip** method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | out | The current clip value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The clip parameter is invalid. |

5.2.4.4 IBMDSwitcherKeyLumaParameters::SetClip method

The **SetClip** method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | in | The desired clip value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.4.5 **IBMDSwitcherKeyLumaParameters::GetGain method**

The **GetGain** method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | out | The current gain value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

5.2.4.6 **IBMDSwitcherKeyLumaParameters::SetGain method**

The **SetGain** method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | in | The desired gain value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.4.7 **IBMDSwitcherKeyLumaParameters::GetInverse** method

The **GetInverse** method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

5.2.4.8 **IBMDSwitcherKeyLumaParameters::SetInverse** method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.4.9 **IBMDSwitcherKeyLumaParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyLumaParameters** object. Pass an object implementing the **IBMDSwitcherKeyLumaParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyLumaParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyLumaParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.4.10 IBMDSwitcherKeyLumaParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyLumaParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyLumaParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.5 IBMDSwitcherKeyLumaParametersCallback Interface

The **IBMDSwitcherKeyLumaParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyLumaParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------|-----------------------------------|--|
| IBMDSwitcherKeyLumaParameters | IID_IBMDSwitcherKeyLumaParameters | An IBMDSwitcherKeyLumaParametersCallback object interface is installed with IBMDSwitcherKeyLumaParameters::AddCallback and removed with IBMDSwitcherKeyLumaParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.5.1 IBMDSwitcherKeyLumaParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyLumaParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherKeyLumaParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | IBMDSwitcherKeyLumaParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6 IBMDSwitcherKeyChromaParameters Interface

The **IBMDSwitcherKeyChromaParameters** object interface is used for manipulating settings specific to the chroma type key.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|--|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyChromaParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface . |

| Public Member Functions | |
|-------------------------|----------------------------------|
| Method | Description |
| GetHue | Get the current hue value. |
| SetHue | Set the hue value. |
| GetGain | Get the current gain value. |
| SetGain | Set the gain value. |
| GetYSuppress | Get the current y-suppress flag. |
| SetYSuppress | Set the y-suppress flag. |
| GetLift | Get the current lift value. |
| SetLift | Set the lift value. |
| GetNarrow | Get the current narrow flag. |
| SetNarrow | Set the narrow flag. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.6.1 IBMDSwitcherKeyChromaParameters::GetHue method

The **GetHue** method gets the current hue value.

Syntax

```
HRESULT GetHue (double* hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| hue | out | The current hue value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The hue parameter is invalid. |

5.2.6.2 IBMDSwitcherKeyChromaParameters::SetHue method

The **SetHue** method sets the hue value.

Syntax

```
HRESULT SetHue (double hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| hue | in | The desired hue value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6.3 IBMDSwitcherKeyChromaParameters::GetGain method

The **GetGain** method gets the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | out | The current gain value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

5.2.6.4 IBMDSwitcherKeyChromaParameters::SetGain method

The **SetGain** method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | in | The desired gain value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6.5 **IBMDSwitcherKeyChromaParameters::GetYSuppress method**

The **GetYSuppress** method gets the current y-suppress value.

Syntax

```
HRESULT GetYSuppress (double* ySuppress);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| ySuppress | out | The current y-suppress value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The ySuppress parameter is invalid. |

5.2.6.6 **IBMDSwitcherKeyChromaParameters::SetYSuppress method**

The **SetYSuppress** method sets the y-suppress value.

Syntax

```
HRESULT SetYSuppress (double ySuppress);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|------------------------------|
| ySuppress | in | The desired ySuppress value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6.7 **IBMDSwitcherKeyChromaParameters::GetLift** method

The **GetLift** method gets the current lift value.

Syntax

```
HRESULT GetLift (double* lift);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| lift | out | The current lift value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The lift parameter is invalid. |

5.2.6.8 **IBMDSwitcherKeyChromaParameters::SetLift** method

The **SetLift** method sets the lift value.

Syntax

```
HRESULT SetLift (double lift);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| lift | in | The desired lift value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6.9 IBMDSwitcherKeyChromaParameters::GetNarrow method

The **GetNarrow** method gets the current narrow flag.

Syntax

```
HRESULT GetNarrow (boolean* narrow);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------|
| narrow | out | The current narrow flag. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The narrow parameter is invalid. |

5.2.6.10 IBMDSwitcherKeyChromaParameters::SetNarrow method

The **SetNarrow** method sets the narrow flag.

Syntax

```
HRESULT SetNarrow (boolean narrow);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------|
| narrow | in | The desired narrow flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.6.11 **IBMDSwitcherKeyChromaParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyChromaParameters** object. Pass an object implementing the **IBMDSwitcherKeyChromaParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyChromaParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyChromaParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.6.12 IBMDSwitcherKeyChromaParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherKeyChromaParametersCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherKeyChromaParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.7 **IBMDSwitcherKeyChromaParametersCallback Interface**

The **IBMDSwitcherKeyChromaParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyChromaParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------------|-------------------------------------|--|
| IBMDSwitcherKeyChromaParameters | IID_IBMDSwitcherKeyChromaParameters | An IBMDSwitcherKeyChromaParametersCallback object interface is installed with IBMDSwitcherKeyChromaParameters::AddCallback and removed with IBMDSwitcherKeyChromaParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.7.1 IBMDSwitcherKeyChromaParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyChromaParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyChromaParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherKeyChromaParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8 IBMDSwitcherKeyPatternParameters Interface

The **IBMDSwitcherKeyPatternParameters** object interface is used for manipulating settings specific to the pattern type key.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|---|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyPatternParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface . |

| Public Member Functions | |
|-------------------------|------------------------------------|
| Method | Description |
| GetPattern | Get the current pattern style. |
| SetPattern | Set the pattern style. |
| GetSize | Get the current size value. |
| SetSize | Set the size value. |
| GetSymmetry | Get the current symmetry value. |
| SetSymmetry | Set the symmetry value. |
| GetSoftness | Get the current softness value. |
| SetSoftness | Set the softness value. |
| GetHorizontalOffset | Get the current horizontal offset. |
| SetHorizontalOffset | Set the horizontal offset. |
| GetVerticalOffset | Get the current vertical offset. |
| SetVerticalOffset | Set the vertical offset. |
| GetInverse | Get the current inverse flag. |
| SetInverse | Set the inverse flag. |

SECTION **5** Keyers

Public Member Functions

| Method | Description |
|----------------|--------------------|
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.8.1 **IBMDSwitcherKeyPatternParameters::GetPattern** method

The **GetPattern** method gets the current pattern style.

Syntax

```
HRESULT GetPattern (BMDSwitcherPatternStyle* pattern);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| pattern | out | The current pattern style of BMDSwitcherPatternStyle . |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The pattern parameter is invalid. |

5.2.8.2 **IBMDSwitcherKeyPatternParameters::SetPattern** method

The **SetPattern** method sets the pattern style.

Syntax

```
HRESULT SetPattern (BMDSwitcherPatternStyle pattern);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| pattern | in | The desired BMDSwitcherPatternStyle pattern style. |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The pattern parameter is invalid. |
| E_FAIL | Failure. |

5.2.8.3 IBMDSwitcherKeyPatternParameters::GetSize method

The **GetSize** method gets the current size value.

Syntax

```
HRESULT GetSize (double* size);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| size | out | The current size value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The size parameter is invalid. |

5.2.8.4 IBMDSwitcherKeyPatternParameters::SetSize method

The **SetSize** method sets the size value.

Syntax

```
HRESULT SetSize (double size);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| size | in | The desired size value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.5 **IBMDSwitcherKeyPatternParameters::GetSymmetry** method

The **GetSymmetry** method gets the current symmetry value.

Syntax

```
HRESULT GetSymmetry (double* symmetry);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| symmetry | out | The current symmetry value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The symmetry parameter is invalid. |

5.2.8.6 **IBMDSwitcherKeyPatternParameters::SetSymmetry** method

The **SetSymmetry** method sets the symmetry value.

Syntax

```
HRESULT SetSymmetry (double symmetry);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| symmetry | in | The desired symmetry value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.7 IBMDSwitcherKeyPatternParameters::GetSoftness method

The **GetSoftness** method gets the current softness value.

Syntax

```
HRESULT GetSoftness (double* softness);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| softness | out | The current softness value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The softness parameter is invalid. |

5.2.8.8 IBMDSwitcherKeyPatternParameters::SetSoftness method

The **SetSoftness** method sets the softness value.

Syntax

```
HRESULT SetSoftness (double softness);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-----------------------------|
| softness | in | The desired softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.9 IBMDSwitcherKeyPatternParameters::GetHorizontalOffset method

The **GetHorizontalOffset** method gets the current horizontal offset value.

Syntax

```
HRESULT GetHorizontalOffset (double* hOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--------------------------------------|
| hOffset | out | The current horizontal offset value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The hOffset parameter is invalid. |

5.2.8.10 IBMDSwitcherKeyPatternParameters::SetHorizontalOffset method

The **SetHorizontalOffset** method sets the horizontal offset value.

Syntax

```
HRESULT SetHorizontalOffset (double hOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--------------------------------------|
| hOffset | in | The desired horizontal offset value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.11 IBMDSwitcherKeyPatternParameters::GetVerticalOffset method

The **GetVerticalOffset** method gets the current vertical offset value.

Syntax

```
HRESULT GetVerticalOffset (double* vOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|------------------------------------|
| vOffset | out | The current vertical offset value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The vOffset parameter is invalid. |

5.2.8.12 IBMDSwitcherKeyPatternParameters::SetVerticalOffset method

The **SetVerticalOffset** method sets the vertical offset value.

Syntax

```
HRESULT SetVerticalOffset (double vOffset);
```

Parameters

| Name | Direction | Description |
|---------|-----------|------------------------------------|
| vOffset | in | The desired vertical offset value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.13 **IBMDSwitcherKeyPatternParameters::GetInverse** method

The **GetInverse** method gets the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

5.2.8.14 **IBMDSwitcherKeyPatternParameters::SetInverse** method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.8.15 IBMDSwitcherKeyPatternParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyPatternParameters** object. Pass an object implementing the **IBMDSwitcherKeyPatternParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyPatternParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyPatternParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.8.16 IBMDSwitcherKeyPatternParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherKeyPatternParametersCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyPatternParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.9 IBMDSwitcherKeyPatternParametersCallback Interface

The **IBMDSwitcherKeyPatternParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyPatternParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------------|--------------------------------------|---|
| IBMDSwitcherKeyPatternParameters | IID_IBMDSwitcherKeyPatternParameters | An IBMDSwitcherKeyPatternParametersCallback object interface is installed with IBMDSwitcherKeyPatternParameters::AddCallback and removed with IBMDSwitcherKeyPatternParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.9.1 IBMDSwitcherKeyPatternParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyPatternParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherKeyPatternParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | IBMDSwitcherKeyPatternParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10 **IBMDSwitcherKeyDVEParameters Interface**

The **IBMDSwitcherKeyDVEParameters** object interface is used for manipulating settings specific to the DVE-type key. Note that properties that affect a fly key also affects a DVE key; they are access through the **IBMDSwitcherKeyFlyParameters** object interface. Also note that the mask properties in this interface only affect keys with their type set to DVE.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|---|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyDVEParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface . |

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetShadow | Get the current shadow flag. |
| SetShadow | Set the shadow flag. |
| GetLightSourceDirection | Get the current light source direction value. |
| SetLightSourceDirection | Set the light source direction value. |
| GetLightSourceAltitude | Get the current light source altitude value. |
| SetLightSourceAltitude | Set the light source altitude value. |
| GetBorderEnabled | Get the current border enabled flag. |
| SetBorderEnabled | Set the border enabled flag. |
| GetBorderBevel | Get the current border bevel option. |
| SetBorderBevel | Set the border bevel option. |
| GetBorderWidthIn | Get the current border inner width value. |
| SetBorderWidthIn | Set the border inner width value. |
| GetBorderWidthOut | Get the current border outer width value. |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| SetBorderWidthOut | Set the border outer width value. |
| GetBorderSoftnessIn | Get the current border inner softness value. |
| SetBorderSoftnessIn | Set the border inner softness value. |
| GetBorderSoftnessOut | Get the current border outer softness value. |
| SetBorderSoftnessOut | Set the border outer softness value. |
| GetBorderBevelSoftness | Get the current border bevel softness value. |
| SetBorderBevelSoftness | Set the border bevel softness value. |
| GetBorderBevelPosition | Get the current border bevel position value. |
| SetBorderBevelPosition | Set the border bevel position value. |
| GetBorderOpacity | Get the current border opacity value. |
| SetBorderOpacity | Set the border opacity value. |
| GetBorderHue | Get the current border hue value. |
| SetBorderHue | Set the border hue value. |
| GetBorderSaturation | Get the current border saturation value. |
| SetBorderSaturation | Set the border saturation value. |
| GetBorderLuma | Get the current border luminance value. |
| SetBorderLuma | Set the border luminance value. |
| GetMasked | Get the current masked flag. |
| SetMasked | Set the masked flag. |
| GetMaskTop | Get the current mask top value. |
| SetMaskTop | Set the mask top value. |
| GetMaskBottom | Get the current mask bottom value. |

SECTION 5 Keyers

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| SetMaskBottom | Set the mask bottom value. |
| GetMaskLeft | Get the current mask left value. |
| SetMaskLeft | Set the mask left value. |
| GetMaskRight | Get the current mask right value. |
| SetMaskRight | Set the mask right value. |
| ResetMask | Reset mask properties to default values. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.10.1 IBMDSwitcherKeyDVEParameters::GetShadow method

The **GetShadow** method gets the current shadow flag.

Syntax

```
HRESULT GetShadow (boolean* shadow);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------|
| shadow | out | The current shadow flag. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The shadow parameter is invalid. |

5.2.10.2 IBMDSwitcherKeyDVEParameters::SetShadow method

The **SetShadow** method sets the shadow flag.

Syntax

```
HRESULT SetShadow (boolean shadow);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------|
| shadow | in | The desired shadow flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.3 IBMDSwitcherKeyDVEParameters::GetLightSourceDirection method

The **GetLightSourceDirection** method gets the current light source direction value.

Syntax

```
HRESULT GetLightSourceDirection (double* degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| degrees | out | The current light source direction in degrees. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The degrees parameter is invalid. |

5.2.10.4 IBMDSwitcherKeyDVEParameters::SetLightSourceDirection method

The **SetLightSourceDirection** method sets the light source direction value.

Syntax

```
HRESULT SetLightSourceDirection (double degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| degrees | in | The desired light source direction value in degrees. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.5 IBMDSwitcherKeyDVEParameters::GetLightSourceAltitude method

The **GetLightSourceAltitude** method gets the current light source altitude value.

Syntax

```
HRESULT GetLightSourceAltitude (double* altitude);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| altitude | out | The current light source altitude value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The altitude parameter is invalid. |

5.2.10.6 IBMDSwitcherKeyDVEParameters::SetLightSourceAltitude method

The **SetLightSourceAltitude** method sets the light source altitude value.

Syntax

```
HRESULT SetLightSourceAltitude (double altitude);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| altitude | in | The desired light source altitude value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.7 IBMDSwitcherKeyDVEParameters::GetBorderEnabled method

The **GetBorderEnabled** method gets the current border enabled flag.

Syntax

```
HRESULT GetBorderEnabled (boolean* enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------------|
| enabled | out | The current border enabled flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The enabled parameter is invalid. |

5.2.10.8 IBMDSwitcherKeyDVEParameters::SetBorderEnabled method

The **SetBorderEnabled** method sets the border enabled flag.

Syntax

```
HRESULT SetBorderEnabled (boolean enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------------|
| enabled | in | The desired border enabled flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.9 **IBMDSwitcherKeyDVEParameters::GetBorderBevel** method

The **GetBorderBevel** method gets the current border bevel option.

Syntax

```
HRESULT GetBorderBevel (BMDSwitcherBorderBevelOption* bevelOption);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---|
| bevelOption | out | The current bevel option of BMDSwitcherBorderBevelOption . |

Return Values

| Value | Description |
|--------------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The bevelOption parameter is invalid. |
| E_UNEXPECTED | Unexpected error occurred. |

5.2.10.10 **IBMDSwitcherKeyDVEParameters::SetBorderBevel** method

The **SetBorderBevel** method sets the border bevel option.

Syntax

```
HRESULT SetBorderBevel (BMDSwitcherBorderBevelOption bevelOption);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---|
| bevelOption | in | The desired bevel option of BMDSwitcherBorderBevelOption . |

Return Values

| Value | Description |
|--------------|---------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The bevelOption parameter is invalid. |
| E_FAIL | Failure. |

5.2.10.11 **IBMDSwitcherKeyDVEParameters::GetBorderWidthIn** method

The **GetBorderWidthIn** method gets the current border inner width value.

Syntax

```
HRESULT GetBorderWidthIn (double* widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------------|
| widthIn | out | The current border inner width value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The widthIn parameter is invalid. |

5.2.10.12 **IBMDSwitcherKeyDVEParameters::SetBorderWidthIn** method

The **SetBorderWidthIn** method sets the border inner width value.

Syntax

```
HRESULT SetBorderWidthIn (double widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------------|
| widthIn | in | The desired border inner width value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.13 IBMDSwitcherKeyDVEParameters::GetBorderWidthOut method

The **GetBorderWidthOut** method gets the current border outer width value.

Syntax

```
HRESULT GetBorderWidthOut (double* widthOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------------|
| widthIn | out | The current border outer width value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The widthOut parameter is invalid. |

5.2.10.14 IBMDSwitcherKeyDVEParameters::SetBorderWidthOut method

The **SetBorderWidthOut** method sets the border outer width value.

Syntax

```
HRESULT SetBorderWidthOut (double widthOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------------|
| widthIn | in | The desired border outer width value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.15 IBMDSwitcherKeyDVEParameters::GetBorderSoftnessIn method

The **GetBorderSoftnessIn** method gets the current border inner softness value.

Syntax

HRESULT GetBorderSoftnessIn (double* softIn);

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| softIn | out | The current border inner softness value. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The softIn parameter is invalid. |

5.2.10.16 IBMDSwitcherKeyDVEParameters::SetBorderSoftnessIn method

The **SetBorderSoftnessIn** method sets the border inner softness value.

Syntax

HRESULT SetBorderSoftnessIn (double softIn);

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| softIn | in | The desired border inner softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.17 IBMDSwitcherKeyDVEParameters::GetBorderSoftnessOut method

The **GetBorderSoftnessOut** method gets the current border outer softness value.

Syntax

```
HRESULT GetBorderSoftnessOut (double* softOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| softOut | out | The current border outer softness value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The softOut parameter is invalid. |

5.2.10.18 IBMDSwitcherKeyDVEParameters::SetBorderSoftnessOut method

The **SetBorderSoftnessOut** method sets the border outer softness value.

Syntax

```
HRESULT SetBorderSoftnessOut (double softOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| softOut | in | The desired border outer softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.19 IBMDSwitcherKeyDVEParameters::GetBorderBevelSoftness method

The **GetBorderBevelSoftness** method gets the current border bevel softness value.

Syntax

HRESULT GetBorderBevelSoftness (double* bevelSoft);

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| bevelSoft | out | The current border bevel softness value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The bevelSoft parameter is invalid. |

5.2.10.20 IBMDSwitcherKeyDVEParameters::SetBorderBevelSoftness method

The **SetBorderBevelSoftness** method sets the border bevel softness value.

Syntax

HRESULT SetBorderBevelSoftness (double bevelSoft);

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| bevelSoft | in | The desired border bevel softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.21 IBMDSwitcherKeyDVEParameters::GetBorderBevelPosition method

The **GetBorderBevelPosition** method gets the current border bevel position value.

Syntax

```
HRESULT GetBorderBevelPosition (double* bevelPosition);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| bevelPosition | out | The current border bevel position value. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The bevelPosition parameter is invalid. |

5.2.10.22 IBMDSwitcherKeyDVEParameters::SetBorderBevelPosition method

The **SetBorderBevelPosition** method sets the border bevel position value.

Syntax

```
HRESULT SetBorderBevelPosition (double bevelPosition);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| bevelPosition | in | The desired border bevel position value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.23 IBMDSwitcherKeyDVEParameters::GetBorderOpacity method

The **GetBorderOpacity** method gets the current border opacity value.

Syntax

HRESULT GetBorderOpacity (double* opacity);

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------------|
| opacity | out | The current border opacity value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The opacity parameter is invalid. |

5.2.10.24 IBMDSwitcherKeyDVEParameters::SetBorderOpacity method

The **SetBorderOpacity** method sets the border opacity value.

Syntax

HRESULT SetBorderOpacity (double opacity);

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------------|
| opacity | in | The desired border opacity value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.25 IBMDSwitcherKeyDVEParameters::GetBorderHue method

The **GetBorderHue** method gets the current border hue value.

Syntax

```
HRESULT GetBorderHue (double* hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------|
| hue | out | The current border hue value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The hue parameter is invalid. |

5.2.10.26 IBMDSwitcherKeyDVEParameters::SetBorderHue method

The **SetBorderHue** method sets the border hue value.

Syntax

```
HRESULT SetBorderHue (double hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------|
| hue | in | The desired border hue value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.27 IBMDSwitcherKeyDVEParameters::GetBorderSaturation method

The **GetBorderSaturation** method gets the current border saturation value.

Syntax

```
HRESULT GetBorderSaturation (double* sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------------------|
| sat | out | The current border saturation value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The sat parameter is invalid. |

5.2.10.28 IBMDSwitcherKeyDVEParameters::SetBorderSaturation method

The **SetBorderSaturation** method sets the border saturation value.

Syntax

```
HRESULT SetBorderSaturation (double saturation);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------------|
| saturation | in | The desired border saturation value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.29 **IBMDSwitcherKeyDVEParameters::GetBorderLuma** method

The **GetBorderLuma** method gets the current border luminance value.

Syntax

```
HRESULT GetBorderLuma (double* luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------------|
| luma | out | The current border luminance value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The luma parameter is invalid. |

5.2.10.30 **IBMDSwitcherKeyDVEParameters::SetBorderLuma** method

The **SetBorderLuma** method sets the border luminance value.

Syntax

```
HRESULT SetBorderLuma (double luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------------|
| luma | in | The desired border luminance value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.31 IBMDSwitcherKeyDVEParameters::GetMasked method

The **GetMasked** method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| masked | out | Boolean flag of whether masking is enabled. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The masked parameter is invalid. |

5.2.10.32 IBMDSwitcherKeyDVEParameters::SetMasked method

Use **SetMasked** method to enable or disable masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------|
| masked | in | The desired masked value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.33 IBMDSwitcherKeyDVEParameters::GetMaskTop method

The **GetMaskTop** method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | out | The current mask top value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The maskTop parameter is invalid. |

5.2.10.34 IBMDSwitcherKeyDVEParameters::SetMaskTop method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | in | The desired mask top value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.35 IBMDSwitcherKeyDVEParameters::GetMaskBottom method

The **GetMaskBottom** method returns the current mask bottom value.

Syntax

HRESULT GetMaskBottom (double* maskBottom);

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | out | The current mask bottom value. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskBottom parameter is invalid. |

5.2.10.36 IBMDSwitcherKeyDVEParameters::SetMaskBottom method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

HRESULT SetMaskBottom (double maskBottom);

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | in | The desired mask bottom value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.37 IBMDSwitcherKeyDVEParameters::GetMaskLeft method

The **GetMaskLeft** method returns the current mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | out | The current mask left value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskLeft parameter is invalid. |

5.2.10.38 BMDSwitcherKeyDVEParameters::SetMaskLeft method

The **SetMaskLeft** method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | in | The desired mask left value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.39 BMDSwitcherKeyDVEParameters::GetMaskRight method

The **GetMaskRight** method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | out | The current mask right value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskRight parameter is invalid. |

5.2.10.40 BMDSwitcherKeyDVEParameters::SetMaskRight method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | in | The desired mask right value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.41 IBMDSwitcherKeyDVEParameters::ResetMask method

The **ResetMask** method resets the mask settings to default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.10.42 IBMDSwitcherKeyDVEParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyDVEParameters** object. Pass an object implementing the **IBMDSwitcherKeyDVEParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyDVEParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyDVEParametersCallback object interface. |

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.10.43 IBMDSwitcherKeyDVEParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherKeyDVEParametersCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyDVEParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.11 **IBMDSwitcherKeyDVEParametersCallback Interface**

The **IBMDSwitcherKeyDVEParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyDVEParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------|----------------------------------|---|
| IBMDSwitcherKeyDVEParameters | IID_IBMDSwitcherKeyDVEParameters | An IBMDSwitcherKeyDVEParametersCallback object interface is installed with IBMDSwitcherKeyDVEParameters::AddCallback and removed with IBMDSwitcherKeyDVEParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.11.1 IBMDSwitcherKeyDVEParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyDVEParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyDVEParametersEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherKeyDVEParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12 **IBMDSwitcherKeyFlyParameters Interface**

The **IBMDSwitcherKeyFlyParameters** object interface is used for manipulating fly settings of a key. A luminance, chroma or pattern key can be made a “fly” key, filtering its current state through the DVE hardware. Turning off the fly setting will remove the filter and return the key to its original state. Note that most properties in this interface also take effect when the key type is set to DVE.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------|---------------------|---|
| IBMDSwitcherKey | IID_IBMDSwitcherKey | An IBMDSwitcherKeyFlyParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface . |

| Public Member Functions | |
|-------------------------|-----------------------------------|
| Method | Description |
| GetFly | Get the current fly flag. |
| SetFly | Set the fly flag. |
| GetCanFly | Get the current can-fly flag. |
| GetRate | Get the current fly rate. |
| SetRate | Set the fly rate. |
| GetSizeX | Get the current size x value. |
| SetSizeX | Set the size x value. |
| GetSizeY | Get the current size y value. |
| SetSizeY | Set the size y value. |
| GetPositionX | Get the current position x value. |
| SetPositionX | Set the position x value. |
| GetPositionY | Get the current position y value. |
| SetPositionY | Set the position y value. |

SECTION 5 5 Keyers

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetRotation | Get the current rotation value. |
| SetRotation | Set the rotation value. |
| ResetRotation | Reset rotation to default value. |
| ResetDVE | Reset DVE properties (size, position and rotation) to default values. |
| ResetDVEFull | Reset DVE properties (size, position and rotation) to full screen. |
| IsKeyFrameStored | Determine if a key frame has been stored. |
| StoreAsKeyFrame | Store current state into a key frame. |
| RunToKeyFrame | Run to a key frame. |
| IsAtKeyFrames | Determines if the current frame matches any of the stored key frames. |
| IsRunning | Determines if the key is currently running. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.12.1 IBMDSwitcherKeyFlyParameters::GetFly method

The **GetFly** method returns whether fly is enabled or not.

Syntax

```
HRESULT GetFly (boolean* isFlyKey);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| isFlyKey | out | Boolean status of whether fly is enabled. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The isFlyKey parameter is invalid. |

5.2.12.2 IBMDSwitcherKeyFlyParameters::SetFly method

Use the **SetFly** method to enable or disable fly.

Syntax

```
HRESULT SetFly (boolean isFlyKey);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| isFlyKey | in | The desired fly enable flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.3 IBMDSwitcherKeyFlyParameters::GetCanFly method

The **GetCanFly** method returns whether this key can enable fly or not. The DVE hardware is a shared resource; if another component is currently using the resource, it may not be available for this key.

Syntax

HRESULT GetCanFly (boolean* canFly);

Parameters

| Name | Direction | Description |
|--------|-----------|-------------------------------------|
| canFly | out | Boolean status of the can-fly flag. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The canFly parameter is invalid. |

5.2.12.4 IBMDSwitcherKeyFlyParameters::GetRate method

The **GetRate** method gets the current fly rate value.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------------|
| frames | out | The current rate value in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

5.2.12.5 IBMDSwitcherKeyFlyParameters::SetRate method

The **SetRate** method sets the fly rate value.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------------|
| frames | in | The desired rate value in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The frames parameter is invalid. |
| E_FAIL | Failure. |

5.2.12.6 IBMDSwitcherKeyFlyParameters::GetSizeX method

The **GetSizeX** method gets the current size x value. The flying size is a multiple of the original key size.

Syntax

HRESULT GetSizeX (double* multiplierX);

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierX | out | The current size x value. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The multiplierX parameter is invalid. |

5.2.12.7 **IBMDSwitcherKeyFlyParameters::SetSizeX method**

The **SetSizeX** method sets the size x value. The flying size is a multiple of the original key size.

Syntax

HRESULT SetSizeX (double multiplierX);

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierX | in | The desired size x value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.8 IBMDSwitcherKeyFlyParameters::GetSizeY method

The **GetSizeY** method gets the current size y value. The flying size is a multiple of the original key size.

Syntax

```
HRESULT GetSizeY (double* multiplierY);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierY | out | The current size y value. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The multiplierY parameter is invalid. |

5.2.12.9 IBMDSwitcherKeyFlyParameters::SetSizeY method

The **SetSizeY** method sets the size y value. The flying size is a multiple of the original key size.

Syntax

HRESULT SetSizeY (double multiplierY);

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierY | in | The desired size y value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.10 IBMDSwitcherKeyFlyParameters::GetPositionX method

The **GetPositionX** method gets the current position x value. This is an offset from the original key position.

Syntax

```
HRESULT GetPositionX (double* offsetX);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| offsetX | out | The current offset x value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The offsetX parameter is invalid. |

5.2.12.11 IBMDSwitcherKeyFlyParameters::SetPositionX method

The **SetPositionX** method sets the position x value. This is an offset from the original key position.

Syntax

HRESULT SetPositionX (double offsetX);

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| offsetX | in | The desired position x value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.12 IBMDSwitcherKeyFlyParameters::GetPositionY method

The **GetPositionY** method gets the current position y value. This is an offset from the original key position.

Syntax

HRESULT GetPositionY (double* offsetY);

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| offsetY | out | The current offset y value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The offsetY parameter is invalid. |

5.2.12.13 IBMDSwitcherKeyFlyParameters::SetPositionY method

The **SetPositionY** method sets the position y value. This is an offset from the original key position.

Syntax

```
HRESULT SetPositionY (double offsetY);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| offsetY | in | The desired position y value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.14 IBMDSwitcherKeyFlyParameters::GetRotation method

The **GetRotation** method gets the current rotation value.

Syntax

```
HRESULT GetRotation (double* degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| degrees | out | The current rotation value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The degrees parameter is invalid. |

5.2.12.15 IBMDSwitcherKeyFlyParameters::SetRotation method

The **SetRotation** method sets the rotation value.

Syntax

```
HRESULT SetRotation (double degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| degrees | in | The desired rotation value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.16 IBMDSwitcherKeyFlyParameters::ResetRotation method

The **ResetRotation** method resets the rotation value to its default.

Syntax

```
HRESULT ResetRotation (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.17 IBMDSwitcherKeyFlyParameters::ResetDVE method

The **ResetDVE** method resets the DVE parameters to their default values, i.e. size, position and rotation.

Syntax

```
HRESULT ResetDVE (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.18 IBMDSwitcherKeyFlyParameters::ResetDVEFull method

The **ResetDVEFull** method resets the key fly parameters to full screen with no rotation.

Syntax

```
HRESULT ResetDVEFull (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.12.19 IBMDSwitcherKeyFlyParameters::IsKeyFrameStored method

The **IsKeyFrameStored** method returns whether the specified key frame has been stored or not. It is intended for use with user-defined key frames to determine if they have been stored.

Syntax

```
HRESULT IsKeyFrameStored (BMDSwitcherFlyKeyFrame keyFrame, boolean* stored);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| keyFrame | in | Specify a single key frame of BMDSwitcherFlyKeyFrame to query the status on. |
| stored | out | The current status flag of whether the specified key frame has been stored. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The keyFrame parameter is invalid. |
| E_POINTER | The stored parameter is invalid. |

5.2.12.20 IBMDSwitcherKeyFlyParameters::StoreAsKeyFrame method

The **StoreAsKeyFrame** method stores the current frame into the specified key frame(s). Multiple user-defined key frames can be specified.

Syntax

```
HRESULT StoreAsKeyFrame (BMDSwitcherFlyKeyFrame keyFrames);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| keyFrames | in | Specify where to store the current frame, must be user-defined key frame(s). |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The keyFrames parameter is invalid. |
| E_FAIL | Failure. |

5.2.12.21 IBMDSwitcherKeyFlyParameters::RunToKeyFrame method

The **RunToKeyFrame** method commences a run from current frame to the specified key frame.

Syntax

HRESULT RunToKeyFrame (BMDSwitcherFlyKeyFrame destination);

Parameters

| Name | Direction | Description |
|-------------|-----------|----------------------------|
| destination | in | The destination key frame. |

Return Values

| Value | Description |
|--------------|---------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The destination parameter is invalid. |
| E_FAIL | Failure. |

5.2.12.22 **IBMDSwitcherKeyFlyParameters::IsAtKeyFrames method**

The **IsAtKeyFrames** method returns a bit set of key frames that match the current frame. Zero is returned if the current frame does not match any built-in or user-defined frames.

Syntax

```
HRESULT IsAtKeyFrames (BMDSwitcherFlyKeyFrame* keyFrames);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| keyFrames | out | All key frames that match the current frame. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The keyFrames parameter is invalid. |

5.2.12.23 IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters method

The **GetKeyFrameParameters** method returns an object interface for accessing individual parameters in a key frame.

Syntax

```
HRESULT GetKeyFrameParameters (BMDSwitcherFlyKeyFrame keyFrame, IBMDSwitcherKeyFlyKeyFrameParameters** keyFrameParameters);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| keyFrame | in | The desired key frame. |
| keyFrameParameters | out | IBMDSwitcherKeyFlyKeyFrameParameters object interface. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_INVALIDARG | The keyFrame parameter is invalid. |
| E_POINTER | The keyFrameParameters parameter is invalid. |

5.2.12.24 IBMDSwitcherKeyFlyParameters::IsRunning method

The **IsRunning** method returns the current run status.

Syntax

```
HRESULT IsRunning (boolean* isRunning, BMDSwitcherFlyKeyFrame* destination);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|--|
| isRunning | out | Boolean status of whether the key is running. |
| destination | out | If the key is running, this is the destination of the run. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| E_POINTER | The isRunning and/or destination parameter is invalid. |
| E_FAIL | Failure. |

5.2.12.25 IBMDSwitcherKeyFlyParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyFlyParameters** object. Pass an object implementing the **IBMDSwitcherKeyFlyParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyFlyParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyFlyParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.12.26 IBMDSwitcherKeyFlyParameters::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyFlyParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyFlyParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.13 IBMDSwitcherKeyFlyParametersCallback Interface

The **IBMDSwitcherKeyFlyParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyFlyParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------|----------------------------------|---|
| IBMDSwitcherKeyFlyParameters | IID_IBMDSwitcherKeyFlyParameters | An IBMDSwitcherKeyFlyParametersCallback object interface is installed with IBMDSwitcherKeyFlyParameters::AddCallback and removed with IBMDSwitcherKeyFlyParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.13.1 IBMDSwitcherKeyFlyParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyFlyParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT Notify (BMDSwitcherKeyFlyParametersEventType eventType, BMDSwitcherFlyKeyFrame keyFrame);

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherKeyFlyParametersEventType that describes the type of event that has occurred. |
| keyFrame | in | This parameter is only valid when eventType is bmdSwitcherKeyFlyParametersEventTypes KeyFrameStoredChanged , it specifies the changed key frame. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14 IBMDSwitcherKeyFlyKeyFrameParameters Interface

The IBMDSwitcherKeyFlyKeyFrameParameters object interface provides access to individual key frame parameters.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------|----------------------------------|---|
| IBMDSwitcherKeyFlyParameters | IID_IBMDSwitcherKeyFlyParameters | An IBMDSwitcherKeyFlyKeyFrameParameters object interface can be obtained from IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters . |

| Public Member Functions | |
|-------------------------|--------------------------------------|
| Method | Description |
| GetSizeX | Get the size x value. |
| SetSizeX | Set the size x value. |
| GetSizeY | Get the size y value. |
| SetSizeY | Set the size y value. |
| GetPositionX | Get the position x value. |
| SetPositionX | Set the position x value. |
| GetPositionY | Get the position y value. |
| SetPositionY | Set the position y value. |
| GetRotation | Get the rotation value. |
| SetRotation | Set the rotation value. |
| GetBorderWidthOut | Get the border outer width value. |
| SetBorderWidthOut | Set the border outer width value. |
| GetBorderWidthIn | Get the border inner width value. |
| SetBorderWidthIn | Set the border inner width value. |
| GetBorderSoftnessOut | Get the border outer softness value. |

| Public Member Functions | |
|-------------------------------|--|
| Method | Description |
| SetBorderSoftnessOut | Set the border outer softness value. |
| GetBorderSoftnessIn | Get the border inner softness value. |
| SetBorderSoftnessIn | Set the border inner softness value. |
| GetBorderBevelSoftness | Get the border bevel softness value. |
| SetBorderBevelSoftness | Set the border bevel softness value. |
| GetBorderBevelPosition | Get the border bevel position value. |
| SetBorderBevelPosition | Set the border bevel position value. |
| GetBorderOpacity | Get the border opacity value. |
| SetBorderOpacity | Set the border opacity value. |
| GetBorderHue | Get the border hue value. |
| SetBorderHue | Set the border hue value. |
| GetBorderSaturation | Get the border saturation value. |
| SetBorderSaturation | Set the border saturation value. |
| GetBorderLuma | Get the border luminance value. |
| SetBorderLuma | Set the border luminance value. |
| GetBorderLightSourceDirection | Get the border light source direction value. |
| SetBorderLightSourceDirection | Set the border light source direction value. |
| GetBorderLightSourceAltitude | Get the border light source altitude value. |
| SetBorderLightSourceAltitude | Set the border light source altitude value. |
| GetMaskTop | Get the mask top value. |
| SetMaskTop | Set the mask top value. |
| GetMaskBottom | Get the mask bottom value. |
| SetMaskBottom | Set the mask bottom value. |

| Public Member Functions | |
|-------------------------|---------------------------|
| Method | Description |
| GetMaskLeft | Get the mask left value. |
| SetMaskLeft | Set the mask left value. |
| GetMaskRight | Get the mask right value. |
| SetMaskRight | Set the mask right value. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.14.1 **IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeX** method

The **GetSizeX** method gets the size x value.

Syntax

```
HRESULT GetSizeX (double* multiplierX);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierX | out | The current size x value. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The multiplierX parameter is invalid. |

5.2.14.2 **IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeX** method

The **SetSizeX** method sets the size x value.

Syntax

```
HRESULT SetSizeX (double multiplierX);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierX | in | The desired size x value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.3 **IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeY** method

The **GetSizeY** method gets the size y value.

Syntax

```
HRESULT GetSizeY (double* multiplierY);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|-------------------|
| multiplierY | out | The size y value. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The multiplierY parameter is invalid. |

5.2.14.4 **IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeY** method

The **SetSizeY** method sets the size y value.

Syntax

```
HRESULT SetSizeY (double multiplierY);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| multiplierY | in | The desired size y value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.5 **IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionX** method

The **GetPositionX** method gets the position x value.

Syntax

HRESULT `GetPositionX (double* offsetX);`

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------|
| offsetX | out | The position x value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The offsetX parameter is invalid. |

5.2.14.6 **IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionX** method

The **SetPositionX** method sets the position x value.

Syntax

HRESULT `SetPositionX (double offsetX);`

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| offsetX | in | The desired position x value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.7 **IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionY** method

The **GetPositionY** method gets the position y value.

Syntax

```
HRESULT GetPositionY (double* offsetY);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------|
| offsetY | out | The position y value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The offsetY parameter is invalid. |

5.2.14.8 **IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionY** method

The **SetPositionY** method sets the position y value.

Syntax

```
HRESULT SetPositionY (double offsetY);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| offsetY | in | The desired position y value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.9 IBMDSwitcherKeyFlyKeyFrameParameters::GetRotation method

The **GetRotation** method gets the rotation value.

Syntax

```
HRESULT GetRotation (double* degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------|
| degrees | out | The rotation value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The degrees parameter is invalid. |

5.2.14.10 IBMDSwitcherKeyFlyKeyFrameParameters::SetRotation method

The **SetRotation** method sets the rotation value.

Syntax

```
HRESULT SetRotation (double degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| degrees | in | The desired rotation value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.11 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthOut** method

The **GetBorderWidthOut** method gets the border outer width value.

Syntax

```
HRESULT GetBorderWidthOut (double* widthOut);
```

Parameters

| Name | Direction | Description |
|----------|-----------|-------------------------------|
| widthOut | out | The border outer width value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The widthOut parameter is invalid. |

5.2.14.12 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthOut** method

The **SetBorderWidthOut** method sets the border outer width value.

Syntax

```
HRESULT SetBorderWidthOut (double widthOut);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---------------------------------------|
| widthOut | in | The desired border outer width value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.13 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthIn** method

The **GetBorderWidthIn** method gets the border inner width value.

Syntax

```
HRESULT GetBorderWidthIn (double* widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-------------------------------|
| widthIn | out | The border inner width value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The widthIn parameter is invalid. |

5.2.14.14 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthIn** method

The **SetBorderWidthIn** method sets the border inner width value.

Syntax

```
HRESULT SetBorderWidthIn (double widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------------|
| widthIn | in | The desired border inner width value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.15 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessOut method

The **GetBorderSoftnessOut** method gets the border outer softness value.

Syntax

```
HRESULT GetBorderSoftnessOut (double* softOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------------|
| softOut | out | The border outer softness value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The softOut parameter is invalid. |

5.2.14.16 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessOut method

The **SetBorderSoftnessOut** method sets the border outer softness value.

Syntax

```
HRESULT SetBorderSoftnessOut (double softOut);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| softOut | in | The desired border outer softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.17 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessIn method

The **GetBorderSoftnessIn** method gets the border inner softness value.

Syntax

```
HRESULT GetBorderSoftnessIn (double* softIn);
```

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------------------|
| softIn | out | The border inner softness value. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The softIn parameter is invalid. |

5.2.14.18 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessIn method

The **SetBorderSoftnessIn** method sets the border inner softness value.

Syntax

```
HRESULT SetBorderSoftnessIn (double softIn);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--|
| softIn | in | The desired border inner softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.19 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelSoftness** method

The **GetBorderBevelSoftness** method gets the border bevel softness value.

Syntax

```
HRESULT GetBorderBevelSoftness (double* bevelSoft);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|----------------------------------|
| bevelSoft | out | The border bevel softness value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The bevelSoft parameter is invalid. |

5.2.14.20 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelSoftness** method

The **SetBorderBevelSoftness** method sets the border bevel softness value.

Syntax

```
HRESULT SetBorderBevelSoftness (double bevelSoft);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| bevelSoft | in | The desired border bevel softness value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.21 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelPosition method

The **GetBorderBevelPosition** method gets the border bevel position value.

Syntax

HRESULT GetBorderBevelPosition (double* bevelPosition);

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| bevelPosition | out | The border bevel position value. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The bevelPosition parameter is invalid. |

5.2.14.22 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelPosition method

The **SetBorderBevelPosition** method sets the border bevel position value.

Syntax

HRESULT SetBorderBevelPosition (double bevelPosition);

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| bevelPosition | in | The desired border bevel position value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.23 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderOpacity method

The **GetBorderOpacity** method gets the border opacity value.

Syntax

```
HRESULT GetBorderOpacity (double* opacity);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| opacity | out | The border opacity value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The opacity parameter is invalid. |

5.2.14.24 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderOpacity method

The **SetBorderOpacity** method sets the border opacity value.

Syntax

```
HRESULT SetBorderOpacity (double opacity);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------------|
| opacity | in | The desired border opacity value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.25 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderHue method

The **GetBorderHue** method gets the border hue value.

Syntax

```
HRESULT GetBorderHue (double* hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| hue | out | The border hue value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The hue parameter is invalid. |

5.2.14.26 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderHue method

The **SetBorderHue** method sets the border hue value.

Syntax

```
HRESULT SetBorderHue (double hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------|
| hue | in | The desired border hue value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.27 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSaturation** method

The **GetBorderSaturation** method gets the border saturation value.

Syntax

```
HRESULT GetBorderSaturation (double* sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------------|
| sat | out | The border saturation value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The sat parameter is invalid. |

5.2.14.28 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSaturation** method

The **SetBorderSaturation** method sets the border saturation value.

Syntax

```
HRESULT SetBorderSaturation (double sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------------------|
| sat | in | The desired border saturation value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.29 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLuma method

The **GetBorderLuma** method gets the border luminance value.

Syntax

```
HRESULT GetBorderLuma (double* luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------------|
| luma | out | The border luminance value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The luma parameter is invalid. |

5.2.14.30 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLuma method

The **SetBorderLuma** method sets the border luminance value.

Syntax

```
HRESULT SetBorderLuma (double luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------------------|
| luma | in | The desired border luminance value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.31 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceDirection method

The **GetBorderLightSourceDirection** method gets the border light source direction value.

Syntax

```
HRESULT GetBorderLightSourceDirection (double* degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| degrees | out | The border light source direction in degrees. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The degrees parameter is invalid. |

5.2.14.32 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceDirection method

The **SetBorderLightSourceDirection** method sets the border light source direction value.

Syntax

HRESULT SetBorderLightSourceDirection (double degrees);

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| degrees | in | The desired border light source direction value in degrees. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.33 IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceAltitude method

The **GetBorderLightSourceAltitude** method gets the border light source altitude value.

Syntax

HRESULT GetBorderLightSourceAltitude (double* altitude);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| altitude | out | The border light source altitude value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The altitude parameter is invalid. |

5.2.14.34 IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceAltitude method

The **SetBorderLightSourceAltitude** method sets the border light source altitude value.

Syntax

HRESULT SetBorderLightSourceAltitude (double altitude);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| altitude | in | The desired border light source altitude value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.35 IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskTop method

The **GetMaskTop** method returns the mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------|
| maskTop | out | The mask top value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The maskTop parameter is invalid. |

5.2.14.36 IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskTop method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | in | The desired mask top value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.37 IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskBottom method

The **GetMaskBottom** method returns the mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|------------------------|
| maskBottom | out | The mask bottom value. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskBottom parameter is invalid. |

5.2.14.38 IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskBottom method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | in | The desired mask bottom value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.39 **IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskLeft** method

The **GetMaskLeft** method returns the mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|----------------------|
| maskLeft | out | The mask left value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskLeft parameter is invalid. |

5.2.14.40 **IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskLeft** method

The **SetMaskLeft** method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | in | The desired mask left value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.41 IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskRight method

The **GetMaskRight** method returns the mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------|
| maskRight | out | The mask right value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskRight parameter is invalid. |

5.2.14.42 IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskRight method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | in | The desired mask right value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.14.43 IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyFlyKeyFrameParameters** object. Pass an object implementing the **IBMDSwitcherKeyFlyKeyFrameParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

HRESULT AddCallback (IBMDSwitcherKeyFlyKeyFrameParametersCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.14.44 IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyFlyKeyFrameParametersCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.15 IBMDSwitcherKeyFlyKeyFrameParametersCallback Interface

The **IBMDSwitcherKeyFlyKeyFrameParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyFlyKeyFrameParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------------------|--|---|
| IBMDSwitcherKeyFlyKeyFrameParameters | IID_ IBMDSwitcherKeyFlyKeyFrame Parameters | An IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface is installed with IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback and removed with IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

5.2.15.1 IBMDSwitcherKeyFlyKeyFrameParametersCallback::Notify method

The Notify method is called when **IBMDSwitcherKeyFlyKeyFrameParameters** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT Notify (BMDSwitcherKeyFlyKeyFrameParametersEventType eventType);

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherKeyFlyKeyFrameParametersEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.16 IBMDSwitcherDownstreamKeylterator Interface

The **IBMDSwitcherDownstreamKeylterator** is used to enumerate the available downstream keys.

A reference to an **IBMDSwitcherDownstreamKeylterator** object interface may be obtained from an **IBMDSwitcher** object interface using the **Createrlterator** method. Pass **IID_IBMDSwitcherDownstreamKeylterator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::Createrlterator can return an IBMDSwitcherDownstreamKeylterator object interface. |

Public Member Functions

| Method | Description |
|--------|--|
| Next | Returns a pointer to the next IBMDSwitcherDownstreamKey object interface. |

5.2.16.1 IBMDSwitcherDownstreamKeyIterator::Next method

The **Next** method returns the next available **IBMDSwitcherDownstreamKey** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherDownstreamKey** downstreamKey);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| downstreamKey | out | IBMDSwitcherDownstreamKey object interface. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherDownstreamKey objects available. |
| E_POINTER | The downstreamKey parameter is invalid. |

5.2.17 **IBMDSwitcherDownstreamKey Interface**

The **IBMDSwitcherDownstreamKey** object interface is used for managing the settings of a downstream key.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------------------|---------------------------------------|---|
| IBMDSwitcherDownstreamKeyIterator | IID_IBMDSwitcherDownstreamKeyIterator | An IBMDSwitcherDownstreamKey object will be returned after a successful call to IBMDSwitcherDownstreamKeyIterator::Next method. |

| Public Member Functions | |
|------------------------------|--|
| Method | Description |
| GetInputCut | Get the current cut input source. |
| SetInputCut | Set the cut input source. |
| GetInputFill | Get the current fill input source. |
| SetInputFill | Set the fill input source. |
| GetFillInputAvailabilityMask | Get the availability mask for the fill of this input. |
| GetCutInputAvailabilityMask | Get the availability mask for the cut of this input. |
| GetTie | Get the current tie flag. |
| SetTie | Set the tie flag. |
| GetRate | Get the current rate value. |
| SetRate | Set the rate value. |
| GetOnAir | Get the current on-air flag. |
| SetOnAir | Set the on-air flag. |
| PerformAutoTransition | Perform an auto-transition. |
| IsTransitioning | Determines if this downstream key is transitioning. |
| IsAutoTransitioning | Determines if this downstream key is auto-transitioning. |

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetFramesRemaining | Get the number of frames remaining in the transition. |
| GetPreMultiplied | Get the current pre-multiplied flag. |
| SetPreMultiplied | Set the pre-multiplied flag. |
| GetClip | Get the current clip value. |
| SetClip | Set the clip value. |
| GetGain | Get the current gain value. |
| SetGain | Set the gain value. |
| GetInverse | Get the current inverse flag. |
| SetInverse | Set the inverse flag. |
| GetMasked | Get the current masked flag. |
| SetMasked | Set the masked flag. |
| GetMaskTop | Get the current mask top value. |
| SetMaskTop | Set the mask top value. |
| GetMaskBottom | Get the current mask bottom value. |
| SetMaskBottom | Set the mask bottom value. |
| GetMaskLeft | Get the current mask left value. |
| SetMaskLeft | Set the mask left value. |
| GetMaskRight | Get the current mask right value. |
| SetMaskRight | Set the mask right value. |
| ResetMask | Reset mask properties to default. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

5.2.17.1 IBMDSwitcherDownstreamKey::GetInputCut method

The **GetInputCut** method returns the selected cut input source.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| inputId | out | BMDSwitcherInputId of the selected cut input source. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inputId parameter is invalid. |

5.2.17.2 IBMDSwitcherDownstreamKey::SetInputCut method

The **SetInputCut** method sets the cut input source.

Syntax

HRESULT SetInputCut (BMDSwitcherInputId inputId);

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | in | The desired cut input source's BMDSwitcherInputId . |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The inputId parameter is invalid. |

5.2.17.3 IBMDSwitcherDownstreamKey::GetInputFill method

The **GetInputFill** method returns the selected fill input source.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| inputId | out | BMDSwitcherInputId of the selected fill input source. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inputId parameter is invalid. |

5.2.17.4 **IBMDSwitcherDownstreamKey::SetInputFill** method

The **SetInputFill** method sets the fill input source.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId inputId);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| inputId | in | The desired fill input source's BMDSwitcherInputId . |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The inputId parameter is invalid. |

5.2.17.5 IBMDSwitcherDownstreamKey::GetFillInputAvailabilityMask method

The GetFillInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for fill inputs available to this downstream key. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this downstream key.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

5.2.17.6 IBMDSwitcherDownstreamKey::GetCutInputAvailabilityMask method

The GetCutInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this downstream key. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this downstream key.

Syntax

HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

5.2.17.7 IBMDSwitcherDownstreamKey::GetTie method

The **GetTie** method gets the current tie flag.

Syntax

```
HRESULT GetTie (boolean* tie);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| tie | out | Boolean tie flag. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The tie parameter is invalid. |

5.2.17.8 IBMDSwitcherDownstreamKey::SetTie method

The **SetTie** method sets the tie flag.

Syntax

```
HRESULT SetTie (boolean tie);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| tie | in | The desired tie flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.9 IBMDSwitcherDownstreamKey::GetRate method

The **GetRate** method gets the current rate value.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------------|
| frames | out | The current rate value in frames. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The frames parameter is invalid. |

5.2.17.10 IBMDSwitcherDownstreamKey::SetRate method

The **SetRate** method sets the rate value.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------------|
| frames | in | The desired rate value in frames. |

Return Values

| Value | Description |
|--------------|----------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The frames parameter is invalid. |
| E_FAIL | Failure. |

5.2.17.11 IBMDSwitcherDownstreamKey::GetOnAir method

The **GetOnAir** method returns the on-air flag.

Syntax

```
HRESULT GetOnAir (boolean* onAir);
```

Parameters

| Name | Direction | Description |
|-------|-----------|----------------------|
| onAir | out | Boolean on-air flag. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The onAir parameter is invalid. |

5.2.17.12 IBMDSwitcherDownstreamKey::SetOnAir method

The **SetOnAir** method sets the on-air flag.

Syntax

```
HRESULT SetOnAir (boolean onAir);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------------------|
| onAir | in | The desired on-air flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.13 IBMDSwitcherDownstreamKey::PerformAutoTransition method

Use the **PerformAutoTransition** method to start an auto-transition.

Syntax

```
HRESULT PerformAutoTransition (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.14 IBMDSwitcherDownstreamKey::IsTransitioning method

The **IsTransitioning** method returns whether this downstream key is transitioning or not.

Syntax

```
HRESULT IsTransitioning (boolean* isTransitioning);
```

Parameters

| Name | Direction | Description |
|-----------------|-----------|--|
| isTransitioning | out | Boolean status of whether it is transitioning. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The isTransitioning parameter is invalid. |

5.2.17.15 **IBMDSwitcherDownstreamKey::IsAutoTransitioning** method

The **IsAutoTransitioning** method returns whether this downstream key is auto-transitioning or not.

Syntax

```
HRESULT IsAutoTransitioning (boolean* isAutoTransitioning);
```

Parameters

| Name | Direction | Description |
|---------------------|-----------|---|
| isAutoTransitioning | out | Boolean status of whether it is auto-transitioning. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The isAutoTransitioning parameter is invalid. |

5.2.17.16 **IBMDSwitcherDownstreamKey::GetFramesRemaining** method

The **GetFramesRemaining** method gets the number of frames remaining in the transition.

Syntax

```
HRESULT GetFramesRemaining (uint32_t* framesRemaining);
```

Parameters

| Name | Direction | Description |
|-----------------|-----------|---|
| framesRemaining | out | Number of frames remaining in the transition. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The framesRemaining parameter is invalid. |

5.2.17.17 IBMDSwitcherDownstreamKey::GetPreMultiplied method

The **GetPreMultiplied** method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | out | The current pre-multiplied flag. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The preMultiplied parameter is invalid. |

5.2.17.18 IBMDSwitcherDownstreamKey::SetPreMultiplied method

The **SetPreMultiplied** method sets the pre-multiplied flag. Note that clip, gain and inverse controls are not used when pre-multiplied flag is set to true.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | in | The desired pre-multiplied flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.19 **IBMDSwitcherDownstreamKey::GetClip** method

The **GetClip** method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | out | The current clip value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The clip parameter is invalid. |

5.2.17.20 **IBMDSwitcherDownstreamKey::SetClip** method

The **SetClip** method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | in | The desired clip value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.21 **IBMDSwitcherDownstreamKey::GetGain** method

The **GetGain** method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | out | The current gain value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

5.2.17.22 **IBMDSwitcherDownstreamKey::SetGain** method

The **SetGain** method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | in | The desired gain value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.23 **IBMDSwitcherDownstreamKey::GetInverse** method

The **GetInverse** method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

5.2.17.24 **IBMDSwitcherDownstreamKey::SetInverse** method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.25 IBMDSwitcherDownstreamKey::GetMasked method

The **GetMasked** method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| masked | out | Boolean flag of whether masking is enabled. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The masked parameter is invalid. |

5.2.17.26 IBMDSwitcherDownstreamKey::SetMasked method

The **SetMasked** method enables or disables masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---------------------------|
| masked | in | The desired masked value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.27 IBMDSwitcherDownstreamKey::GetMaskTop method

The **GetMaskTop** method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | out | The current mask top value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The maskTop parameter is invalid. |

5.2.17.28 IBMDSwitcherDownstreamKey::SetMaskTop method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------------|
| maskTop | in | The desired mask top value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.29 IBMDSwitcherDownstreamKey::GetMaskBottom method

The **GetMaskBottom** method returns the current mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | out | The current mask bottom value. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskBottom parameter is invalid. |

5.2.17.30 IBMDSwitcherDownstreamKey::SetMaskBottom method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--------------------------------|
| maskBottom | in | The desired mask bottom value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.31 IBMDSwitcherDownstreamKey::GetMaskLeft method

The **GetMaskLeft** method returns the current mask left value.

Syntax

HRESULT GetMaskLeft (double* maskLeft);

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | out | The current mask left value. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskLeft parameter is invalid. |

5.2.17.32 IBMDSwitcherDownstreamKey::SetMaskLeft method

The **SetMaskLeft** method sets the mask left value.

Syntax

HRESULT SetMaskLeft (double maskLeft);

Parameters

| Name | Direction | Description |
|----------|-----------|------------------------------|
| maskLeft | in | The desired mask left value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.33 IBMDSwitcherDownstreamKey::GetMaskRight method

The **GetMaskRight** method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | out | The current mask right value. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The maskRight parameter is invalid. |

5.2.17.34 IBMDSwitcherDownstreamKey::SetMaskRight method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------------|
| maskRight | in | The desired mask right value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.35 IBMDSwitcherDownstreamKey::ResetMask method

The **ResetMask** method resets mask settings to the default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

5.2.17.36 IBMDSwitcherDownstreamKey::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherDownstreamKey** object. Pass an object implementing the **IBMDSwitcherDownstreamKeyCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherDownstreamKeyCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherDownstreamKeyCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.17.37 IBMDSwitcherDownstreamKey::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherDownstreamKeyCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherDownstreamKeyCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

5.2.18 IBMDSwitcherDownstreamKeyCallback Interface

The **IBMDSwitcherDownstreamKeyCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherDownstreamKey** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------|-------------------------------|--|
| IBMDSwitcherDownstreamKey | IID_IBMDSwitcherDownstreamKey | An IBMDSwitcherDownstreamKeyCallback object interface is installed with IBMDSwitcherDownstreamKey::AddCallback and removed with IBMDSwitcherDownstreamKey::RemoveCallback |

| Public Member Functions | |
|-------------------------|------------------------------|
| Method | Description |
| Next | Called when an event occurs. |

5.2.18.1 IBMDSwitcherDownstreamKeyCallback::Notify

The **Notify** method is called when **IBMDSwitcherDownstreamKey** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherDownstreamKeyEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| eventType | in | BMDSwitcherDownstreamKeyEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6 SuperSource

When available in the target switcher, the SuperSource allows multiple video sources to be displayed within boxes as part of a single video output.

6.1 SuperSource Data Types

6.1.1 SuperSource Box Event Type

BMDSwitcherSuperSourceBoxEventType enumerates the possible event types for **BMDSwitcherSuperSourceBox**.

| | |
|---|--------------------------------|
| bmdSwitcherSuperSourceBoxEventTypeInputSourceChanged | The source input changed. |
| bmdSwitcherSuperSourceBoxEventTypePositionXChanged | The x position changed. |
| bmdSwitcherSuperSourceBoxEventTypePositionYChanged | The y position changed. |
| bmdSwitcherSuperSourceBoxEventTypeSizeChanged | The size changed. |
| bmdSwitcherSuperSourceBoxEventTypeCroppedChanged | The cropped flag changed. |
| bmdSwitcherSuperSourceBoxEventTypeCropTopChanged | The top crop value changed. |
| bmdSwitcherSuperSourceBoxEventTypeCropBottomChanged | The bottom crop value changed. |
| bmdSwitcherSuperSourceBoxEventTypeCropLeftChanged | The left crop value changed. |
| bmdSwitcherSuperSourceBoxEventTypeCropRightChanged | The right crop value changed. |

6.1.2 SuperSource Input Event Type

BMDSwitcherInputSuperSourceEventType enumerates the possible event types for **BMDSwitcherInputSuperSource**.

| | |
|--|--|
| bmdSwitcherInputSuperSourceEventTypeInputFillChanged | The fill input changed. |
| bmdSwitcherInputSuperSourceEventTypeInputCutChanged | The cut input changed. |
| bmdSwitcherInputSuperSourceEventTypeArtOptionChanged | The art option changed. |
| bmdSwitcherInputSuperSourceEventTypePreMultipliedChanged | The pre-multiplied flag changed. |
| bmdSwitcherInputSuperSourceEventTypeClipChanged | The clip value changed. |
| bmdSwitcherInputSuperSourceEventTypeGainChanged | The gain changed. |
| bmdSwitcherInputSuperSourceEventTypeInverseChanged | The inverse flag changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderEnabledChanged | The border enabled flag changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderBevelChanged | The border bevel changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderWidthOutChanged | The border outer width changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderWidthInChanged | The border inner width changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderSoftnessOutChanged | The border outer softness changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderSoftnessInChanged | The border inner softness changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderBevelSoftnessChanged | The border bevel softness changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderBevelPositionChanged | The border bevel position changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderHueChanged | The border hue changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderSaturationChanged | The border saturation changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderLumaChanged | The border luminescence changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderLightSourceDirectionChanged | The border light source direction changed. |
| bmdSwitcherInputSuperSourceEventTypeBorderLightSourceAltitudeChanged | The border light source altitude changed. |

6.1.3 SuperSource Art Option

BMDSwitcherSuperSourceArtOption enumerates the possible supersource art options, used by the **IBMDSwitcherInputSuperSource** object interface.

bmdSwitcherSuperSourceArtOptionBackground
bmdSwitcherSuperSourceArtOptionForeground

Places art in the background.
Places art in the foreground.

6.2 Interface Reference

6.2.1 **IBMDSwitcherInputSuperSource** Interface

The **IBMDSwitcherInputSuperSource** object interface is used for manipulating settings specific to the SuperSource input.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------|-----------------------|---|
| IBMDSwitcherInput | IID_IBMDSwitcherInput | An IBMDSwitcherInputSuperSource object interface can be obtained with IBMDSwitcherInput::QueryInterface . |

| Public Member Functions | |
|------------------------------|---|
| Method | Description |
| GetInputCut | Get the current art cut input. |
| SetInputCut | Set the art cut input. |
| GetInputFill | Get the current art fill input. |
| SetInputFill | Set the art fill input. |
| GetFillInputAvailabilityMask | Get the availability mask for the fill of this input. |
| GetCutInputAvailabilityMask | Get the availability mask for the cut of this input. |
| GetArtOption | Get the current art option. |
| SetArtOption | Set the art option. |
| GetPreMultiplied | Get the current art pre-multiplied flag. |
| SetPreMultiplied | Set the art pre-multiplied flag. |
| GetClip | Get the current art clip value. |
| SetClip | Set the art clip value. |
| GetGain | Get the current art gain. |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| SetGain | Set the art gain. |
| GetInverse | Get the current art inverse flag. |
| SetInverse | Set the art inverse flag. |
| GetBorderEnabled | Get the current border enabled flag. |
| SetBorderEnabled | Set the border enabled flag. |
| GetBorderBevel | Get the current border bevel. |
| SetBorderBevel | Set the border bevel. |
| GetBorderWidthOut | Get the current border outer width. |
| SetBorderWidthOut | Set the border outer width. |
| GetBorderWidthIn | Get the current border inner width. |
| SetBorderWidthIn | Set the border inner width. |
| GetBorderSoftnessOut | Get the current border outer softness. |
| SetBorderSoftnessOut | Set the border outer softness. |
| GetBorderSoftnessIn | Get the current border inner softness. |
| SetBorderSoftnessIn | Set the border inner softness. |
| GetBorderBevelSoftness | Get the current border bevel softness. |
| SetBorderBevelSoftness | Set the border bevel softness. |
| GetBorderBevelPosition | Get the current border bevel position. |
| SetBorderBevelPosition | Set the border bevel position. |
| GetBorderHue | Get the current border hue. |
| SetBorderHue | Set the border hue. |
| GetBorderSaturation | Get the current border saturation. |
| SetBorderSaturation | Set the border saturation. |

| Public Member Functions | |
|-------------------------------|--|
| Method | Description |
| GetBorderLuma | Get the current border luminescence. |
| SetBorderLuma | Set the border luminescence. |
| GetBorderLightSourceDirection | Get the current border light source direction. |
| SetBorderLightSourceDirection | Set the border light source direction. |
| GetBorderLightSourceAltitude | Get the current border light source altitude. |
| SetBorderLightSourceAltitude | Set the border light source altitude. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |
| CreateIterator | Creates an iterator. |

6.2.1.1 IBMDSwitcherInputSuperSource::GetInputCut method

The **GetInputCut** method returns the current art cut input.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | out | The current cut input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

6.2.1.2 IBMDSwitcherInputSuperSource::SetInputCut method

The **SetInputCut** method sets the art cut input.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|------------------------|
| input | in | The desired cut input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

6.2.1.3 IBMDSwitcherInputSuperSource::GetInputFill method

The **GetInputFill** method returns the current art fill input.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------|
| input | out | The current fill input. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

6.2.1.4 IBMDSwitcherInputSuperSource::SetInputFill method

The **SetInputFill** method sets the art fill input.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------|
| input | in | The desired fill input. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

6.2.1.5 IBMDSwitcherInputSuperSource::GetFillInputAvailabilityMask method

The GetFillInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for fill inputs available to this supersource input. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this supersource.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

6.2.1.6 **IBMDSwitcherInputSuperSource::GetCutInputAvailabilityMask** method

The GetCutInputAvailabilityMask method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this supersource input. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this supersource.

Syntax

HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask. |

Return Values

| Value | Description |
|-----------|-------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter. |

6.2.1.7 IBMDSwitcherInputSuperSource::GetArtOption method

The **GetArtOption** method returns the current art option.

Syntax

```
HRESULT GetArtOption (BMDSwitcherSuperSourceArtOption* artOption);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| artOption | out | The current art option. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The artOption parameter is invalid. |

6.2.1.8 IBMDSwitcherInputSuperSource::SetArtOption method

The **SetArtOption** method sets the art option.

Syntax

```
HRESULT SetArtOption (BMDSwitcherSuperSourceArtOption artOption);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| artOption | in | The desired art option. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The artOption parameter is invalid. |

6.2.1.9 IBMDSwitcherInputSuperSource::GetPreMultiplied method

The **GetPreMultiplied** method returns the current art pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | out | The current pre-multiplied flag. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The preMultiplied parameter is invalid. |

6.2.1.10 IBMDSwitcherInputSuperSource::SetPreMultiplied method

The **SetPreMultiplied** method sets the art pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|----------------------------------|
| preMultiplied | in | The desired pre-multiplied flag. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The preMultiplied parameter is invalid. |

6.2.1.11 IBMDSwitcherInputSuperSource::GetClip method

The **GetClip** method returns the current art clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | out | The current clip value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The clip parameter is invalid. |

6.2.1.12 IBMDSwitcherInputSuperSource::SetClip method

The **SetClip** method sets the art clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| clip | in | The desired clip value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.13 IBMDSwitcherInputSuperSource::GetGain method

The **GetGain** method returns the current art gain.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | out | The current gain. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

6.2.1.14 IBMDSwitcherInputSuperSource::SetGain method

The **SetGain** method sets the art gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| gain | in | The desired gain. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.15 IBMDSwitcherInputSuperSource::GetInverse method

The **GetInverse** method returns the current art inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | out | The current inverse flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The inverse parameter is invalid. |

6.2.1.16 IBMDSwitcherInputSuperSource::SetInverse method

The **SetInverse** method sets the art inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| inverse | in | The desired inverse flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.17 IBMDSwitcherInputSuperSource::GetBorderEnabled method

The **GetBorderEnabled** method returns the current border enabled flag.

Syntax

```
HRESULT GetBorderEnabled (boolean* enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------------|
| enabled | out | The current border enabled flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The enabled parameter is invalid. |

6.2.1.18 IBMDSwitcherInputSuperSource::SetBorderEnabled method

The **SetBorderEnabled** method sets the border enabled flag.

Syntax

```
HRESULT SetBorderEnabled (boolean enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------|
| enabled | in | The desired border enabled flag |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.19 IBMDSwitcherInputSuperSource::GetBorderBevel method

The **GetBorderBevel** method returns the current border bevel option.

Syntax

```
HRESULT GetBorderBevel (BMDSwitcherBorderBevelOption* bevelOption);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|----------------------------------|
| bevelOption | out | The current border bevel option. |

Return Values

| Value | Description |
|--------------|---------------------------------------|
| S_OK | Success. |
| E_UNEXPECTED | Unexpected error occurred. |
| E_POINTER | The bevelOption parameter is invalid. |

6.2.1.20 IBMDSwitcherInputSuperSource::SetBorderBevel method

The **SetBorderBevel** method sets the border bevel option.

Syntax

```
HRESULT SetBorderBevel (BMDSwitcherBorderBevelOption bevelOption);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|----------------------------------|
| bevelOption | in | The desired border bevel option. |

Return Values

| Value | Description |
|--------------|---------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The bevelOption parameter is invalid. |
| E_FAIL | Failure. |

6.2.1.21 IBMDSwitcherInputSuperSource::GetBorderWidthOut method

The **GetBorderWidthOut** method returns the current border outer width.

Syntax

```
HRESULT GetBorderWidthOut (double* widthOut);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---------------------------------|
| widthOut | out | The current border outer width. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The widthOut parameter is invalid. |

6.2.1.22 IBMDSwitcherInputSuperSource::SetBorderWidthOut method

The **SetBorderWidthOut** method sets the border outer width.

Syntax

```
HRESULT SetBorderWidthOut (double widthOut);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---------------------------------|
| widthOut | in | The desired border outer width. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.23 IBMDSwitcherInputSuperSource::GetBorderWidthIn method

The **GetBorderWidthIn** method returns the current border inner width.

Syntax

```
HRESULT GetBorderWidthIn (double* widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------|
| widthIn | out | The current border inner width. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The widthIn parameter is invalid. |

6.2.1.24 IBMDSwitcherInputSuperSource::SetBorderWidthIn method

The **SetBorderWidthIn** method sets the border inner width.

Syntax

```
HRESULT SetBorderWidthIn (double widthIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------------|
| widthIn | in | The desired border inner width. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.25 IBMDSwitcherInputSuperSource::GetBorderSoftnessOut method

The **GetBorderSoftnessOut** method returns the current border outer softness.

Syntax

```
HRESULT GetBorderSoftnessOut (double* softnessOut);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|------------------------------------|
| softnessOut | out | The current border outer softness. |

Return Values

| Value | Description |
|-----------|---------------------------------------|
| S_OK | Success. |
| E_POINTER | The softnessOut parameter is invalid. |

6.2.1.26 IBMDSwitcherInputSuperSource::SetBorderSoftnessOut method

The **SetBorderSoftnessOut** method sets the border outer softness.

Syntax

```
HRESULT SetBorderSoftnessOut (double softnessOut);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|------------------------------------|
| softnessOut | in | The desired border outer softness. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.27 IBMDSwitcherInputSuperSource::GetBorderSoftnessIn method

The **GetBorderSoftnessIn** method returns the current border inner softness.

Syntax

```
HRESULT GetBorderSoftnessIn (double* softnessIn);
```

Parameters

| Name | Direction | Description |
|------------|-----------|------------------------------------|
| softnessIn | out | The current border inner softness. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The softnessIn parameter is invalid. |

6.2.1.28 IBMDSwitcherInputSuperSource::SetBorderSoftnessIn method

The **SetBorderSoftnessIn** method sets the border inner softness.

Syntax

```
HRESULT SetBorderSoftnessIn (double softnessIn);
```

Parameters

| Name | Direction | Description |
|------------|-----------|------------------------------------|
| softnessIn | in | The desired border inner softness. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.29 IBMDSwitcherInputSuperSource::GetBorderBevelSoftness method

The **GetBorderBevelSoftness** method returns the current border bevel softness.

Syntax

```
HRESULT GetBorderBevelSoftness (double* bevelSoftness);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|------------------------------------|
| bevelSoftness | out | The current border bevel softness. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The bevelSoftness parameter is invalid. |

6.2.1.30 IBMDSwitcherInputSuperSource::SetBorderBevelSoftness method

The **SetBorderBevelSoftness** method sets the border bevel softness.

Syntax

```
HRESULT SetBorderBevelSoftness (double bevelSoftness);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|------------------------------------|
| bevelSoftness | in | The desired border bevel softness. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.31 IBMDSwitcherInputSuperSource::GetBorderBevelPosition method

The **GetBorderBevelPosition** method returns the current border bevel position.

Syntax

```
HRESULT GetBorderBevelPosition (double* bevelPosition);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|------------------------------------|
| bevelPosition | out | The current border bevel position. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The bevelPosition parameter is invalid. |

6.2.1.32 IBMDSwitcherInputSuperSource::SetBorderBevelPosition method

The **SetBorderBevelPosition** method sets the border bevel position.

Syntax

```
HRESULT SetBorderBevelPosition (double bevelPosition);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|------------------------------------|
| bevelPosition | in | The desired border bevel position. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.33 IBMDSwitcherInputSuperSource::GetBorderHue method

The **GetBorderHue** method returns the current border hue.

Syntax

```
HRESULT GetBorderHue (double* hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| hue | out | The current border hue. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The hue parameter is invalid. |

6.2.1.34 IBMDSwitcherInputSuperSource::SetBorderHue method

The **SetBorderHue** method sets the border hue.

Syntax

```
HRESULT SetBorderHue (double hue);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| hue | in | The desired border hue. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.35 IBMDSwitcherInputSuperSource::GetBorderSaturation method

The **GetBorderSaturation** method returns the current border saturation.

Syntax

```
HRESULT GetBorderSaturation (double* sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------------|
| sat | out | The current border saturation. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The sat parameter is invalid. |

6.2.1.36 IBMDSwitcherInputSuperSource::SetBorderSaturation method

The **SetBorderSaturation** method sets the border saturation.

Syntax

```
HRESULT SetBorderSaturation (double sat);
```

Parameters

| Name | Direction | Description |
|------|-----------|--------------------------------|
| sat | in | The desired border saturation. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.37 IBMDSwitcherInputSuperSource::GetBorderLuma method

The **GetBorderLuma** method returns the current border luminescence.

Syntax

```
HRESULT GetBorderLuma (double* luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|----------------------------------|
| luma | out | The current border luminescence. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The luma parameter is invalid. |

6.2.1.38 IBMDSwitcherInputSuperSource::SetBorderLuma method

The **SetBorderLuma** method sets the border luminescence.

Syntax

```
HRESULT SetBorderLuma (double luma);
```

Parameters

| Name | Direction | Description |
|------|-----------|----------------------------------|
| luma | in | The desired border luminescence. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.39 IBMDSwitcherInputSuperSource::GetBorderLightSourceDirection method

The **GetBorderLightSourceDirection** method returns the current border light source direction.

Syntax

```
HRESULT GetBorderLightSourceDirection (double* degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| degrees | out | The current border light source direction in degrees. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The degrees parameter is invalid. |

6.2.1.40 IBMDSwitcherInputSuperSource::SetBorderLightSourceDirection method

The **SetBorderLightSourceDirection** method sets the border light source direction.

Syntax

```
HRESULT SetBorderLightSourceDirection (double degrees);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---|
| degrees | in | The desired border light source direction in degrees. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.41 IBMDSwitcherInputSuperSource::GetBorderLightSourceAltitude method

The **GetBorderLightSourceAltitude** method returns the current border light source altitude.

Syntax

```
HRESULT GetBorderLightSourceAltitude (double* altitude);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| altitude | out | The current border light source altitude. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| S_OK | Success. |
| E_POINTER | The altitude parameter is invalid. |

6.2.1.42 IBMDSwitcherInputSuperSource::SetBorderLightSourceAltitude method

The **SetBorderLightSourceAltitude** method sets the border light source altitude.

Syntax

```
HRESULT SetBorderLightSourceAltitude (double altitude);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| altitude | in | The desired border light source altitude. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.1.43 IBMDSwitcherInputSuperSource::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherInputSuperSource** object. Pass an object implementing the **IBMDSwitcherInputSuperSourceCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputSuperSourceCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputSuperSourceCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

6.2.1.44 IBMDSwitcherInputSuperSource::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputSuperSourceCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherInputSuperSourceCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

6.2.2 IBMDSwitcherInputSuperSourceCallback Interface

The **IBMDSwitcherInputSuperSourceCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherInputSuperSource** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------|----------------------------------|---|
| IBMDSwitcherInputSuperSource | IID_IBMDSwitcherInputSuperSource | An IBMDSwitcherInputSuperSourceCallback object interface is installed with IBMDSwitcherInputSuperSource::AddCallback and removed with IBMDSwitcherInputSuperSource::RemoveCallback |

| Public Member Functions | |
|-------------------------|------------------------------|
| Method | Description |
| Notify | Called when an event occurs. |

6.2.2.1 **IBMDSwitcherInputSuperSourceCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherInputSuperSource** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputSuperSourceEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherInputSuperSourceEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.3 **IBMDSwitcherSuperSourceBoxIterator** Interface

The **IBMDSwitcherSuperSourceBoxIterator** is used to enumerate the available supersource boxes for a supersource input.

A reference to an **IBMDSwitcherSuperSourceBoxIterator** object interface may be obtained from an **IBMDSwitcherInputSuperSource** object interface using the **CreateIterator** method. Pass **IID_IBMDSwitcherSuperSourceBoxIterator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------------|---|---|
| IBMDSwitcherInputSuperSource | IID_IBMDSwitcherInputSuperSource | IBMDSwitcherInputSuperSource::CreateIterator can return an IBMDSwitcherSuperSourceBoxIterator object interface. |

Public Member Functions

| Method | Description |
|-------------|---|
| Next | Returns a pointer to the next IBMDSwitcherSuperSourceBox object interface. |

6.2.3.1 **IBMDSwitcherSuperSourceBoxIterator::Next** method

The **Next** method returns the next available **IBMDSwitcherSuperSourceBox** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherSuperSourceBox** box);
```

Parameters

| Name | Direction | Description |
|------|-----------|---|
| box | out | IBMDSwitcherSuperSourceBox object interface. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherSuperSourceBox objects available. |
| E_POINTER | The box parameter is invalid. |

6.2.4 **IBMDSwitcherSuperSourceBox** Interface

The **IBMDSwitcherSuperSourceBox** object interface is used for manipulating supersource box settings.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------------------|--|---|
| IBMDSwitcherSuperSourceBoxIterator | IID_IBMDSwitcherSuperSourceBoxIterator | An IBMDSwitcherSuperSourceBox object will be returned after a successful call to IBMDSwitcherSuperSourceBoxIterator::Next method. |

| Public Member Functions | |
|-------------------------|-------------------------------|
| Method | Description |
| GetEnabled | Get the current enabled flag. |
| SetEnabled | Set the enabled flag. |
| GetInputSource | Get the input source. |
| SetInputSource | Set the input source. |
| GetPositionX | Get the x position. |
| SetPositionX | Set the x position. |
| GetPositionY | Get the y position. |
| SetPositionY | Set the y position. |
| GetSize | Get the size. |
| SetSize | Set the size. |
| GetCropped | Get the cropped flag. |
| SetCropped | Set the cropped flag. |
| GetCropTop | Get the top crop value. |
| SetCropTop | Set the top crop value. |

| Public Member Functions | |
|--------------------------|----------------------------------|
| Method | Description |
| GetCropBottom | Get the bottom crop value. |
| SetCropBottom | Set the bottom crop value. |
| GetCropLeft | Get the left crop value. |
| SetCropLeft | Set the left crop value. |
| GetCropRight | Get the right crop value. |
| SetCropRight | Set the right crop value. |
| ResetCrop | Reset to default crop values. |
| GetInputAvailabilityMask | Get the input availability mask. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

6.2.4.1 IBMDSwitcherSuperSourceBox::GetEnabled method

The **GetEnabled** method returns the current enabled flag. Enabled supersource boxes are included in the corresponding supersource input.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| enabled | out | The current enabled flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The enabled parameter is invalid. |

6.2.4.2 IBMDSwitcherSuperSourceBox::SetEnabled method

The **SetEnabled** method sets the enabled flag. Enabled supersource boxes are included in the corresponding supersource input.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| enabled | in | The desired enabled flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.3 IBMDSwitcherSuperSourceBox::GetInputSource method

The **GetInputSource** method returns the current input source.

Syntax

```
HRESULT GetInputSource (BMDSwitcherInputId* input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--|
| input | out | The current input source's BMDSwitcherInputId. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The input parameter is invalid. |

6.2.4.4 IBMDSwitcherSuperSourceBox::SetInputSource method

The **SetInputSource** method sets the input source.

Syntax

```
HRESULT SetInputSource (BMDSwitcherInputId input);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--|
| input | in | The desired input source's BMDSwitcherInputId. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The input parameter is invalid. |

6.2.4.5 IBMDSwitcherSuperSourceBox::GetPositionX method

The **GetPositionX** method returns the current x position.

Syntax

```
HRESULT GetPositionX (double* positionX);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| positionX | out | The current x position. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The positionX parameter is invalid. |

6.2.4.6 IBMDSwitcherSuperSourceBox::SetPositionX method

The **SetPositionX** method sets the x position.

Syntax

```
HRESULT SetPositionX (double positionX);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| positionX | in | The desired x position. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.7 IBMDSwitcherSuperSourceBox::GetPositionY method

The **GetPositionY** method returns the current y position.

Syntax

```
HRESULT GetPositionY (double* positionY);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| positionY | out | The current y position. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_POINTER | The positionY parameter is invalid. |

6.2.4.8 IBMDSwitcherSuperSourceBox::SetPositionY method

The **SetPositionY** method sets the y position.

Syntax

```
HRESULT SetPositionY (double positionY);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-------------------------|
| positionY | in | The desired y position. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.9 IBMDSwitcherSuperSourceBox::GetSize method

The **GetSize** method returns the current size.

Syntax

```
HRESULT GetSize (double* size);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| size | out | The current size. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The size parameter is invalid. |

6.2.4.10 IBMDSwitcherSuperSourceBox::SetSize method

The **SetSize** method sets the size.

Syntax

```
HRESULT SetSize (double size);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------|
| size | in | The desired size. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.11 IBMDSwitcherSuperSourceBox::GetCropped method

The **GetCropped** method returns the current cropped flag.

Syntax

```
HRESULT GetCropped (boolean* cropped);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| cropped | out | The current cropped flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The cropped parameter is invalid. |

6.2.4.12 IBMDSwitcherSuperSourceBox::SetCropped method

The **SetCropped** method sets the cropped flag.

Syntax

```
HRESULT SetCropped (boolean cropped);
```

Parameters

| Name | Direction | Description |
|---------|-----------|---------------------------|
| cropped | in | The desired cropped flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.13 IBMDSwitcherSuperSourceBox::GetCropTop method

The **GetCropTop** method returns the current top crop value.

Syntax

```
HRESULT GetCropTop (double* top);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------------|
| top | out | The current top crop value. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The top parameter is invalid. |

6.2.4.14 IBMDSwitcherSuperSourceBox::SetCropTop method

The **SetCropTop** method sets the top crop value.

Syntax

```
HRESULT SetCropTop (double top);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------------|
| top | in | The desired top crop value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.15 IBMDSwitcherSuperSourceBox::GetCropBottom method

The **GetCropBottom** method returns the current bottom crop value.

Syntax

```
HRESULT GetCropBottom (double* bottom);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------|
| bottom | out | The current bottom crop value. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The bottom parameter is invalid. |

6.2.4.16 IBMDSwitcherSuperSourceBox::SetCropBottom method

The **SetCropBottom** method sets the bottom crop value.

Syntax

```
HRESULT SetCropBottom (double bottom);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------|
| bottom | in | The desired bottom crop value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.17 IBMDSwitcherSuperSourceBox::GetCropLeft method

The **GetCropLeft** method returns the current left crop value.

Syntax

```
HRESULT GetCropLeft (double* left);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------------|
| left | out | The current left crop value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The left parameter is invalid. |

6.2.4.18 IBMDSwitcherSuperSourceBox::SetCropLeft method

The **SetCropLeft** method sets the left crop value.

Syntax

```
HRESULT SetCropLeft (double left);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------------|
| left | in | The desired left crop value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.19 IBMDSwitcherSuperSourceBox::GetCropRight method

The **GetCropRight** method returns the current right crop value.

Syntax

```
HRESULT GetCropRight (double* right);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------------|
| right | out | The current right crop value. |

Return Values

| Value | Description |
|-----------|---------------------------------|
| S_OK | Success. |
| E_POINTER | The right parameter is invalid. |

6.2.4.20 IBMDSwitcherSuperSourceBox::SetCropRight method

The **SetCropRight** method sets the right crop value.

Syntax

```
HRESULT SetCropRight (double right);
```

Parameters

| Name | Direction | Description |
|-------|-----------|-------------------------------|
| right | in | The desired right crop value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.21 IBMDSwitcherSuperSourceBox::ResetCrop method

The **ResetCrop** method resets the crop to default values.

Syntax

```
HRESULT ResetCrop (void);
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

6.2.4.22 IBMDSwitcherSuperSourceBox::GetInputAvailabilityMask method

The **GetInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask for this supersource box. The input availability property (**bmdSwitcherInputPropertyIdInputAvailability**) of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value to determine whether an input is available for use as a source for this supersource box.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| mask | out | BMDSwitcherInputAvailability bit mask |

Return Values

| Value | Description |
|-----------|------------------------|
| S_OK | Success. |
| E_POINTER | Invalid mask parameter |

6.2.4.23 IBMDSwitcherSuperSourceBox::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherSuperSourceBox** object. Pass an object implementing the **IBMDSwitcherSuperSourceBoxCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherSuperSourceBoxCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherSuperSourceBoxCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

6.2.4.24 IBMDSwitcherSuperSourceBox::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherSuperSourceBoxCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherSuperSourceBoxCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

6.2.5 IBMDSwitcherSuperSourceBoxCallback Interface

The **IBMDSwitcherSuperSourceBoxCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherSuperSourceBox** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------------|--------------------------------|---|
| IBMDSwitcherSuperSourceBox | IID_IBMDSwitcherSuperSourceBox | An IBMDSwitcherSuperSourceBoxCallback object interface is installed with IBMDSwitcherSuperSourceBox::AddCallback and removed with IBMDSwitcherSuperSourceBox::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

6.2.5.1 **IBMDSwitcherSuperSourceBoxCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherSuperSourceBox** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherSuperSourceBoxEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherSuperSourceBoxEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7 Audio Mixing

Every switcher allows control over how audio is to be mixed into the program output, whether it is sourced from the media players, external audio-in or embedded with the video on an input.

7.1 Audio Mixing Data Types

7.1.1 Audio Mixer Event Type

BMDSwitcherAudioMixerEventType enumerates the possible event types for the **IBMDSwitcherAudioMixerCallback** object interface.

- bmdSwitcherAudioMixerEventTypeProgramOutGainChanged** The program out gain changed.
- bmdSwitcherAudioMixerEventTypeProgramOutBalanceChanged** The program out balance changed.

7.1.2 Audio Input Identifier

BMDSwitcherAudioInputId

BMDSwitcherAudioInputId is a signed 64 bit integer type and used as a unique identifier for each audio input.

7.1.3 Audio Input Type

BMDSwitcherAudioInputType enumerates the possible input types for the **IBMDSwitcherAudioInput** object interface.

- bmdSwitcherAudioInputTypeEmbeddedWithVideo** The audio is embedded into a switcher input.
- bmdSwitcherAudioInputTypeMediaPlayer** The audio is from a media player.
- bmdSwitcherAudioInputTypeAudioIn** The audio is from an external audio-in.

7.1.4 Audio Mix Option

BMDSwitcherAudioMixOption enumerates the possible mix options for the **IBMDSwitcherAudioInput** object interface.

- bmdSwitcherAudioMixOptionOff** The audio is not to be mixed into anything.
- bmdSwitcherAudioMixOptionOn** The audio is always mixed into the output.
- bmdSwitcherAudioMixOptionAudioFollowVideo** The audio is mixed into the output when its associated video is on air.

7.1.5 Audio Input Event Type

BMDSwitcherAudioInputEventType enumerates the possible event types for the **IBMDSwitcherAudioInputCallback** object interface.

| | |
|---|---|
| bmdSwitcherAudioInputEventTypeMixOptionChanged | The mix option changed. |
| bmdSwitcherAudioInputEventTypeGainChanged | The gain changed. |
| bmdSwitcherAudioInputEventTypeBalanceChanged | The balance changed. |
| bmdSwitcherAudioInputEventTypeCurrentExternalPortTypeChanged | The audio input's external port type changed. |
| bmdSwitcherAudioInputEventTypeIsMixedInChanged | The is-mixed-in changed. |

7.1.6 Audio Monitor Output Event Type

BMDSwitcherAudioMonitorOutputEventType enumerates the possible event types for the **IBMDSwitcherAudioMonitorOutputCallback** object interface.

| | |
|---|-----------------------------------|
| bmdSwitcherAudioMonitorOutputEventTypeMonitorEnableChanged | The monitor enable flag changed. |
| bmdSwitcherAudioMonitorOutputEventTypeGainChanged | The gain changed. |
| bmdSwitcherAudioMonitorOutputEventTypeMuteChanged | The mute changed. |
| bmdSwitcherAudioMonitorOutputEventTypeSoloChanged | The solo flag changed. |
| bmdSwitcherAudioMonitorOutputEventTypeSoloInputChanged | The input that is soloed changed. |
| bmdSwitcherAudioMonitorOutputEventTypeDimChanged | The dim flag changed. |
| bmdSwitcherAudioMonitorOutputEventTypeDimLevelChanged | The dim level changed. |

7.1.7 Switcher Talkback Event Types

BMDSwitcherTalkbackEventType enumerates the possible event types for the **IBMDSwitcherTalkbackCallback** object interface.

| | |
|---|--|
| bmdSwitcherTalkbackEventTypeMuteSDIChanged | The mute state of the talkback input SDI channels has changed. |
|---|--|

7.2 Interface Reference

7.2.1 **IBMDSwitcherAudioMixer** Interface

The **IBMDSwitcherAudioMixer** object interface is the root object for all audio mixing control and feedback.

A reference to an **IBMDSwitcherAudioMixer** object interface may be obtained from an **IBMDSwitcher** object interface using the **QueryInterface** method. Pass **IID_IBMDSwitcherAudioMixer** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------|-------------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | IBMDSwitcher::QueryInterface can return an IBMDSwitcherAudioMixer object interface. |

| Public Member Functions | |
|--|---|
| Method | Description |
| GetProgramOutGain | Get the current program out gain value. |
| SetProgramOutGain | Set the program out gain value. |
| GetProgramOutBalance | Get the current program out balance value. |
| SetProgramOutBalance | Set the program out balance value. |
| GetProgramOutFollowFadeToBlack | Get the current program out follow fade to black state. |
| SetProgramOutFollowFadeToBlack | Set the current program out follow fade to black state. |
| SetAllLevelNotificationsEnable | Opt-in to level notifications. |
| ResetProgramOutLevelNotificationPeaks | Reset program out peak level statistics to zero. |
| ResetAllLevelNotificationPeaks | Reset all switcher peak level statistics to zero. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |
| CreateIterator | Create an iterator. |

7.2.1.1 IBMDSwitcherAudioMixer::GetProgramOutGain method

The **GetProgramOutGain** method returns the current gain value.

Syntax

```
HRESULT GetProgramOutGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | out | The current gain value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

7.2.1.2 IBMDSwitcherAudioMixer::SetProgramOutGain method

The **SetProgramOutGain** method sets the gain to apply to the program out.

Syntax

```
HRESULT SetProgramOutGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | in | The desired gain value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.1.3 IBMDSwitcherAudioMixer::GetProgramOutBalance method

The **GetProgramOutBalance** method returns the current balance value.

Syntax

HRESULT GetProgramOutBalance (double* balance);

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------|
| balance | out | The current balance value. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The balance parameter is invalid. |

7.2.1.4 **IBMDSwitcherAudioMixer::GetProgramOutFollowFadeToBlack method**

The **GetProgramOutFollowFadeToBlack** method returns the current follow fade to black state. When enabled the program out audio will fade in unity with a fade to black transition.

Syntax

HRESULT GetProgramOutFollowFadeToBlack (boolean* follow)

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| follow | out | The current follow fade to black state. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The balance parameter is invalid. |

7.2.1.5 **IBMDSwitcherAudioMixer::SetProgramOutFollowFadeToBlack method**

The **SetProgramOutFollowFadeToBlack** method sets the current follow fade to black state. When enabled the program out audio will fade in unity with a fade to black transition.

Syntax

HRESULT SetProgramOutFollowFadeToBlack (boolean follow)

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| follow | in | The desired follow fade to black state. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

7.2.1.6 **IBMDSwitcherAudioMixer::SetProgramOutBalance** method

The **SetProgramOutBalance** method sets the balance to apply to the program out.

Syntax

HRESULT SetProgramOutBalance (double balance);

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------|
| balance | in | The desired balance value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.1.7 **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable** method

The **SetAllLevelNotificationsEnable** method enables level statistics for the relevant mixer inputs and outputs. Receiving level notifications are an opt-in subscription, affecting the callbacks **IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification**, **IBMDSwitcherAudioInputCallback::LevelNotification** and **IBMDSwitcherAudioMonitorOutputCallback::LevelNotification**.

Syntax

HRESULT SetAllLevelNotificationsEnable (boolean enable);

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------------------|
| enable | in | Whether to enable notifications. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.1.8 **IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks method**

The **ResetLevelNotificationPeaks** method resets's the switcher's program out peak level statistics to zero.

Syntax

HRESULT ResetProgramOutLevelNotificationPeaks (void);

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.1.9 **IBMDSwitcherAudioMixer::ResetAllLevelNotificationPeaks method**

The **ResetAllLevelNotificationPeaks** method resets peak statistics to zero for all mixer inputs and outputs.

Syntax

HRESULT ResetAllLevelNotificationPeaks (void);

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.1.10 **IBMDSwitcherAudioMixer::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioMixer** object. Pass an object implementing the **IBMDSwitcherAudioMixerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioMixerCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioMixerCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.1.11 IBMDSwitcherAudioMixer::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherAudioMixerCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioMixerCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.1.12 IBMDSwitcherAudioMixer::CreateIterator method

The **CreateIterator** method creates an iterator object interface for the specified interface ID, such as **IBMDSwitcherAudioInputIterator** and **IBMDSwitcherAudioMonitorOutputIterator**.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| iid | in | Iterator Interface ID to create an iterator for. |
| ppv | in | Pointer to return interface object. |

Return Values

| Value | Description |
|---------------|---|
| S_OK | Success. |
| E_POINTER | The ppv parameter is invalid. |
| E_OUTOFMEMORY | Insufficient memory to create interface object. |
| E_NOINTERFACE | Interface was not found. |

7.2.2 IBMDSwitcherAudioMixerCallback Interface

The **IBMDSwitcherAudioMixerCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioMixer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------|----------------------------|---|
| IBMDSwitcherAudioMixer | IID_IBMDSwitcherAudioMixer | An IBMDSwitcherAudioMixerCallback object interface is installed with IBMDSwitcherAudioMixer::AddCallback and removed with IBMDSwitcherAudioMixer::RemoveCallback |

| Public Member Functions | |
|-----------------------------|------------------------------|
| Method | Description |
| Notify | Called when an event occurs. |
| ProgramOutLevelNotification | Reports level statistics. |

7.2.2.1 **IBMDSwitcherAudioMixerCallback::Notify method**

The **Notify** method is called when **IBMDSwitcherAudioMixer** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioMixerEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherAudioMixerEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.2.2 IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification method

The **ProgramOutLevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using **IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT ProgramOutLevelNotification (double left, double right, peakRight);

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| left | in | The current dB level of the left channel. |
| right | in | The current dB level of the right channel. |
| peakLeft | in | The highest encountered peak dB level of the left channel since the last reset. |
| peakRight | in | The highest encountered peak dB level of the right channel since the last reset. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.3 IBMDSwitcherAudioInputIterator Interface

The **IBMDSwitcherAudioInputIterator** is used to enumerate the available inputs for the audio mixer.

A reference to an **IBMDSwitcherAudioInputIterator** object interface may be obtained from an **IBMDSwitcherAudioMixer** object interface using the **CreateIterator** method. Pass **IID_IBMDSwitcherAudioInputIterator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------|-----------------------------------|---|
| IBMDSwitcherAudioMixer | IID_IBMDSwitcherAudioMixer | IBMDSwitcherAudioMixer::CreateIterator can return an IBMDSwitcherAudioInputIterator object interface. |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| Next | Returns a pointer to the next IBMDSwitcherAudioInput object interface. |
| GetById | Returns a pointer to an IBMDSwitcherAudioInput object interface, given its BMDSwitcherAudioInputId . |

7.2.3.1 IBMDSwitcherAudioInputIterator::Next method

The **Next** method returns the next available **IBMDSwitcherAudioInput** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherAudioInput** audioInput);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---|
| audioInput | out | IBMDSwitcherAudioInput object interface. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherAudioInput objects available. |
| E_POINTER | The audioInput parameter is invalid. |

7.2.3.2 IBMDSwitcherAudioInputIterator::GetById method

The **GetById** method returns a pointer to an **IBMDSwitcherAudioInput** object interface, given its **BMDSwitcherAudioInputId**.

Syntax

HRESULT GetById (BMDSwitcherAudioInputId audioInputId, IBMDSwitcherAudioInput** audioInput);

Parameters

| Name | Direction | Description |
|--------------|-----------|---|
| audioInputId | in | BMDSwitcherAudioInputId identifier. |
| audioInput | out | IBMDSwitcherAudioInput object interface. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_INVALIDARG | The audioInputId is not a valid identifier. |
| E_POINTER | The audioInput parameter is invalid. |

7.2.4 **IBMDSwitcherAudioInput Interface**

The **IBMDSwitcherAudioInput** object interface is used for manipulating the settings of an audio input.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------------|--|---|
| IBMDSwitcherAudioInputIterator | IID_ IBMDSwitcherAudioInputIterator | An IBMDSwitcherAudioInput object interface will be returned after a successful call to IBMDSwitcherAudioInputIterator::Next method. |

| Public Member Functions | |
|-----------------------------|--|
| Method | Description |
| GetType | Get the audio input type. |
| GetMixOption | Get the current mix option. |
| SetMixOption | Set the mix option. |
| GetGain | Get the current gain value. |
| SetGain | Set the gain value. |
| GetBalance | Get the current balance value. |
| SetBalance | Set the balance value. |
| IsMixedIn | Get the current is-mixed-in flag. |
| GetAudioInputId | Get the identifier of the audio input. |
| ResetLevelNotificationPeaks | Reset peak level statistics to zero. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

7.2.4.1 **IBMDSwitcherAudioInput::GetType method**

The **GetType** method returns the type of the audio input.

Syntax

```
HRESULT GetType (BMDSwitcherAudioInputType* type);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| type | out | The audio input type. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The type parameter is invalid. |

7.2.4.2 **IBMDSwitcherAudioInput::GetCurrentExternalPortType** method

The **GetCurrentExternalPortType** method gets the current physical external port type of the audio input. This may change if the physical input is switchable, generating the event **bmdSwitcherAudioInputEventTypeCurrentExternalPortTypeChanged**.

Syntax

```
HRESULT GetCurrentExternalPortType (BMDSwitcherExternalPortType* type);
```

Parameters

| Name | Direction | Description |
|------|-----------|---------------------------------|
| type | out | The current external port type. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The type parameter is invalid. |

7.2.4.3 IBMDSwitcherAudioInput::GetMixOption method

The **GetMixOption** method returns the mix option of the audio input.

Syntax

```
HRESULT GetMixOption (BMDSwitcherAudioMixOption* mixOption);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------|
| mixOption | out | The audio input mix option. |

Return Values

| Value | Description |
|-----------|-------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_POINTER | The mixOption parameter is invalid. |

7.2.4.4 **IBMDSwitcherAudioInput::SetMixOption** method

The **SetMixOption** method sets the mix option of the audio input.

Syntax

```
HRESULT SetMixOption (BMDSwitcherAudioMixOption mixOption);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|-----------------------------|
| mixOption | in | The audio input mix option. |

Return Values

| Value | Description |
|--------------|-------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The mixOption parameter is invalid. |

7.2.4.5 **IBMDSwitcherAudioInput::GetGain method**

The **GetGain** method returns the gain currently applied to the audio input.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| gain | out | The gain currently applied to the audio input. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

7.2.4.6 **IBMDSwitcherAudioInput::SetGain method**

The **SetGain** method sets the gain to apply to the audio input.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|---------------------------------------|
| gain | in | The gain to apply to the audio input. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.4.7 **IBMDSwitcherAudioInput::GetBalance method**

The **GetBalance** method returns the current balance.

Syntax

```
HRESULT GetBalance (double* balance);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------|
| balance | out | The current balance. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The balance parameter is invalid. |

7.2.4.8 **IBMDSwitcherAudioInput::SetBalance** method

The **SetBalance** method sets the balance to apply to the audio input.

Syntax

HRESULT SetBalance (double balance);

Parameters

| Name | Direction | Description |
|---------|-----------|-----------------------|
| balance | in | The balance to apply. |

Return Values

| Value | Description |
|--------------|-----------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The balance parameter is invalid. |

7.2.4.9 IBMDSwitcherAudioInput::IsMixedIn method

The **IsMixedIn** method indicates whether the audio input is currently being mixed into the program out.

Syntax

```
HRESULT IsMixedIn (boolean* mixedIn);
```

Parameters

| Name | Direction | Description |
|---------|-----------|----------------------------|
| mixedIn | out | The current mixed-in flag. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| S_OK | Success. |
| E_POINTER | The mixedIn parameter is invalid. |

7.2.4.10 IBMDSwitcherAudioInput::GetAudioInputId method

The **GetAudioInputId** method gets the **BMDSwitcherAudioInputId** of the audio input.

Syntax

```
HRESULT GetAudioInputId (BMDSwitcherAudioInputId* audioInputId);
```

Parameters

| Name | Direction | Description |
|--------------|-----------|--|
| audioInputId | out | The BMDSwitcherAudioInputId of the audio input. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.4.11 IBMDSwitcherAudioInput::ResetLevelNotificationPeaks method

The **ResetLevelNotificationPeaks** method resets the switcher’s input peak level statistics to zero.

Syntax

```
HRESULT ResetLevelNotificationPeaks (void);
```

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.4.12 IBMDSwitcherAudioInput::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioInput** object. Pass an object implementing the **IBMDSwitcherAudioInputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioInputCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioInputCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.4.13 IBMDSwitcherAudioInput::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherAudioInputCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioInputCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.5 **IBMDSwitcherAudioInputCallback Interface**

The **IBMDSwitcherAudioInputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioInput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------|----------------------------|---|
| IBMDSwitcherAudioInput | IID_IBMDSwitcherAudioInput | An IBMDSwitcherAudioInputCallback object interface is installed with IBMDSwitcherAudioInput::AddCallback and removed with IBMDSwitcherAudioInput::RemoveCallback |

Public Member Functions

| Method | Description |
|-------------------|------------------------------|
| Notify | Called when an event occurs. |
| LevelNotification | Reports level statistics. |

7.2.5.1 IBMDSwitcherAudioInputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioInput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioInputEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherAudioInputEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.5.2 **IBMDSwitcherAudioInputCallback::LevelNotification** method

The **LevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using **IBMDSwitcherAudioInput::ResetLevelNotificationPeaks**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT LevelNotification (double left, double right, double peakLeft, double peakRight);

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| left | in | The current dB level of the left channel. |
| right | in | The current dB level of the right channel. |
| peakLeft | in | The highest encountered peak dB level of the left channel since the last reset. |
| peakRight | in | The highest encountered peak dB level of the right channel since the last reset. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.6 IBMDSwitcherAudioMonitorOutputIterator Interface

The **IBMDSwitcherAudioMonitorOutputIterator** is used to enumerate the available monitor outputs for the audio mixer.

A reference to an **IBMDSwitcherAudioMonitorOutputIterator** object interface may be obtained from an **IBMDSwitcherAudioMixer** object interface using the **CreateIterator** method. Pass **IID_IBMDSwitcherAudioMonitorOutputIterator** for the IID parameter.

Related Interfaces

| Interface | Interface ID | Description |
|------------------------|----------------------------|---|
| IBMDSwitcherAudioMixer | IID_IBMDSwitcherAudioMixer | IBMDSwitcherAudioMixer::CreateIterator can return an IBMDSwitcherAudioMonitorOutputIterator object interface. |

Public Member Functions

| Method | Description |
|--------|---|
| Next | Returns a pointer to the next IBMDSwitcherAudioMonitorOutputIterator object interface. |

7.2.6.1 **IBMDSwitcherAudioMonitorOutputIterator::Next method**

The **Next** method returns the next available **IBMDSwitcherAudioMonitorOutput** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherAudioMonitorOutput** audioMonitorOutput);
```

Parameters

| Name | Direction | Description |
|--------------------|-----------|---|
| audioMonitorOutput | out | IBMDSwitcherAudioMonitorOutput object interface. |

Return Values

| Value | Description |
|-----------|--|
| S_OK | Success. |
| S_FALSE | No more IBMDSwitcherAudioMonitorOutput objects available. |
| E_POINTER | The audioMonitorOutput parameter is invalid. |

7.2.7 **IBMDSwitcherAudioMonitorOutput Interface**

The **IBMDSwitcherAudioMonitorOutput** object interface is used for manipulating parameters specific to audio monitor outputs.

Related Interfaces

| Interface | Interface ID | Description |
|--|--|---|
| IBMDSwitcherAudioMonitorOutput Iterator | IID_ IBMDSwitcherAudioMonitorOutput | An IBMDSwitcherAudioMonitorOutput interface can be obtained with IBMDSwitcherAudioMonitorOutputIterator::Next . |

| Public Member Functions | |
|-------------------------|--------------------------------------|
| Method | Description |
| GetMonitorEnable | Get the current monitor-enable flag. |
| SetMonitorEnable | Set the monitor-enable flag. |
| GetMute | Get the current mute flag. |
| SetMute | Set the mute flag. |
| GetGain | Get the current gain value. |
| SetGain | Set the gain value. |
| GetSolo | Get the current solo flag. |
| SetSolo | Set the solo flag. |
| GetSoloInput | Get the current soloed input. |
| SetSoloInput | Set the soloed input. |
| GetDim | Get the current dim flag. |
| SetDim | Set the dim flag. |
| GetDimLevel | Get the current dim level. |
| SetDimLevel | Set the dim level. |

SECTION **7** Audio Mixing

| Public Member Functions | |
|-----------------------------|--------------------------------------|
| Method | Description |
| ResetLevelNotificationPeaks | Reset peak level statistics to zero. |
| AddCallback | Add a callback. |
| RemoveCallback | Remove a callback. |

7.2.7.1 **IBMDSwitcherAudioMonitorOutput::GetMonitorEnable** method

The **GetMonitorEnable** method returns the current monitor enable flag.

Syntax

```
HRESULT GetMonitorEnable (boolean* enable);
```

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------------------|
| enable | out | The current monitor enable flag. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| S_OK | Success. |
| E_POINTER | The enable parameter is invalid. |

7.2.7.2 **IBMDSwitcherAudioMonitorOutput::SetMonitorEnable** method

The **SetMonitorEnable** method sets the monitor enable flag.

This output acts as a monitor when the flag is set, otherwise it mirrors the content of program out.

Syntax

HRESULT SetMonitorEnable (boolean enable);

Parameters

| Name | Direction | Description |
|--------|-----------|----------------------------------|
| enable | in | The current monitor enable flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.3 **IBMDSwitcherAudioMonitorOutput::GetMute** method

The **GetMute** method returns the current mute flag.

Syntax

```
HRESULT GetMute (boolean* mute);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| mute | out | The current mute flag. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The mute parameter is invalid. |

7.2.7.4 **IBMDSwitcherAudioMonitorOutput::SetMute** method

The **SetMute** method sets the mute flag.

Syntax

```
HRESULT SetMute (boolean mute);
```

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| mute | in | The desired mute flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.5 **IBMDSwitcherAudioMonitorOutput::GetGain** method

The **GetGain** method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | out | The current gain value. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

7.2.7.6 **IBMDSwitcherAudioMonitorOutput::SetGain** method

The **SetGain** method sets the gain to apply to the audio monitor output.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

| Name | Direction | Description |
|------|-----------|-------------------------|
| gain | in | The desired gain value. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.7 **IBMDSwitcherAudioMonitorOutput::GetSolo** method

The **GetSolo** method returns the current solo flag.

Syntax

HRESULT GetSolo (boolean* solo);

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| solo | out | The current solo flag. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The solo parameter is invalid. |

7.2.7.8 **IBMDSwitcherAudioMonitorOutput::SetSolo** method

The **SetSolo** method sets the solo flag.

Syntax

HRESULT SetSolo (boolean solo);

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| solo | in | The desired solo flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.9 **IBMDSwitcherAudioMonitorOutput::GetSoloInput method**

The **GetSoloInput** method returns which audio input is selected for soloing in the monitor output.

Syntax

```
HRESULT GetSoloInput (BMDSwitcherAudioInputId* audioInput);
```

Parameters

| Name | Direction | Description |
|------------|-----------|------------------------------|
| audioInput | out | The audio input for soloing. |

Return Values

| Value | Description |
|-----------|--------------------------------------|
| S_OK | Success. |
| E_POINTER | The audioInput parameter is invalid. |

7.2.7.10 **IBMDSwitcherAudioMonitorOutput::SetSoloInput method**

The **SetSoloInput** method selects which audio input is soloed in the monitor output.

Syntax

HRESULT SetSoloInput (BMDSwitcherAudioInputId audioInput);

Parameters

| Name | Direction | Description |
|------------|-----------|------------------------------|
| audioInput | in | The audio input for soloing. |

Return Values

| Value | Description |
|--------------|--------------------------------------|
| S_OK | Success. |
| E_FAIL | Failure. |
| E_INVALIDARG | The audioInput parameter is invalid. |

7.2.7.11 IBMDSwitcherAudioMonitorOutput::GetDim method

The **GetDim** method returns the current dim flag.

Syntax

```
HRESULT GetDim (boolean* dim);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| dim | out | The current dim flag. |

Return Values

| Value | Description |
|-----------|-------------------------------|
| S_OK | Success. |
| E_POINTER | The dim parameter is invalid. |

7.2.7.12 IBMDSwitcherAudioMonitorOutput::SetDim method

The **SetDim** method sets the dim flag.

Syntax

```
HRESULT SetDim (boolean dim);
```

Parameters

| Name | Direction | Description |
|------|-----------|-----------------------|
| dim | in | The desired dim flag. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.13 IBMDSwitcherAudioMonitorOutput::GetDimLevel method

The **GetDimLevel** method returns the current dim level in dB.

Syntax

HRESULT GetDimLevel (double* gain);

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| gain | out | The current dim level. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| S_OK | Success. |
| E_POINTER | The gain parameter is invalid. |

7.2.7.14 IBMDSwitcherAudioMonitorOutput::SetDimLevel method

The **SetDimLevel** method sets the dim level in dB.

Syntax

HRESULT SetDimLevel (double gain);

Parameters

| Name | Direction | Description |
|------|-----------|------------------------|
| dim | in | The desired dim level. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.15 **IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks** method

The **ResetLevelNotificationPeaks** method resets the switcher's output peak level statistics to zero.

Syntax

HRESULT ResetLevelNotificationPeaks (void);

Parameters

none.

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.7.16 IBMDSwitcherAudioMonitorOutput::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioMonitorOutput** object. Pass an object implementing the **IBMDSwitcherAudioMonitorOutputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioMonitorOutputCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioMonitorOutputCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.7.17 **IBMDSwitcherAudioMonitorOutput::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherAudioMonitorOutputCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherAudioMonitorOutputCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.8 IBMDSwitcherAudioMonitorOutputCallback Interface

The **IBMDSwitcherAudioMonitorOutputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioMonitorOutput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------------|--|---|
| IBMDSwitcherAudioMonitorOutput | IID_ IBMDSwitcherAudioMonitorOutput | An IBMDSwitcherAudioMonitorOutputCallback object interface is installed with IBMDSwitcherAudioMonitorOutput::AddCallback and removed with IBMDSwitcherAudioMonitorOutput::RemoveCallback |

| Public Member Functions | |
|-------------------------|------------------------------|
| Method | Description |
| Notify | Called when an event occurs. |
| LevelNotification | Reports level statistics. |

7.2.8.1 IBMDSwitcherAudioMonitorOutputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioMonitorOutput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioMonitorOutputEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherAudioMonitorOutputEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.8.2 **IBMDSwitcherAudioMonitorOutputCallback::LevelNotification method**

The **LevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using **IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT LevelNotification (double left, double right, double peakLeft, double peakRight);

Parameters

| Name | Direction | Description |
|-----------|-----------|--|
| left | in | The current dB level of the left channel. |
| right | in | The current dB level of the right channel. |
| peakLeft | in | The highest encountered peak dB level of the left channel since the last reset. |
| peakRight | in | The highest encountered peak dB level of the right channel since the last reset. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.9 IBMDSwitcherTalkback Interface

The **IBMDSwitcherTalkback** object interface is used for managing functionality relating to the talkback features on the switcher.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|---|
| IBMDSwitcher | IID_IBMDSwitcher | An IBMDSwitcherTalkback interface can be obtained with IBMDSwitcher::QueryInterface . |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| GetMuteSDI | Query the mute state of the talkback input SDI channels. |
| SetMuteSDI | Set the mute state of the talkback input SDI channels. |
| AddCallback | Add a talkback callback. |
| RemoveCallback | Remove a talkback callback. |

7.2.9.1 **IBMDSwitcherTalkback::GetMuteSDI method**

The **GetMuteSDI** method returns the mute state of the audio on the dedicated talkback input SDI channels.

Syntax

HRESULT GetMuteSDI (boolean* muteSDI);

Parameter

| Name | Direction | Description |
|---------|-----------|--|
| muteSDI | out | The mute state of the talkback input SDI channels. |

Return Values

| Value | Description |
|-----------|---|
| S_OK | Success. |
| E_POINTER | The muteSDI parameter is not a valid pointer. |

7.2.9.2 IBMDSwitcherTalkback::SetMuteSDI method

The **SetMuteSDI** method sets the mute state of the audio on the dedicated talkback input SDI channels.

Syntax

HRESULT SetMuteSDI (boolean muteSDI);

Parameters

| Name | Direction | Description |
|---------|-----------|--|
| muteSDI | out | The mute state of the talkback input SDI channels. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

7.2.9.3 IBMDSwitcherTalkback::AddCallback method

The **AddCallback** method configures a callback to be called when a switcher talkback property changes, such as the talkback SDI mute state.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

HRESULT AddCallback (IBMDSwitcherTalkbackCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherTalkbackCallback interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.9.4 **IBMDSwitcherTalkback::RemoveCallback method**

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback (IBMDSwitcherTalkbackCallback* callback);

Parameters

| Name | Direction | Description |
|----------|-----------|----------------------------|
| callback | in | Callback object to remove. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

7.2.10 IBMDSwitcherTalkbackCallback Interface

The **IBMDSwitcherTalkbackCallback** object interface is a callback class which is called when a switcher talkback event occurs, such as a change in the talkback input SDI mute state.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|----------------------|--------------------------|---|
| IBMDSwitcherTalkback | IID_IBMDSwitcherTalkback | An IBMDSwitcherTalkbackCallback interface may be installed with IBMDSwitcherTalkback::AddCallback . |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| Notify | A Switcher talkback event occurred, such as a change in the talkback input SDI mute state. |

7.2.10.1 IBMDSwitcherSerialPortCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTalkback** events occur.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

HRESULT Notify (BMDSwitcherTalkbackEventType eventType);

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | A BMDSwitcherTalkbackEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| S_OK | Success. |
| E_FAIL | Failure. |

8 Camera Control

The Switcher Camera Control API provides programmatic access to supported Blackmagic Design cameras via ATEM switchers. Devices must support the Blackmagic Video Device Embedded Control Protocol. Please refer to the Developer Information section of the ATEM Switchers Operation Manual for further information about the protocol.

8.1 Camera Control Data Types

8.1.1 Switcher Camera Control Event Type

BMDSwitcherCameraControlEventType enumerates the possible event types for the **IBMDSwitcherCameraControlCallback** object interface.

- bmdSwitcherCameraControlEventTypePeriodicFlushIntervalChanged** The periodic flush interval has changed.
- bmdSwitcherCameraControlEventTypeParameterValueChanged** The parameter value has changed.
- bmdSwitcherCameraControlEventTypeParameterPeriodicFlushEnabledChanged** The parameter period flush enabled state has changed.

8.1.2 Switcher Camera Control Parameter Type

BMDSwitcherCameraControlParameterType enumerates the possible parameter types for the **IBMDSwitcherCameraControl** object interface.

- bmdSwitcherCameraControlParameterTypeVoidBool** Boolean (1 or more values) or Void (0 values).
- bmdSwitcherCameraControlParameterTypeSigned8Bit** Signed 8-bit type. This type is the same as byte.
- bmdSwitcherCameraControlParameterTypeSigned16Bit** Signed 16-bit type
- bmdSwitcherCameraControlParameterTypeSigned32Bit** Signed 32-bit type
- bmdSwitcherCameraControlParameterTypeSigned64Bit** Signed 64-bit type
- bmdSwitcherCameraControlParameterTypeFixedPoint16Bit** Binary fixed point signed number. 5 bits integer and 11 bits fractional.

8.2 Interface Reference

8.2.1 Switcher Camera Control Parameter Iterator

The **IBMDSwitcherCameraControlParameterIterator** is used to iterate control parameters that have been previously set. A reference to an **IBMDSwitcherCameraControlParameterIterator** object interface may be obtained from an **IBMDSwitcherCameraControl** object interface using the **CreateIterator** method.

The **IBMDSwitcherCameraControlParameterIterator** interface is used to iterate through control parameters.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------|-------------------------------|--|
| IBMDSwitcherCameraControl | IID_IBMDSwitcherCameraControl | IBMDSwitcherCameraControl::CreateIterator returns an IBMDSwitcherCameraControlParameterIterator object interface when the IID_IBMDSwitcherCameraControlParameterIterator IID is specified. |

| Public Member Functions | |
|-------------------------|-------------------------------------|
| Method | Description |
| Next | Returns the next control parameter. |

8.2.1.1 **IBMDSwitcherCameraControlParameterIterator::Next method**

The **Next** method returns the next control parameter.

Syntax

HRESULT Next(uint32_t* destinationDevice, uint32_t* category, uint32_t* parameter)

Parameters

| Name | Direction | Description |
|-------------------|-----------|-------------------------------------|
| destinationDevice | out | The destination device address. |
| category | out | The configuration category number. |
| parameter | out | The configuration parameter number. |

Return Values

| Value | Description |
|-----------|---|
| S_FALSE | No more control parameters are available. |
| S_OK | Success. |
| E_POINTER | One or more of the parameters is NULL. |

8.2.2 IBMDSwitcherCameraControlCallback Interface

The **IBMDSwitcherCameraControlCallback** object interface is a callback class which is called when a camera control event occurs.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------|-------------------------------|--|
| IBMDSwitcherCameraControl | IID_IBMDSwitcherCameraControl | An IBMDSwitcherCameraControlCallback object interface may be installed with IBMDSwitcherCameraControl::AddCallback . |

Public Member Functions

| Method | Description |
|--------|--|
| Notify | Called when a camera control event occurs. |

8.2.2.1 **IBMDSwitcherCameraControlCallback::Notify method**

The **Notify** method is called when **IBMDSwitcherCameraControl** events occur. This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher. To determine the type and count of the parameter values call **IBMDSwitcherCameraControl::GetParameterInfo**.

Syntax

HRESULT Notify (BMDSwitcherCameraControlEventType eventType, uint32_t destinationDevice, uint32_t category, uint32_t parameter)

Parameters

| Name | Direction | Description |
|-------------------|-----------|---|
| eventType | in | The BMDSwitcherCameraControlEventType that describes the type of event that has occurred. |
| destinationDevice | in | The destination device address. |
| category | in | The configuration category number available on the device. |
| parameter | in | The configuration parameter number available on the device. |

Return Values

| Value | Description |
|--------------|-------------------------|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | A parameter is invalid. |

8.2.3 IBMDSwitcherCameraControl Interface

The **IBMDSwitcherCameraControl** object interface is used for controlling compatible Blackmagic Design cameras.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|-------------------|---|
| IBMDSwitcher | IID_ IBMDSwitcher | An IBMDSwitcherCameraControl object interface can be obtained with IBMDSwitcher::QueryInterface . |

| Public Member Functions | |
|----------------------------------|---|
| Method | Description |
| CreateIterator | Create an iterator. |
| GetPeriodicFlushInterval | Get the periodic flush interval for parameters to be sent over SDI. |
| SetPeriodicFlushInterval | Set the periodic flush interval for parameters to be sent over SDI. |
| GetParameterInfo | Get the type and count of a parameter. |
| GetParameterPeriodicFlushEnabled | Get the status of flush enable. |
| SetFlags | Sets the current flag values. |
| ToggleFlags | Toggles the current flag values. |
| GetFlags | Gets the current flag values. |
| SetBytes | Sets the current signed 8-bit values. |
| OffsetBytes | Apply signed offsets to the signed 8-bit values. |
| GetBytes | Get the parameter values consisting of bytes. |
| SetInt16s | Sets the current signed 16-bit integer values. |
| OffsetInt16s | Apply a signed offset to the signed 16-bit integer values. |
| GetInt16s | Get the current signed 16-bit integer values. |
| SetInt32s | Sets the current signed 32-bit integer values. |
| OffsetInt32s | Apply a signed offset to the signed 32-bit integer values. |

SECTION **8** Camera Control

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetInt32s | Get the current signed 32-bit integer values. |
| SetInt64s | Sets the current signed 64-bit integer values. |
| OffsetInt64s | Apply a signed offset to the signed 64-bit integer values. |
| GetInt64s | Get the current signed 64-bit integer values. |
| OffsetFloats | Apply a signed floating point offset to the fixed point values. |
| SetFloats | Sets the current fixed point values. |
| GetFloats | Get the current fixed point values. |
| AddCallback | Add a callback to receive camera control event notifications. |
| RemoveCallback | Remove a callback. |

8.2.3.1 **IBMDSwitcherCameraControl::CreateIterator method**

The **CreateIterator** method creates an iterator object interface for the specified interface ID.

Syntax

HRESULT CreateIterator(REFIID iid, LPVOID* ppv)

Parameters

| Name | Direction | Description |
|------|-----------|--|
| iid | in | Iterator Interface ID to create an iterator for. |
| ppv | in | Pointer to return interface object. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_OUTOFMEMORY | Unable to allocate memory. |
| E_POINTER | The ppv parameter is NULL. |
| E_NOINTERFACE | Unable to locate interface matching iid parameter. |

8.2.3.2 **IBMDSwitcherCameraControl::GetPeriodicFlushInterval** method

The **GetPeriodicFlushInterval** method returns the periodic interval set on the switcher.

The flush interval is the period where the nominated parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT GetPeriodicFlushInterval (uint32_t *intervalMs);
```

Parameters

| Name | Direction | Description |
|------------|-----------|--|
| intervalMs | out | The periodic flush interval in milliseconds. |

Return Values

| Value | Description |
|-----------|-----------------------------------|
| E_POINTER | The intervalMs parameter is NULL. |
| S_OK | Success. |

8.2.3.3 IBMDSwitcherCameraControl::SetPeriodicFlushInterval method

The **SetPeriodicFlushInterval** method sets the periodic flush interval on the switcher.

The flush interval is the period where the parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT SetPeriodicFlushInterval (uint32_t intervalMs);
```

Parameters

| Name | Direction | Description |
|------------|-----------|---------------------------------------|
| intervalMs | in | The refresh interval in milliseconds. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

8.2.3.4 IBMDSwitcherCameraControl::GetParameterInfo method

The **GetParameterInfo** method obtains the type of value (**BMDSwitcherCameraControlParameterType**) and the number of values for a given parameter.

Syntax

```
HRESULT GetParameterInfo (uint32_t destinationDevice, uint32_t category, uint32_t parameter,
    BMDSwitcherCameraControlParameterType* type, uint32_t* count);
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|------------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The configuration category number. |
| parameter | in | The parameter number. |
| type | out | The parameter type. |
| count | out | Number of values. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_UNEXPECTED | An unexpected type error has occurred. |
| E_INVALIDARG | Unable to find parameter information for the given arguments. |
| E_POINTER | The type or count parameter is NULL. |

8.2.3.5 IBMDSwitcherCameraControl::GetParameterPeriodicFlushEnabled method

The **GetParameterPeriodicFlushEnabled** method returns the periodic flush enabled status for the parameter values. When enabled, the parameter values will be flushed periodically from the switcher over the SDI connection to the cameras. The flush interval can be changed by calling **SetPeriodicFlushInterval**.

Syntax

```
HRESULT GetParameterPeriodicFlushEnabled (uint32_t destinationDevice, uint32_t category, uint32_t parameter, boolean* nabled)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|------------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The configuration category number. |
| parameter | in | The parameter number. |
| enabled | out | The periodic flush enabled status. |

Return Values

| Value | Description |
|--------------|--|
| E_POINTER | The enabled parameter is NULL. |
| S_OK | Success. |
| E_INVALIDARG | Unable to find an entry for the given arguments. |

8.2.3.6 IBMDSwitcherCameraControl::SetParameterPeriodicFlushEnabled method

The **SetParameterPeriodicFlushEnabled** method sets the periodic flush enabled parameters. The parameters will not be flushed unless this option has been enabled. The flush interval is the period where the parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT SetParameterPeriodicFlushEnabled (uint32_t destinationDevice, uint32_t category,
uint32_t parameter, boolean enabled)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| enabled | in | Enable periodic flush. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

8.2.3.7 IBMDSwitcherCameraControl::SetFlags method

The **SetFlags** method sends flags to the cameras over SDI.

Syntax

```
HRESULT SetFlags (uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const boolean* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of parameter elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|---|
| E_FAIL | Failure . |
| S_OK | Success. |
| E_POINTER | The values parameter is NULL and the count is non-zero. |
| E_OUTOFMEMORY | There is insufficient memory to complete operation. |

8.2.3.8 IBMDSwitcherCameraControl::ToggleFlags method

The **ToggleFlags** method will toggle the flags and then send the flags from the switcher to the cameras over SDI. If the parameter value is true, then the flag will be toggled otherwise it will remain the same.

Syntax

```
HRESULT ToggleFlags(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const boolean* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of parameter elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|---|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values parameter is NULL and the count is non-zero. |
| E_OUTOFMEMORY | There is insufficient memory to complete operation. |

8.2.3.9 IBMDSwitcherCameraControl::GetFlags method

The **GetFlags** method returns the last flags sent to the cameras over SDI.

Syntax

```
HRESULT GetFlags(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t* count, boolean* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | out | The element count. |
| values | out | The parameter values. |

Return Values

| Value | Description |
|--------------|---|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_INVALIDARG | Flags do not exist for the given arguments. |
| E_POINTER | The count or values parameter is NULL. |

8.2.3.10 **IBMDSwitcherCameraControl::SetBytes** method

The SetBytes method sends 8-bit values to the cameras over SDI.

Syntax

```
HRESULT SetBytes(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int8_t* bytes)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| bytes | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The bytes argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.11 **IBMDSwitcherCameraControl::OffsetBytes** method

The OffsetBytes method will add signed offsets to the current 8-bit values and then send the offset values to the cameras over SDI.

Syntax

HRESULT OffsetBytes(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int8_t* bytes)

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| bytes | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The bytes argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.12 **IBMDSwitcherCameraControl::GetBytes method**

The GetBytes method returns the last signed bytes sent to the cameras over SDI.

Syntax

HRESULT GetBytes(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, int8_t* bytes)

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | out | The element count. |
| bytes | out | The parameter values. |

Return Values

| Value | Description |
|--------------|---|
| S_OK | Success. |
| E_INVALIDARG | Bytes do not exist for the given arguments. |
| E_POINTER | The count or byte parameter is NULL. |

8.2.3.13 **IBMDSwitcherCameraControl::SetInt16s method**

The **SetInt16s** method sends signed 16-bit values from the switcher to the cameras over SDI.

Syntax

```
HRESULT SetInt16s(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const int16_t* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.14 IBMDSwitcherCameraControl::OffsetInt16s method

The **OffsetInt16s** method will add signed offsets to the current 16-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetInt16s(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const int16_t* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.15 **IBMDSwitcherCameraControl::GetInt16s method**

The **GetInt16s** method returns the last 16-bit signed integers sent to the cameras over SDI.

Syntax

HRESULT GetInt16s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, int16_t* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | out | The number of parameter elements. |
| values | out | The parameter values. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_INVALIDARG | Int16s do not exist for the given arguments. |
| E_POINTER | The count or values argument is NULL. |

8.2.3.16 **IBMDSwitcherCameraControl::SetInt32s method**

The **SetInt32s** method sends signed 32-bit values to the cameras over SDI.

Syntax

HRESULT SetInt32s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int32_t* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of parameter elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.17 **IBMDSwitcherCameraControl::OffsetInt32s** method

The **OffsetInt32s** method will add signed offsets to the current 32-bit values and then send the offset values to the cameras over SDI.

Syntax

HRESULT OffsetInt32s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int32_t* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.18 **IBMDSwitcherCameraControl::GetInt32s method**

The **GetInt32s** method returns the last 32-bit signed integers sent to the cameras over SDI.

Syntax

HRESULT `GetInt32s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, int32_t* values)`

Parameters

| Name | Direction | Description |
|--------------------------------|-----------|---------------------------------|
| <code>destinationDevice</code> | in | The destination device address. |
| <code>category</code> | in | The category. |
| <code>parameter</code> | in | The parameter. |
| <code>count</code> | out | The number of elements. |
| <code>values</code> | out | The parameter values. |

Return Values

| Value | Description |
|---------------------------|--|
| <code>S_OK</code> | Success. |
| <code>E_INVALIDARG</code> | Int32s do not exist for the given arguments. |
| <code>E_POINTER</code> | The count or values argument is NULL. |

8.2.3.19 **IBMDSwitcherCameraControl::SetInt64s** method

The **SetInt64s** method sends signed 64-bit values from the switcher to the cameras over SDI.

Syntax

HRESULT SetInt64s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int64_t* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of parameter elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.20 **IBMDSwitcherCameraControl::OffsetInt64s** method

The **OffsetInt64s** method will add signed offsets to the current 64-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetInt64s(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const int64_t* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.21 **IBMDSwitcherCameraControl::GetInt64s** method

The **GetInt64s** method returns the last 64-bit signed integers sent to the cameras over SDI.

Syntax

HRESULT `GetInt64s(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, int64_t* values)`

Parameters

| Name | Direction | Description |
|--------------------------------|-----------|---------------------------------|
| <code>destinationDevice</code> | in | The destination device address. |
| <code>category</code> | in | The category. |
| <code>parameter</code> | in | The parameter. |
| <code>count</code> | out | The element count. |
| <code>values</code> | out | The parameter values. |

Return Values

| Value | Description |
|---------------------------|--|
| <code>S_OK</code> | Success. |
| <code>E_INVALIDARG</code> | Int64s do not exist for the given arguments. |
| <code>E_POINTER</code> | The count or values argument is NULL. |

8.2.3.22 **IBMDSwitcherCameraControl::OffsetFloats** method

The **OffsetFloats** method will add signed offsets to the current parameter values. The representable range is from -16.0 to 15.9995 (15 + 2047/2048). The resultant parameters are sent from the switcher to the cameras over SDI.

Syntax

HRESULT OffsetFloats(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const double* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The number of elements. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.23 IBMDSwitcherCameraControl::SetFloats method

The **SetFloats** method sends fixed floating point values from the switcher to the cameras over SDI. The representable range is from -16.0 to 15.9995 (15 + 2047/2048).

Syntax

```
HRESULT SetFloats(uint32_t destinationDevice, uint32_t category, uint32_t parameter,
uint32_t count, const double* values)
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | in | The element count. |
| values | in | The parameter values. |

Return Values

| Value | Description |
|---------------|--|
| E_FAIL | Failure. |
| S_OK | Success. |
| E_POINTER | The values argument is NULL. |
| E_OUTOFMEMORY | There was insufficient memory to complete the operation. |

8.2.3.24 **IBMDSwitcherCameraControl::GetFloats method**

The **GetFloats** method returns the last fixed point values sent to the cameras over SDI. The representable range is from -16.0 to 15.9995 (15 + 2047/2048).

Syntax

HRESULT GetFloats(uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, double* values)

Parameters

| Name | Direction | Description |
|-------------------|-----------|-----------------------------------|
| destinationDevice | in | The destination device address. |
| category | in | The category. |
| parameter | in | The parameter. |
| count | out | The element count. |
| values | out | The fixed point parameter values. |

Return Values

| Value | Description |
|--------------|--|
| S_OK | Success. |
| E_INVALIDARG | Floats do not exist for the given arguments. |
| E_POINTER | The count or values argument is NULL. |

8.2.3.25 **IBMDSwitcherCameraControl::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherCameraControlCallback** object. The caller should pass an object implementing the **IBMDSwitcherCameraControlCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

HRESULT AddCallback(**IBMDSwitcherCameraControlCallback*** callback)

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherCameraControlCallback object interface. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is NULL. |

8.2.3.26 **IBMDSwitcherCameraControl::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

HRESULT RemoveCallback(IBMDSwitcherCameraControlCallback* callback)

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherCameraControlCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| S_OK | Success. |
| E_INVALIDARG | The callback parameter is invalid. |

9 Macros

The Switcher Macros API provides the functionality to record, playback, and transfer macros.

9.1 General Information

9.1.1 Macro Indexes and Identification

Each switcher is capable of storing a maximum number of macros. Each macro is uniquely identified by an index ranging from 0 to $n - 1$, where n is the maximum number of macros available on the switcher. A macro is stored using the index specified on record or upload. If there is already a macro with the same index then it will be replaced, so it is best to check for an existing macro at the specified index before recording or uploading. If a macro exists at the specified index then the macro is considered valid, otherwise the index contains no macro.

9.1.2 Recording a Macro

Here are the basic steps for recording a macro on a switcher:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object.
Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroControl** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroControlCallback** object and add it to the macro pool with the **IBMDSwitcherMacroControl::AddCallback** method.
- Call **IBMDSwitcherMacroControl::Record** to begin recording a new macro.
- Perform the switcher operations that you wish to record to the macro.
- Call **IBMDSwitcherMacroControl::StopRecording** to end the macro recording.

9.1.3 Downloading a Macro

Here are the basic steps for downloading a macro from a switcher:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object. Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroPool** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroPoolCallback** object and add it to the macro pool with the **IBMDSwitcherMacroPool::AddCallback** method.
- Call **IBMDSwitcherMacroPool::Download** to begin the transfer of a macro from the switcher. This method will return an **IBMDSwitcherTransferMacro** object which can be used to track the progress of the download. You will also be notified of the download outcome via the **IBMDSwitcherMacroPoolCallback** interface.
- Using the **IBMDSwitcherTransferMacro** object obtained from either **IBMDSwitcherMacroPool::Download** or **IBMDSwitcherMacroPoolCallback::Notify** call **IBMDSwitcherTransferMacro::GetMacro** to get the macro object.

9.1.4 Uploading a Macro

The steps for uploading a macro to a switcher are very similar to downloading:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object. Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroPool** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroPoolCallback** object and add it to the macro pool with the **IBMDSwitcherMacroPool::AddCallback** method.
- Use **IBMDSwitcherMediaPool::CreateMacro** to create a macro object. Populate this with your macro binary data by filling in the macro object's data buffer, which is available via the **IBMDSwitcherMacro::GetBytes** method. Alternatively, you can use an **IBMDSwitcherMacro** object obtained from a previous macro download.
- Call **IBMDSwitcherMacroPool::Upload** to begin the transfer of the macro to the switcher. This method will return an **IBMDSwitcherTransferMacro** object which can be used to track the progress of the upload. You will also be notified of the upload outcome via the **IBMDSwitcherMacroPoolCallback** interface.

9.1.5 Unsupported Operations

As the capabilities of Blackmagic Design Switcher products evolve, new functionality will be added. A macro that is created on a newer version switcher and transferred to an older version switcher may contain operations that the older switcher does not support. A macro containing unsupported operations is flagged as such and can still be played, but the unsupported operations will be ignored.

9.2 Macro Data Types

9.2.1 Macro Pool Event Type

BMDSwitcherMacroPoolEventType enumerates the possible event types for the **IBMDSwitcherMacroPoolCallback** object interface.

| | |
|--|---|
| bmdSwitcherMacroPoolEventTypeValidChanged | A macro has been created (becomes valid), or deleted (becomes invalid). |
| bmdSwitcherMacroPoolEventTypeHasUnsupportedOpsChanged | A macro's unsupported operations flag has changed. |
| bmdSwitcherMacroPoolEventTypeNameChanged | A macro's name has changed. |
| bmdSwitcherMacroPoolEventTypeDescriptionChanged | A macro's description has changed. |
| bmdSwitcherMacroPoolEventTypeTransferCompleted | A macro transfer has completed. |
| bmdSwitcherMacroPoolEventTypeTransferCancelled | A macro transfer has cancelled. |
| bmdSwitcherMacroPoolEventTypeTransferFailed | A macro transfer has failed. |

9.2.2 Macro Control Event Type

BMDSwitcherMacroControlEventType enumerates the possible event types for the **IBMDSwitcherMacroControlCallback** object interface.

| | |
|--|---|
| bmdSwitcherMacroControlEventTypeRunStatusChanged | The switcher's macro playback state has changed |
| bmdSwitcherMacroControlEventTypeRecordStatusChanged | The switcher's macro record state has changed. |

9.2.3 Macro Run Status

BMDSwitcherMacroRunStatus enumerates the possible macro playback states.

| | |
|--|--|
| bmdSwitcherMacroRunStatusIdle | No macro is playing. |
| bmdSwitcherMacroRunStatusRunning | A macro is playing. |
| bmdSwitcherMacroRunStatusWaitingForUser | A macro is waiting for the user to continue playing. |

9.2.4 Macro Record Status

BMDSwitcherMacroRecordStatus enumerates the possible macro record states.

| | |
|--|-----------------------------|
| bmdSwitcherMacroRecordStatusIdle | No macro is being recorded. |
| bmdSwitcherMacroRecordStatusRecording | A macro is being recorded. |

9.3 Interface Reference

9.3.1 **IBMDSwitcherMacroPool** Interface

The **IBMDSwitcherMacroPool** object interface provides functionality for the transfer and deletion of macros and for accessing and modifying macro properties.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|--|
| IBMDSwitcher | IID_IBMDSwitcher | An IBMDSwitcherMacroPool object interface can be obtained with the IBMDSwitcher:QueryInterface method. |

| Public Member Functions | |
|-------------------------|---|
| Method | Description |
| GetMaxCount | Gets the number of macros that can be stored. |
| Delete | Deletes a macro. |
| IsValid | Checks if a macro exists. |
| HasUnsupportedOps | Checks if a macro has unsupported operations. |
| GetName | Gets a macro's name. |
| SetName | Sets a macro's name. |
| GetDescription | Gets a macro's description. |
| SetDescription | Sets a macro's description. |
| CreateMacro | Creates an IBMDSwitcherMacro object. |
| Upload | Uploads a macro. |
| Download | Downloads a macro. |
| AddCallback | Adds a macro pool callback. |
| RemoveCallback | Removes a macro pool callback. |

9.3.1.1 IBMDSwitcherMacroPool::GetMaxCount method

The **GetMaxCount** method returns the number of macros that can be stored on the switcher.

Syntax

```
HRESULT GetMaxCount (uint32_t* maxCount);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| maxCount | out | The maximum number of macros for the switcher. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| E_POINTER | The maxCount parameter is invalid. |
| S_OK | Success. |

9.3.1.2 IBMDSwitcherMacroPool::Delete method

The **Delete** method will delete (set invalid) an existing macro. If the macro is already invalid then this method has no effect.

Syntax

```
HRESULT Delete (uint32_t index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Macro index. |

Return Values

| Value | Description |
|--------------|--------------------------------------|
| E_INVALIDARG | The index parameter is out of range. |
| S_OK | Success. |

9.3.1.3 IBMDSwitcherMacroPool::IsValid method

The **IsValid** method checks if a macro with the specified index exists.

Syntax

```
HRESULT IsValid (uint32_t index, boolean* valid);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--|
| index | in | Macro index. |
| valid | out | Boolean value which is true if the macro is valid. |

Return Values

| Value | Description |
|--------------|--------------------------------------|
| E_POINTER | The valid parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| S_OK | Success. |

9.3.1.4 IBMDSwitcherMacroPool::HasUnsupportedOps method

The **HasUnsupportedOps** method indicates whether a macro contains unsupported operations. A macro with unsupported operations can still be played but the unsupported operations will be ignored.

Syntax

```
HRESULT HasUnsupportedOps (uint32_t index, boolean* hasUnsupportedOps);
```

Parameters

| Name | Direction | Description |
|-------------------|-----------|---|
| index | in | Macro index. |
| hasUnsupportedOps | out | Boolean value which is true if the macro contains unsupported operations. |

Return Values

| Value | Description |
|--------------|---|
| E_POINTER | The hasUnsupportedOps parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| S_OK | Success. |

9.3.1.5 **IBMDSwitcherMacroPool::GetName method**

The **GetName** method gets the name of a macro.

Syntax

```
HRESULT      GetName (uint32_t index, string* name);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Macro index. |
| name | out | Macro name. |

Return Values

| Value | Description |
|---------------|--------------------------------------|
| E_POINTER | The name parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to get the name. |
| S_OK | Success. |

9.3.1.6 IBMDSwitcherMacroPool::SetName method

The **SetName** method sets the name of a macro.

Syntax

```
HRESULT SetName (uint32_t index, string name);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Macro index. |
| name | in | Macro name. |

Return Values

| Value | Description |
|---------------|--------------------------------------|
| E_POINTER | The name parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to set the name. |
| S_OK | Success. |

9.3.1.7 IBMDSwitcherMacroPool::GetDescription method

The **GetDescription** method gets the description of a macro.

Syntax

```
HRESULT GetDescription (uint32_t index, string* description);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|--------------------|
| index | in | Macro index. |
| description | out | Macro description. |

Return Values

| Value | Description |
|---------------|---|
| E_POINTER | The description parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to get the description. |
| S_OK | Success. |

9.3.1.8 IBMDSwitcherMacroPool::SetDescription method

The **SetDescription** method sets the description of a macro.

Syntax

```
HRESULT SetDescription (uint32_t index, string description);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|--------------------|
| index | in | Macro index. |
| description | out | Macro description. |

Return Values

| Value | Description |
|---------------|---|
| E_POINTER | The description parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to set the description. |
| S_OK | Success. |

9.3.1.9 IBMDSwitcherMacroPool::CreateMacro method

The **CreateMacro** method creates an **IBMDSwitcherMacro** object. **IBMDSwitcherMacro** objects are only used for transfers.

Syntax

```
HRESULT CreateMacro (uint32_t sizeBytes, IBMDSwitcherMacro** macro);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|--------------------------------------|
| sizeBytes | in | The size of the macro, in bytes. |
| macro | out | The IBMDSwitcherMacro object. |

Return Values

| Value | Description |
|---------------|--|
| E_OUTOFMEMORY | Insufficient memory to create a macro. |
| S_OK | Success. |

9.3.1.10 **IBMDSwitcherMacroPool::Upload method**

The **Upload** method transfers a macro to the switcher. No more than one transfer can occur at a time.

Syntax

```
HRESULT Upload (uint32_t index, string name, string description, IBMDSwitcherMacro* macro,
                IBMDSwitcherTransferMacro** macroTransfer);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|--|
| index | in | Destination macro index. |
| name | in | Destination macro name. |
| description | in | Destination macro description. |
| macro | in | IBMDSwitcherMacro object containing the macro binary data for the transfer. |
| macroTransfer | out | IBMDSwitcherMacroTransfer object for monitoring the progress of the transfer. |

Return Values

| Value | Description |
|---------------|---|
| E_POINTER | The name, description, or macro parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to perform a transfer. |
| S_OK | Success. |

9.3.1.11 IBMDSwitcherMacroPool::Download method

The **Download** method transfers a macro from the switcher. No more than one transfer can occur at a time.

Syntax

```
HRESULT Download (uint32_t index, IBMDSwitcherTransferMacro** macroTransfer);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|---|
| index | in | Destination macro index. |
| macroTransfer | out | IBMDSwitcherMacroTransfer object for monitoring the progress of the transfer and retrieving the macro binary data. |

Return Values

| Value | Description |
|---------------|--|
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to perform a transfer. |
| S_OK | Success. |

9.3.1.12 IBMDSwitcherMacroPool::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMacroPool** object. Pass an object implementing the **IBMDSwitcherMacroPoolCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMacroPoolCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMacroPoolCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| E_INVALIDARG | The callback parameter is invalid. |
| S_OK | Success. |

9.3.1.13 IBMDSwitcherMacroPool::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMacroPoolCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| callback | in | Callback object implementing the IBMDSwitcherMacroPoolCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| E_INVALIDARG | The callback parameter is invalid. |
| S_OK | Success. |

9.3.2 **IBMDSwitcherTransferMacro** Interface

The **IBMDSwitcherTransferMacro** object interface provides methods to cancel a macro transfer, monitor transfer progress, and retrieve transferred macro binary data.

Related Interfaces

| Interface | Interface ID | Description |
|-------------------------------|---------------------------|--|
| IBMDSwitcherMacroPool | IID_IBMDSwitcherMacroPool | IBMDSwitcherMacroPool::Upload and IBMDSwitcherMacroPool::Download return an IBMDSwitcherTransferMacro object. |
| IBMDSwitcherMacroPoolCallback | IID_IBMDSwitcherMacroPool | IBMDSwitcherMacroPoolCallback::Notify passes in an IBMDSwitcherTransferMacro object. |

| Public Member Functions | |
|-------------------------|--|
| Method | Description |
| Cancel | Cancels the pending transfer. |
| GetProgress | Gets the pending transfer's progress. |
| GetMacro | Gets an IBMDSwitcherMacro object from a completed transfer. |

9.3.2.1 IBMDSwitcherTransferMacro::Cancel method

The **Cancel** method cancels the pending transfer. If there is no pending macro transfer then this method has no effect.

Syntax

HRESULT Cancel (void);

Parameters

none

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.2.2 IBMDSwitcherTransferMacro::GetProgress method

The **GetProgress** method gets the progress of the pending transfer.

Syntax

HRESULT GetProgress (double* progress);

Parameters

| Name | Direction | Description |
|----------|-----------|---|
| progress | out | Transfer progress. Range is between 0.0 to 1.0. |

Return Values

| Value | Description |
|-----------|------------------------------------|
| E_POINTER | The progress parameter is invalid. |
| S_OK | Success. |

9.3.2.3 IBMDSwitcherTransferMacro::GetMacro method

The **GetMacro** method gets the transferred **IBMDSwitcherMacro** object.

Syntax

```
HRESULT GetMacro (IBMDSwitcherMacro** macro);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--|
| macro | out | Pointer to an IBMDSwitcherMacro object. |

Return Values

| Value | Description |
|--------------|---------------------------------|
| E_POINTER | The macro parameter is invalid. |
| E_UNEXPECTED | No transfer has been initiated. |
| S_OK | Success. |

9.3.3 **IBMDSwitcherMacro Interface**

The **IBMDSwitcherMacro** object interface provides access to macro binary data used for transferring macros.

This interface does not provide access to macro properties or control to record or playback a macro. To access properties use the **IBMDSwitcherMacroPool** interface. To record or playback a macro use the **IBMDSwitcherMacroControl** interface.

Related Interfaces

| Interface | Interface ID | Description |
|---------------------------|-------------------------------|--|
| IBMDSwitcherMacroPool | IID_IBMDSwitcherMacroPool | IBMDSwitcherMacroPool::CreateMacro returns an IBMDSwitcherMacro object. |
| IBMDSwitcherTransferMacro | IID_IBMDSwitcherMacroTransfer | IBMDSwitcherMacroTransfer::GetMacro returns an IBMDSwitcherMacro object. |

Public Member Functions

| Method | Description |
|----------|--|
| GetSize | Gets the size (in bytes) of the macro binary data. |
| GetBytes | Gets a pointer to the macro binary data buffer. |

9.3.3.1 IBMDSwitcherMacro::GetSize method

The **GetSize** method returns the size (in bytes) of the macro binary data.

Syntax

```
uint32_t GetSize (void);
```

Parameters

none

Return Values

| Value | Description |
|-------|---|
| Size | Size (in bytes) of the macro binary data. |

9.3.3.2 IBMDSwitcherMacro::GetBytes method

The **GetBytes** method returns a pointer to the macro binary data buffer.

Syntax

```
HRESULT GetBytes (void** buffer);
```

Parameters

| Name | Direction | Description |
|--------|-----------|-----------------------------------|
| buffer | out | Pointer to the macro binary data. |

Return Values

| Value | Description |
|-----------|----------------------------------|
| E_POINTER | The buffer parameter is invalid. |
| S_OK | Success. |

9.3.4 **IBMDSwitcherMacroPoolCallback Interface**

The **IBMDSwitcherMacroPoolCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherMacroPool** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|-----------------------|---------------------------|--|
| IBMDSwitcherMacroPool | IID_IBMDSwitcherMacroPool | An IBMDSwitcherMacroPoolCallback object interface is installed with IBMDSwitcherMacroPool::AddCallback and removed with IBMDSwitcherMacroPool::RemoveCallback |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

9.3.4.1 **IBMDSwitcherMacroPoolCallback::Notify** method

The **Notify** method is called when an **IBMDSwitcherMacroPool** event occurs, such as macro property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMacroPoolEventType eventType, uint32_t index,
                IBMDSwitcherTransferMacro* macroTransfer);
```

Parameters

| Name | Direction | Description |
|---------------|-----------|---|
| eventType | in | BMDSwitcherMacroPoolEventType that describes the type of event that has occurred. |
| index | in | Index of the macro that has changed. |
| macroTransfer | in | If the event type is one of bmdSwitcherMacroPoolEventTypeTransferCompleted , bmdSwitcherMacroPoolEventTypeTransferCancelled , or bmdSwitcherMacroPoolEventTypeTransferFailed then this parameter is a pointer to the affected IBMDSwitcherTransferMacro interface object. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5 **IBMDSwitcherMacroControl** Interface

The **IBMDSwitcherMacroControl** object interface provides macro recording state, playback state, and control.

Related Interfaces

| Interface | Interface ID | Description |
|--------------|------------------|--|
| IBMDSwitcher | IID_IBMDSwitcher | An IBMDSwitcherMacroControl object interface can be obtained with the IBMDSwitcher::QueryInterface . |

Public Member Functions

| Method | Description |
|-----------------|--|
| Run | Begins playback of a macro. |
| GetLoop | Gets the playback loop setting. |
| SetLoop | Sets the playback loop setting. |
| ResumeRunning | Resumes playback of a waiting macro. |
| StopRunning | Stops a playing or waiting macro. |
| Record | Begins recording of a new macro. |
| RecordUserWait | Inserts a user wait into the currently recording macro. |
| RecordPause | Inserts a time delay into the currently recording macro. |
| StopRecording | Ends recording. |
| GetRunStatus | Gets the current playback state. |
| GetRecordStatus | Gets the current record state. |
| AddCallback | Adds a macro control callback. |
| RemoveCallback | Removes a macro control callback. |

9.3.5.1 IBMDSwitcherMacroControl::Run method

The **Run** method begins playback of a macro.

Syntax

```
HRESULT Run (uint32_t index);
```

Parameters

| Name | Direction | Description |
|-------|-----------|--------------|
| index | in | Macro index. |

Return Values

| Value | Description |
|--------------|---|
| E_INVALIDARG | The index parameter is out of range or invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.2 IBMDSwitcherMacroControl::GetLoop method

The **GetLoop** method gets the current loop setting. When true, a running macro will loop back to the start when the last operation completes.

Syntax

```
HRESULT GetLoop (boolean* loop);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| loop | out | Boolean value which is true if playback will loop. |

Return Values

| Value | Description |
|-----------|--------------------------------|
| E_POINTER | The loop parameter is invalid. |
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.3 IBMDSwitcherMacroControl::SetLoop method

The **SetLoop** method sets the current loop setting. When true, a running macro will loop back to the start when the last operation completes.

Syntax

```
HRESULT SetLoop (boolean loop);
```

Parameters

| Name | Direction | Description |
|------|-----------|--|
| loop | in | Desired setting for loop, which is true if playback will loop. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.4 IBMDSwitcherMacroControl::ResumeRunning method

The **ResumeRunning** method continues playback of a macro that is waiting for the user. If there is no macro currently waiting then this method has no effect.

Syntax

```
HRESULT      ResumeRunning (void);
```

Parameters

none

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.5 IBMDSwitcherMacroControl::StopRunning method

The **StopRunning** method stops the currently playing macro. If there is no macro currently playing then this method has no effect.

Syntax

```
HRESULT      StopRunning (void);
```

Parameters

none

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.6 IBMDSwitcherMacroControl::Record method

The **Record** method begins recording of a new macro.

Syntax

```
HRESULT Record (uint32_t index, string name, string description);
```

Parameters

| Name | Direction | Description |
|-------------|-----------|---------------------------|
| index | in | Macro index. |
| name | in | Name of the macro. |
| description | in | Description of the macro. |

Return Values

| Value | Description |
|---------------|---|
| E_POINTER | The name or description parameter is invalid. |
| E_INVALIDARG | The index parameter is out of range. |
| E_OUTOFMEMORY | Insufficient memory to record a new macro. |
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.7 IBMDSwitcherMacroControl::RecordUserWait method

The **RecordUserWait** method inserts a user wait into the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT RecordUserWait (void);
```

Parameters

None

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.8 IBMDSwitcherMacroControl::RecordPause method

The **RecordPause** method inserts a timed pause into the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT RecordPause (uint32_t frames);
```

Parameters

| Name | Direction | Description |
|--------|-----------|--------------------------------|
| frames | in | Number of frames to pause for. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.9 IBMDSwitcherMacroControl::StopRecording method

The **StopRecording** method stops the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT StopRecording (void);
```

Parameters

none

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

9.3.5.10 **IBMDSwitcherMacroControl::GetRunStatus** method

The **GetRunStatus** method gets the current playback state of the switcher.

Syntax

```
HRESULT GetRunStatus (BMDSwitcherMacroRunStatus* status, boolean* loop, uint32_t* index);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| status | out | BMDSwitcherMacroRunStatus value indicating the macro playback state. |
| loop | out | Boolean value which is true if playback is set to loop. |
| index | out | Index of the macro that is playing/waiting. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The status, loop, or index parameter is invalid. |
| S_OK | Success. |

9.3.5.11 IBMDSwitcherMacroControl::GetRecordStatus method

The **GetRecordStatus** method gets the current record state of the switcher.

Syntax

```
HRESULT GetRecordStatus (BMDSwitcherMacroRecordStatus* status, uint32_t* index);
```

Parameters

| Name | Direction | Description |
|--------|-----------|---|
| status | out | BMDSwitcherMacroRecordStatus value indicating the macro recording state. |
| index | out | Index of the macro that is recording. |

Return Values

| Value | Description |
|-----------|--|
| E_POINTER | The status, or index parameter is invalid. |
| S_OK | Success. |

9.3.5.12 **IBMDSwitcherMacroControl::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMacroControl** object. Pass an object implementing the **IBMDSwitcherMacroControlCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMacroControlCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherMacroControlCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| E_INVALIDARG | The callback parameter is invalid. |
| S_OK | Success. |

9.3.5.13 IBMDSwitcherMacroControl::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMacroControlCallback* callback);
```

Parameters

| Name | Direction | Description |
|----------|-----------|--|
| callback | in | Callback object implementing the IBMDSwitcherMacroControlCallback object interface. |

Return Values

| Value | Description |
|--------------|------------------------------------|
| E_INVALIDARG | The callback parameter is invalid. |
| S_OK | Success. |

9.3.6 IBMDSwitcherMacroControlCallback Interface

The **IBMDSwitcherMacroControlCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherMacroControl** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

| Interface | Interface ID | Description |
|--------------------------|------------------------------|---|
| IBMDSwitcherMacroControl | IID_IBMDSwitcherMacroControl | An IBMDSwitcherMacroControlCallback object interface is installed with IBMDSwitcherMacroControl::AddCallback and removed with IBMDSwitcherMacroControl::RemoveCallback . |

Public Member Functions

| Method | Description |
|--------|------------------------------|
| Notify | Called when an event occurs. |

9.3.6.1 **IBMDSwitcherMacroControlCallback::Notify method**

The **Notify** method is called when an **IBMDSwitcherMacroControl** event occurs, such as a macro playback and recording states.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMacroControlEventType eventType);
```

Parameters

| Name | Direction | Description |
|-----------|-----------|---|
| eventType | in | BMDSwitcherMacroControlEventType that describes the type of event that has occurred. |

Return Values

| Value | Description |
|--------|-------------|
| E_FAIL | Failure. |
| S_OK | Success. |

